

CLAAS



SCORPION

7045 (from serial no. 403 03 0416)

7040 (from serial no. 402 03 0503)

7030 (from serial no. 401 03 0484)

Operator's Manual

SERVICE & PARTS

Contents

EC Declaration of Conformity	EG
EC declaration of conformity (model 401-03)	EG-1
EC declaration of conformity (model 402-03)	EG-2
EC declaration of conformity (model 403-03)	EG-3
Introduction	1
Operator's Manual	1-1
Important notice on this Operator's Manual	1-1
Notice on machine safety	1-1
Notice on maintenance, repairs and spare parts	1-1
Explanation of safety symbols	1-2
Explanation of abbreviations and symbols	1-2
Machine outside view	1-3
Brief description of telehandler	1-4
General information on the machine	1-4
Model designation – trade names	1-4
Main components of machine	1-4
Hydrostatic drive	1-5
Work hydraulics and 4 wheel steering	1-5
Cooling system	1-5
Telehandler warranty	1-5
Warranty claims	1-5
Fields of application and using a telehandler with an attachment	1-6
Authorised attachments	1-6
Legal regulations regarding telehandler operation	1-9
Principal regulations for the operating staff	1-9
Driving licence	1-9
Licence/identification	1-9
Adjusting the headlights	1-10
Machine inspections	1-10
Documents	1-10
On-board equipment	1-11
Warning identification of telehandler on public roads (option)	1-11
Type labels and component numbers	1-12
Explanation of "Book" symbol	1-12
Serial number	1-12
Cab number	1-12
Engine number	1-13
Hydraulic pump number	1-13
Variable displacement motor number	1-13
Variable displacement motor number (high speed option)	1-14
Front and rear axle numbers	1-14
Description of labels	1-15
Important notice on signs and labels	1-15
Labels on the outside of the machine	1-15
Labels inside the cab	1-17
Labels in the engine compartment	1-22
Safety instructions	2
Identification of warnings and dangers	2-1
Designated use and exemption from liability	2-2
General conduct and safety instructions	2-3
Organisational measures	2-3
Selection and qualification of staff, basic responsibilities	2-5
Safety instructions regarding operation	2-6
Normal operation	2-6

Applications with lifting gear	2-8
Trailer operation	2-8
Attachment operation	2-9
Transport	2-9
Safety instructions for maintenance	2-10
Maintenance work on protective ROPS and FOPS structures	2-12
ROPS/FOPS description	2-12
Cab, roll-over bar, protective screen	2-12
Warning of special hazards	2-12
Electric energy	2-12
Gas, dust, steam, smoke	2-13
Hydraulic equipment	2-13
Noise	2-13
Oil, grease and other chemical substances	2-13
Battery	2-14
Tyres	2-14
Operation	3
Information regarding the description of the control elements	3-1
Inside of cab (overview)	3-2
Control elements on the control lever and switch consoles: overview	3-4
Indicator lights and warning lights: description	3-6
Indicator light check	3-6
Indicator light and warning light – indicating instrument	3-6
Indicator light and warning light – front instrument panel	3-8
Before putting the machine into operation	3-9
Important information for the operating staff	3-9
Running-in period	3-9
“Diesel engine start” checklist	3-10
Checklist “Putting the machine into service”	3-11
Parking checklist	3-11
Cab	3-12
Safety instructions regarding cab entrance and exit	3-12
Safety instruction – side window (right)	3-12
Locking and unlocking the door	3-13
Closing and opening the side window (to a gap)	3-14
Completely opening and locking the side window	3-14
Opening/closing the rear window	3-15
Rear window emergency exit	3-15
Seat	3-16
Important notice on seat adjustment	3-16
Seat adjustment: overview	3-16
Weight adjustment	3-17
Backrest adjustment	3-17
Horizontal adjustment	3-17
Lumbar support adjustment (option)	3-18
Adjustment of horizontal suspension (option)	3-18
Adjustable seat suspension damper (option)	3-18
Heated seat (option)	3-18
Seat belt (lap belt)	3-19
Important notice on the seat belt	3-19
Fastening the seat belt	3-19
Unfastening the seat belt	3-20
Longer/shorter lap belt adjustment:	3-20
Engine cover	3-20
Opening/closing the engine cover	3-20

Air-suspension seat (option)	3-21
Important notice on air-suspension seat operation	3-21
Air-suspension seat operation	3-21
Fire extinguisher (option)	3-21
Fire extinguisher operation	3-21
Key-based drive interlock (option)	3-22
Coding ("training") new ignition keys	3-22
Enabling (locking) the drive interlock	3-23
Disabling (releasing) the drive interlock	3-23
Deleting coded keys	3-23
Safety functions	3-23
Drive interlock with code input (option)	3-24
Entering/changing the personal code	3-25
Enabling the drive interlock	3-25
Disabling the drive interlock	3-26
Putting the drive interlock out of operation	3-26
Putting the drive interlock back into operation again	3-27
Interruption of drive interlock power	3-27
Drive interlock maintenance	3-27
Battery master switch	3-27
Switching the battery master switch ON and OFF	3-27
Oil and fuel preheater (option)	3-28
Putting the coolant and oil preheater into operation	3-28
Fuel preheater (option)	3-28
Putting the diesel engine into operation	3-29
Preparing to start the engine	3-29
Starting the diesel engine	3-30
Avoiding running the engine under low-load conditions	3-31
Stopping the engine	3-31
Jump-starting the engine (external battery)	3-32
Safety instructions regarding external starting aids	3-32
Providing external starting aid	3-32
Error code displays (103 kW diesel engine)	3-33
Reading out the flash code	3-33
Warning limit – coolant temperature	3-33
Warning limit – charge-air temperature	3-34
Warning limit – engine oil pressure	3-34
Overview – description of flashing codes	3-35
Preparing for driving on public roads	3-38
Important notice regarding driving on public roads	3-38
Safety equipment for driving on public roads	3-39
Functional check of brakes, steering system and lights	3-39
Locking the control lever (joystick) and the 3rd control circuit (attachments) ..	3-39
Moving off the telehandler	3-40
Speed range selection	3-40
Driving direction selection (reversing operation forwards/reverse)	3-41
Selecting a speed range (low-speed control option)	3-42
Stopping/parking the machine	3-43
Steering system	3-44
Steering column height and angle adjustment	3-44
Checking the steering system	3-44
Synchronising the steering system	3-45
Changeover to front axle steering	3-46
Changing over to 4 wheel steering	3-46
Changing over to diagonal steering (crab steering option)	3-47

Accelerator pedal	3-48
Manual throttle (option)	3-48
Manual throttle operation	3-48
Brake/inching pedal	3-49
Important notice on brake/inching pedal actuation	3-49
Inching with the brake/inching pedal	3-49
Braking with the brake/inching pedal	3-49
Parking brake	3-50
Notice on the parking brake	3-50
Applying the parking brake	3-50
Telescopic boom load stabiliser	3-51
Information regarding the load stabiliser function	3-51
Switching the load stabiliser ON or OFF	3-52
Differential lock	3-53
Important information on the differential lock	3-53
Switching the differential lock ON and OFF	3-53
Backup warning system (option)	3-54
Information on the backup warning system	3-54
Electric mirror adjustment (option)	3-54
Adjusting the rearview mirror	3-54
Reversing fan (option)	3-54
Machine lights	3-55
Notice on machine lights	3-55
Machine lights operation	3-55
Working lights operation	3-56
Interior light operation (cab)	3-56
Signalling system	3-57
Turn indicator operation	3-57
Hazard warning system operation	3-57
Rotating beacon operation (option)	3-57
Cab heating and ventilation	3-58
Description of the heating and ventilation system	3-58
Ventilation and heating in fresh-air mode	3-58
Ventilation and heating in mixed mode	3-58
Air conditioning (option)	3-59
Information on putting the air conditioning into operation	3-59
Air conditioning operation	3-59
Washer system	3-60
Washer system operation	3-60
Tank for washer system	3-60
Telescopic boom control lever: overview	3-61
Operating the control lever for the lift, tilt and push-out rams	3-61
Safe load indicator for telescopic boom	3-62
Important notice on the safe load indicator	3-62
Important notice on the safe load indicator overload display	3-63
Overview of indicator lights on overload display	3-63
Functional check of the safe load indicator	3-63
What to do when the indicator lights come on	3-64
Operating the telescopic boom	3-65
Raising/extending the telescopic boom	3-65
Retracting/lowering the telescopic boom	3-65
Emergency lowering of telescopic boom in case of diesel engine breakdown	3-66
Lower or raise as follows:	3-66
Operating and securing the 3rd control circuit	3-67
Locking and unlocking the quickhitch or an attachment	3-67
Equipping the machine with a standard bucket	3-68
Pressure relief on the quickhitch couplers	3-68

Fitting a standard bucket onto the quickhitch	3-69
Field of application of bucket	3-69
Mounting an attachment on a quickhitch with a hydraulic lock	3-69
Mounting an attachment on a quickhitch with a mechanical lock	3-70
Removing a standard bucket from the quickhitch	3-71
Working with the standard bucket	3-72
Safety instructions regarding work with the bucket	3-72
Driving on public roads with a standard bucket	3-73
Moving with the bucket fully dumped out	3-73
Safety instructions for transporting material in a full bucket	3-74
Loading loose material	3-75
Loading if the material is hard to penetrate	3-75
Removing material/digging in soft soil	3-76
Removing material/digging in hard soil	3-77
Grading	3-77
Loading vehicles	3-77
Fitting a multipurpose bucket	3-78
Field of application of multipurpose bucket	3-78
Picking up a multipurpose bucket with the quickhitch	3-78
Connecting hydraulic lines to the 3rd control circuit	3-79
Removing the multipurpose bucket from the quickhitch	3-80
Working with the multipurpose bucket	3-81
Safety instructions for working with the multipurpose bucket	3-81
Driving on public roads with the multipurpose bucket	3-82
Moving with the multipurpose bucket fully dumped out	3-82
Safety instructions for transporting material in a full multipurpose bucket	3-83
Grading and scraping	3-84
Removing and spreading material in thin layers	3-84
Pulling out material from slopes	3-85
Moving material with longer reach	3-85
Picking up remaining material completely	3-85
Grabbing bulky material	3-86
Pulling out and setting posts	3-86
Backfilling round gravel and precise unloading	3-87
Unloading from the bottom of the bucket for increased dump heights	3-87
Fitting pallet forks	3-88
Picking up pallet forks with the quickhitch	3-88
Removing the pallet forks from the quickhitch	3-88
Driving on public roads with the pallet forks	3-89
Pallet forks transport position without load	3-89
Working with the pallet forks	3-90
Safety instructions regarding the use of the pallet forks	3-90
Brief instructions for fork arms	3-92
Load diagram for pallet forks	3-93
Pallet forks load	3-93
Adjusting the fork arms of the pallet forks	3-94
Picking up material with the pallet forks	3-95
Transporting loads with the pallet forks	3-96
"Hose burst valve" safety feature	3-97
Emergency lowering of the telescopic boom with the hose burst valve	3-97
Equipping the machine with a crane jib (option)	3-98
Important safety instructions for working with a crane jib	3-98
Fitting a crane jib onto the quickhitch	3-98
Working with a crane jib	3-99
Removing a crane jib from the quickhitch	3-99
Driving on public roads with a crane jib	3-99

Continuous operation of 3rd control circuit (option)	3-100
Switching continuous operation of 3rd control circuit ON/OFF	3-100
Tilt ram lock (option)	3-100
Switching the tilt ram lock ON and OFF	3-100
Electric changeover valve for operation of 3rd control circuit as additional front control circuit (option)	3-101
Switching the additional control circuit ON or OFF	3-101
Front/rear hydraulic additional control circuit (option)	3-102
Important notice on the additional control circuit	3-102
Quick couplers of additional control circuit (overview)	3-102
Connecting an attachment onto the additional control circuit	3-103
Operation of additional control circuit	3-104
Automatic bucket repositioning (option)	3-105
Switching on the automatic bucket repositioning	3-105
Tipping trailer connection (option)	3-105
Tipping trailer connection (overview and operation)	3-105
Operation of the Autohitch trailer coupling (option)	3-106
Notice on the Autohitch trailer coupling	3-106
Unlocking and opening the Autohitch trailer coupling	3-106
Locking the Autohitch trailer coupling	3-107
Automatic trailer coupling (option)	3-108
Notice on using the trailer coupling	3-108
Attaching a trailer	3-108
Uncoupling the trailer	3-109
Compressed-air brake system (option)	3-110
Important safety instructions regarding the compressed-air braking system	3-110
Coupling and uncoupling compressed-air hoses	3-110
Compressed-air gauge	3-111
Hydraulic trailer brake (option)	3-111
Notice on using the hydraulic trailer brake	3-111
Fitting attachments other than Kramer onto the quickhitch (option)	3-112
Quickhitches for attachments from other manufacturers	3-112
Important notice on fitting attachments from other manufacturers	3-112
Fitting attachments from other manufacturers	3-113
Example: inspection plan for attachments other than Kramer	3-114
Towing the machine	3-115
Safety instructions for towing away	3-115
Getting ready for towing	3-115
Towing the machine	3-116
Once towing is over	3-116
Loading and transporting the machine on a transport vehicle	3-117
Safety instructions regarding loading	3-117
Loading and tying down the machine	3-118
Tying down the machine	3-118
Crane handling the machine	3-119
Safety instructions regarding crane handling	3-119
Crane handling	3-120
Decommissioning the machine for a longer time	3-121
Preserving the piston rods of the hydraulic rams	3-121
Preserving the diesel engine	3-121
Final decommissioning of machine	3-122
Information on decommissioning	3-122
Preparing disposal	3-122
Disposal	3-122

Troubleshooter	4
Diesel engine malfunctions	4-1
Malfunctions in the air conditioning system (option)	4-3
Maintenance	5
Important information on maintenance work	5-1
Maintenance staff	5-1
Important safety instructions on maintenance work	5-1
Safety prop for telescopic boom	5-2
Mounting the safety prop	5-2
Fuel system	5-3
General safety instructions for refuelling	5-3
Diesel fuel specification	5-3
Stationary fuel pumps	5-3
Refuelling	5-4
Bleeding the fuel system	5-4
Checking/replacing the fuel prefilter (water separator)	5-5
Replacing the fuel filter	5-6
Cleaning the fuel cooler (option)	5-6
Diesel engine lubrication system	5-7
Important safety instructions for working on the lube oil system	5-7
Checking the engine oil level daily	5-7
Filling up engine oil	5-8
Replacing the engine oil (every 500 service hours)	5-9
Replacing the engine oil filter (every 500 service hours)	5-10
Engine and hydraulics cooling system	5-11
Safety instructions regarding cooling system maintenance	5-11
Notice on inspection and cleaning work	5-11
Temperature gauge: diesel engine coolant	5-12
Checking the coolant level and quality	5-12
Filling up coolant	5-13
Draining coolant	5-14
Cleaning the radiator fins	5-15
Cleaning the radiator with the reversing fan (option)	5-16
Air filter	5-17
Checking air filter contamination	5-17
Checking the dust collector (option) once a day	5-18
Replacing the filter cartridge at 500 s/h (service hours)	5-18
V-belts	5-19
Checking the V-belts	5-19
Retightening the V-belts	5-19
Hydraulic system	5-20
Specific safety instructions regarding the hydraulic system	5-20
Important notice on hydraulic oil	5-20
Monitoring the hydraulic oil and the return filter	5-21
Checking the hydraulic oil level once a day	5-22
Filling up hydraulic oil	5-22
Important notice regarding the use of biodegradable oil	5-23
Checking hydraulic pressure lines	5-24
Safety instructions regarding pressure line checks	5-24
Notice for the entrepreneur/owner	5-24
Lubrication work	5-25
Preparing lubrication	5-25
Lubricating the rear axle oscillation-type bearing	5-25
Lubricating the planetary drive bearing (front and rear axles)	5-25
Lubrication points on the telescopic boom: overview	5-26
Description of lubrication points	5-26

Lubricating the telescopic boom	5-27
Checking and adjusting the slide plates	5-27
Lubricating with the central lubrication system (option)	5-28
General functional description of the central lubrication system	5-28
Time control	5-28
Repair work	5-28
Setting the lubrication and break times	5-29
Filling the central lubrication system	5-29
Maintenance of the brake system	5-30
Important safety instructions regarding the brake system	5-30
Checking/filling up the brake fluid level	5-30
Maintenance: compressed-air brake system (option)	5-31
Checking the compressed-air tank and lines	5-31
Checking compressor attachment and drive	5-31
Tyres	5-32
Daily tyre checks	5-32
Changing wheels	5-33
Heating and ventilation system maintenance	5-34
General information on the heating system	5-34
Cleaning/replacing the fine-dust filter	5-34
Cleaning/replacing the recirculated-air filter	5-34
Air conditioning (option): maintenance	5-35
Safety instructions regarding the air conditioning	5-35
Filling up the air conditioning system	5-35
Checking the function, visual check and cleaning once a day	5-36
Maintenance of the electrical system	5-37
Important notice	5-37
Safety instructions regarding the electrical system and the battery	5-37
Checking/replacing the battery	5-38
Checks at regular intervals	5-39
Alternator	5-39
Checking/replacing relays and fuses	5-39
Main fuse box with switching relays	5-40
Maintenance of the automatic trailer coupling (option)	5-41
Cleaning and lubricating the trailer coupling	5-41
Check the trailer coupling for wear	5-41
Cleaning and maintenance work	5-42
Specific safety instructions regarding cleaning	5-42
Cleaning inside the cab	5-43
Cleaning the seat belt	5-43
Cleaning the exterior of the machine	5-43
Cleaning the engine and the engine compartment	5-44
Checking screw connections	5-44
Checking pivots and hinges	5-44
Maintenance of attachments and of the work equipment	5-44
Maintenance work "Aggressive Media" (option)	5-45
Important notice on anticorrosion protection	5-45
Components coated with anticorrosive wax	5-45
Measures for maintaining anticorrosive protection	5-46
Applying the protective anticorrosion coating	5-47
Treatment of oxidised surfaces	5-47
Maintenance plan (overview)	5-48
Fluids and lubricants	5-53
Maintenance label	5-54
Explanation of symbols on the maintenance label	5-54
Maintenance label overview	5-55

Specifications	6
Model and trade names: overview	6-1
Frame	6-1
Engine	6-1
Oil/water fan	6-2
Power train	6-2
Variable displacement pump	6-2
Variable displacement motor	6-2
Axles	6-3
Front axle	6-3
Rear axle	6-3
Service and parking brake	6-4
Steering system	6-4
Work hydraulics	6-5
Hydraulic pump	6-5
Hydraulic ram protection	6-5
Lift, tilt and push-out rams: velocity	6-5
Hydraulic pilot control	6-6
Usable consumer pressure at additional control circuit (option)	6-6
Electrical system	6-7
Fuse assignment	6-7
Electric components	6-8
Main fuse box with relays (88 kW diesel engine)	6-9
Main fuse box with relays (103 kW diesel engine)	6-9
Switching relay assignment	6-10
Tyres for models 401-03 / 402-03 / 403-03	6-11
Machine weights, axle loads	6-11
Noise levels	6-12
Vibrations, oscillation and acceleration value	6-12
Coolant compound table	6-12
Tightening torques	6-13
General tightening torques	6-13
Specific tightening torques	6-13
Trailer couplings: trailer weight/drawbar load	6-13
Load on pallet forks model 401-03 (without counterweight)	6-14
Load on pallet forks model 401-03 (with counterweight 2 x 150 kg)	6-15
Load on pallet forks model 402-03 (without counterweight)	6-16
Load on pallet forks model 402-03 (with counterweight 2 x 150 kg)	6-17
Load on pallet forks model 402-03 (with counterweight 2 x 300 kg)	6-18
Load on pallet forks model 403-03	6-19
Dimensions with bucket	6-20
Dimensions with pallet forks	6-21
Index	S
Index	S-1

1 Introduction

1.1 Operator's Manual

Important notice on this Operator's Manual

This Operator's Manual applies to the following telehandlers:

➡ Models: 401-03, 402-03, 403-03

It is primarily designated for the operator and provides instructions on the use, the adjustment, the operation and the maintenance of the machine.

Carefully read and understand the Operator's Manual before starting up, servicing or repairing the machine.

Pay particular attention to the "Safety Instructions" given in chapter 2.

The Operator's Manual must always be at hand at the place of use of the machine, and must therefore be kept in the storage compartment or net behind the seat.

Immediately replace an incomplete or illegible Operator's Manual with a new one.

In addition to the Operator's Manual, observe and instruct the operator in all other generally applicable legal and other mandatory regulations relevant to accident prevention and environmental protection.

CLAAS keep abreast of the latest technical developments and constantly improve their products. For this reason, we may from time to time need to make changes to diagrams and descriptions in this documentation which do not reflect products which have already been delivered and which will not be implemented on these machines.

Technical data, dimensions and weights are given as an indication only. Responsibility for errors or omissions not accepted.

Please contact your dealer if you require more information on the machine or the Operator's Manual.

Notice on machine safety

Your own safety, as well as the safety of others, depends to a great extent on how the machine is moved and operated.

Careful and prudent working is the best way to avoid accidents! – see chapter 2 "Selection and qualification of staff, basic responsibilities" on page 2-5.

Notice on maintenance, repairs and spare parts

Operational safety and readiness of the machine do not only depend on your reliable control, but also on maintenance and servicing of the machine. This is why regular maintenance and service work is absolutely necessary.



Notice!

Repair work, maintenance or modifications may be carried out only by specifically trained technical staff or by a workshop!

Insist on using original spare parts when carrying out maintenance and repair work.

The machine's permits, certifications, registrations, etc., may be withdrawn if machine parts/components with a prescribed condition or quality, or machine parts/components that can put persons at risk during operation, are subsequently modified or exchanged.

Explanation of safety symbols



This symbol identifies safety warnings. It is used to warn against potential personal risk or danger.

Therefore, pay particular attention to the safety information following this symbol.



This symbol identifies danger for the machine. It is used to avoid potential danger on the machine.

Explanation of abbreviations and symbols

The indication **left** or **right** in the descriptions always refers to the driving direction  of the machine.

Symbols	Explanation
•	Identification of general enumerations or lists of an activity
	Identification of activities to carry out
	Identification of results of an enumeration or lists of an activity
Abbreviations	Explanation
max.	maximum
e.g.	for example
Fig.	Figures
S/h	Service hour
Order no.	Order or part number
(opt)	Option

1.2 Machine outside view




Fig. 1: Machine outside views

Pos.	Description
1	Front eye hook for towing/tying down the machine
2	Headlights with turn indicators
3	Rear clearance light
4	Working lights (front/rear right, option)
5	Left/right rearview mirrors
6	Boom working light (option)
7	Hydraulic connections (telescopic boom additional control circuit option)
8	Air filter (preliminary separator option)
9	Engine cover
10	Eye hook ¹ only for installing/removing the cab
11	Rotating beacon (option)
12	Working light on left (standard)
13	Hydraulic connections (additional control circuit, option)

Pos.	Description
14	Trailer coupling (option)
15	Numberplate fixture (option)
16	Brake, rear and turn indicator lights
17	Door arrester
18	Rear eye hook for loading/tying down the machine
19	Handle for access
20	Cab access
21	Battery (battery master switch option)
22	Front-edge protection

1. Eye hooks are for removing the cab only, and may not be used for crane handling the machine

1.3 Brief description of telehandler

General information on the machine

According to German traffic regulations, the telehandler is a self-propelled work machine or tractor.

Get informed on and follow the legal regulations of your country.

Due to a wide range of possible attachments, the machine is a versatile and powerful helper in the construction industry, in agriculture and in recycling operations.

Other applications – [see Fields of application and using a telehandler with an attachment](#) on page 1-6.

Model designation – trade names

The machine is identified by two designations:

“**Model designation**” => stamped on the type label

“**Trade name**” => affixed outside on the machine

Model designation (version)	Trade name
401-03	7030
402-03	7040
403-03	7045

Main components of machine

- Sturdy steel sheet frame; rubber-mounted engine
- ROPS/FOPS tested cab
 - ➔ ROPS => Roll Over Protective Structure
 - ➔ FOPS => Falling Object Protective Structure
- Water-cooled turbocharged Deutz four-cylinder in-line engine
 - ➔ Exhaust emissions according to Directive 2004/26EC
- Drive Automotive, progressive hydrostatic axial-piston gearbox
 - ➔ Top speed 20 kph (30 or 40 kph option).
- Hydraulic power steering with emergency steering features (front wheel/four wheel/diagonal steering)
- Front and rear planetary steering axles, rear axle with oscillation
- Service brake (multidisc brake)
- Parking brake and auxiliary brake (spring-loaded brake effect on multidisc brake)
- Telescopic boom

Hydrostatic drive

The diesel engine permanently drives a hydraulic pump (variable displacement pump), whose oil flow is sent to a hydraulic motor flanged on the gearbox. The hydraulic motor transmits its power to the front and rear axles (via the transfer gearbox and the cardan shaft) for permanent 4 wheel drive.

Work hydraulics and 4 wheel steering

The diesel engine drives a gear or axial piston pump for the work hydraulics and the steering system, and a gear pump both for the fan (water/hydraulic oil radiator) and the boost pressure of the variable displacement pump (drive).

When the machine is in operation, the diesel engine output can be transmitted to the work hydraulics and the steering system to a large extent. This is made possible by a so-called inching valve which responds as soon as the service brake is used, reducing or cutting off power input of the drive. Therefore, engine output is fully available for the telescopic boom by pressing the accelerator pedal and the brake pedal at the same time.

Cooling system

A combined water/hydraulic oil cooler (for the diesel engine and the hydraulic oil) is located in the engine compartment. The fan drive (water/hydraulic oil cooler) is hydraulically driven by a gear pump located at the diesel engine's power take-off (optional charge-air cooler).

The indicator lights on the instrument panel of the machine ensure constant monitoring of the engine and hydraulic oil temperature (indicator lights), as well as of the coolant temperature and level.

1.4 Telehandler warranty

Warranty claims

Warranty claims can be made only if the conditions of warranty have been observed.

They are included in the General Conditions of Sales and Delivery for new machines and spare parts sold by the dealers. Furthermore, the instructions in this Operator's Manual must be observed.

1.5 Fields of application and using a telehandler with an attachment

The attachments will decide in the first place how the telehandler is used.



Caution!

In order to avoid damage to the machine, only the attachments listed in the table have been certified for installation on the machine.

☞ See table [Authorised attachments](#)

Mounting attachments other than Kramer is only allowed if they correspond to the description in chapter "Operation" [Fitting attachments other than Kramer onto the quickhitch \(option\)](#) on page 3-112.

Note that not all attachments listed in the table are allowed to be used on public roads.

The attachments complying with German road traffic regulations and the applicable provisions are listed in the **General Certification for Vehicles** (Germany) or the **data confirmation** (Germany)!

Attachments that are **not** listed in the table require an **EBE (separate certification for vehicles)** made out by the competent authority!

Get informed on and follow the legal regulations of your country.

Authorised attachments

Attachment ¹	Attachment type no.	Dimensions	Struck/heaped	Use	Telehandler model
Standard bucket – normal material ²	1000150361 1000150491	2400 mm (with teeth) 2400 mm (without teeth)	1.0/1.2 m ³	Loosening, picking up, transporting and loading loose or solid material (material density ≤ p = 1.8 t/m ³)	401-03, 402-03, 403-03
	1000151088 1000151089	2400 mm (with teeth) 2400 mm (without teeth)	1.3/1.6 m ³		402-03, 403-03
Standard bucket – light-weight material ^{2, 3}	1000158730 ⁴	2500 mm	1.5/1.8 m ³	Picking up, transporting and loading lightweight material (material density ≤ p = 1.3 t/m ³)	401-03, 402-03, 403-03
Standard bucket – superlight-weight material ^{2, 3}	1000176645 ⁴		2.0/2.5 m ³	Picking up, transporting and loading very lightweight material (material density ≤ p = 0.9 t/m ³)	401-03, 402-03, 403-03
	1000171728 ⁴	2500 mm	2.5/3.0 m ³	Picking up, transporting and loading grain (material density ≤ p = 0.7 t/m ³)	402-03, 403-03
Stone bucket ²	1000249312	2300 mm	–	Picking up and transporting large stones, e.g. flags	401-03, 402-03, 403-03
Multipurpose bucket with exchangeable blade ^{2, 7}	1000185558	2400 with teeth	1.1/1.2 m ³	Grading, removing and scraping vegetation, for example; picking up and evenly spreading material; grabbing bulky material; loading trucks (material density ≤ p = 1.8 t/m ³)	401-03, 402-03, 403-03

Attachment ¹	Attachment type no.	Dimensions	Struck/heaped	Use	Telehandler model
Silage bucket ^{2, 5}	1000174575	2400 mm	1.45 m ³	Picking up and transporting silage or recycling material (material density ≤ p = 1.1 t/m ³)	401-03, 402-03, 403-03
Silage bucket with hydraulic clamp ^{2, 5, 7}	1000249265	2300 mm	1.3 m ³		401-03, 402-03, 403-03
	1000249266	2300 mm	1.4 m ³		
	1000166717	2400 mm	2.4 m ³		
	1000166718		1.9 m ³		
	1000249267	2500 mm	1.5 m ³		
Manure/silage forks ^{2, 6, 7}	1000166758	Length 1000 mm Width 2300 mm	2.3 m ³	Picking up and transporting manure and silage	401-03, 402-03, 403-03
	1000166765	Length 1000 mm Width 2500 mm	2.5 m ³		
Manure forks with hydraulic grab ^{2, 6, 7}	1000249314 1000249480	2300 mm 2500 mm	–		401-03, 402-03, 403-03
Silage cutter ^{2, 6, 7}	1000249317	800 mm	–		401-03, 402-03, 403-03
Beet basket ^{2, 6, 7}	1000166760	2400 mm	2.0 m ³	Picking up and transporting beets	401-03, 402-03, 403-03
Heavy duty bucket with hydraulic clamp ^{2, 5, 7}	1000174577	2400 mm	1.3 m ³	Picking up, transporting and loading lightweight material (material density ≤ p = 1.3 t/m ³)	401-03, 402-03, 403-03
	1000174578		1.6 m ³	Picking up, transporting and loading lightweight material (material density ≤ p = 0.9 t/m ³)	402-03, 403-03
Pallet forks ^{2, 5, 6, 7}	1000171857	Length 1200 mm	Load diagram	Picking up and transporting pallets	401-03, 402-03, 403-03
	1000165368	Length 2000 mm			
	1000178248	Length 1500 mm			401-03, 402-03, 403-03
Floating pallet forks (floating fork arms) ^{2, 5, 6, 7}	1000171735	Length 1200 mm			401-03, 402-03, 403-03
Floating pallet forks (floating fork arms with hydraulic side shift) ^{2, 5, 6, 7}	1000171736	Length 1200 mm	Load diagram	Picking up, transporting and side-shifting pallets	401-03, 402-03, 403-03
Pallet forks (fork arms with hydraulic side shift) ^{2, 5, 6, 7}	1000174576				
	1000174581	Length 1600 mm			402-03, 403-03

Attachment ¹	Attachment type no.	Dimensions	Struck/heaped	Use	Telehandler model
Crane jib ^{2, 5, 6}	1000157237	Length 1300 mm	Load diagram	Picking up and transporting loads with lifting gear (cables, chains, belts)	401-03, 402-03, 403-03
Bale spike (3 tines) ^{2, 6}	1000166754	Length 1100 mm Width 1250 mm	Load diagram	Picking up and transporting hay and straw bales	401-03, 402-03, 403-03
Bale grapple ^{2, 6}	1000166756	Clamping width 800 – 1800 mm	–	Picking up and transporting hay and straw bales (load-bearing capacity 1500 kg)	401-03, 402-03, 403-03
Bale grapple V40 ^{2, 6, 7}	1000249268	–	–		401-03, 402-03, 403-03
Bale grapple W500 ^{2, 6, 7, 8}	1000249269	–	–		401-03, 402-03, 403-03
Adapter frame EURO quickhitch ^{2, 3}	1000157243	–	–	Picking up attachments	401-03, 402-03, 403-03
Material pusher ⁶	1000249311	Width 2500 mm		For moving loose bulk material	401-03, 402-03, 403-03
Box tipper ^{2, 7}	1000249315	Length 1200 mm	3.5 t	–	401-03, 402-03, 403-03
Rotary broom ^{6, 7}	1000174580	–		Street cleaning	401-03, 402-03, 403-03
Snow plough ^{6, 7}	1000174579	–		Winter service	401-03, 402-03, 403-03

1. Get informed on the legal regulations of your country for information on mounting attachments
2. Bear in mind the safe load indicator when working with this attachment
3. When using this bucket on public roads, mount the right and left-hand headlights in a higher position and readjust them – see "Adjusting the headlights" on page 1-10
4. With screwed-on bucket blade
5. Only with load diagram for telehandler
6. Not authorised for use on public roads
7. See the Operator's Manual of the attachment for putting the attachment into operation and using it
8. Attachment can be operated only with a switchable 3rd control circuit.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com