

**DOMINATOR 130**

**Operator's Manual**

**Original Operator's Manual**

## Validity of manual

Machine	Type	Vehicle identification number	
<b>From</b>	<b>To</b>		
DOMINATOR 130	456	45600011	–
DOMINATOR 130	C14	C1400011	–

## **Information about this Operator's Manual**

Read this Operator's Manual thoroughly in order to make yourself familiar with safe and correct operation, maintenance and transportation of the machine. This avoids injuries and machine damage. If you cannot understand parts of the Operator's Manual, contact a CLAAS Sales Partner.

This Operator's Manual is part of the machine and must be handed over to the buyer of the machine in case of resale. In case of loss or damage, the Operator's Manual and the safety decals applied to the machine can be reordered from a CLAAS Sales Partner. This Operator's Manual is also available in other languages.

Directions such as front, rear, right and left refer to the direction of forward travel.

## Intended use

The CLAAS combine harvester is designed exclusively for professional use in line with the recognised regulations of agricultural practices in agricultural harvesting of grain.

The combine harvester is a self-propelled harvesting machine with a fitted front attachment (machine), which is approved by the manufacturer, and is suitable and intended for harvesting grain in fields during travel. Grain here refers to cultivated cereal and legume crops such as wheat, rye, barley, oats, rice, rape seed, maize, durra, soya beans and sunflowers.

The combine harvester takes the grain from the front attachment and conveys it via a conveying unit to the threshing and separating units. There, the grains are separated from straw and chaff. The straw and chaff are deposited on the field using the distribution units behind the combine harvester. The grain is stored temporarily in the combine harvester's grain tank and then loaded on a transport vehicle by a conveying unit.

When the combine harvester is driven on public roads, a front attachment approved by the manufacturer can be fitted on the front, depending on the applicable regulations, and driven with the combine harvester, or a trailer approved by the manufacturer that is loaded with the front attachment can be coupled to the trailer hitch and towed.

The machine may only be used, maintained and serviced by persons who are familiar with the machine and briefed on the hazards that may arise as a result of the machine's functions.

Compliance with the conditions of operation, maintenance and servicing as specified in the operator's manual and by the manufacturer also constitute essential elements for the intended use.

The relevant accident prevention regulations, all other generally recognised regulations on safety and occupational medicine and the road traffic regulations must be observed by users and owners at all times.

Any use other than this is considered <unintended>, and the manufacturer is not liable for any resulting damage. All liability in this case is borne by the user.

For specific details, you may request information on intended use in exceptional situations from CLAAS.

## Reasonably foreseeable misuse

Any use outside of the intended use is a use not planned by the machine manufacturer and therefore represents a misuse in the sense of the Machinery Directive. The manufacturer accepts no liability for damage resulting from this. All liability is borne by the user.

Misuse of the CLAAS combine harvester includes:

- Use of areas and spaces not described as workplace, maintenance place or access area in the Operator's Manual
- Performance of adjustment work, cleaning work and maintenance work against the specifications in the Operator's Manual
- Performance of fault elimination and servicing work with drives and/or the diesel engine running
- Non-observance of warning signs on the machine and in the Operator's Manual
- Performance of servicing and repair work by untrained personnel
- Unauthorised modifications to the machine
- Attachment of non-approved additional equipment
- Use of spare parts that do not meet CLAAS requirements
- Use in a stationary position
- Use to harvest goods that are not classified as grain
- Use as a carrier vehicle for units not approved by the manufacturer
- Use as a general towing vehicle / carrier vehicle
- Use for compacting goods and subsurfaces
- People transport
- Goods transport

## Hazard signs



This hazard sign warns of risks of injury.

- ▶ To avoid injuries and death, follow all measures marked by this hazard sign.

## Signal word

The warnings in this Operator's Manual are introduced by the hazard sign and a signal word. The signal word expresses the extent of the hazard.

### **DANGER!**

DANGER identifies a dangerous situation that leads to death or serious injury if not avoided.

---

### **WARNING!**

WARNING identifies a dangerous situation that may lead to death or serious injury if not avoided.

---

### **CAUTION!**

CAUTION identifies a dangerous situation that may lead to slight injuries if not avoided.

---

## **Importance of Operator's Manual**

The Operator's Manual is an important document and a part of the machine. It addresses the user and contains safety-relevant information. Only the procedures specified in the Operator's Manual are safe.

- ▶ Read and observe the safety chapter of the machine before using it for the first time.
- ▶ Read and observe the relevant chapters of the Operator's Manual before starting work.
- ▶ When failing to understand content or when help is needed, contact a CLAAS Sales Partner.

## Observing safety decals and warnings

Safety decals on the machine and warnings in the Operator's Manual warn you of hazards in danger areas and are important parts of the machine's safety equipment. Missing or unidentifiable safety decals increase the risk of serious and fatal injuries.

- ▶ Read and observe the safety instructions and warnings in the Operator's Manual and the safety decals on the machine before putting the machine into operation.
- ▶ Clean any dirty safety decals.
- ▶ Replace any missing and unidentifiable safety decals with new ones immediately.
- ▶ Apply the appropriate safety decals to spare parts.
- ▶ Spare parts and components from suppliers may contain safety instructions that are not mentioned in this Operator's Manual.

## **Requirements for all persons working with the machine**

All persons working with the machine must meet the minimum requirements below in order to avoid accidents:

- They are physically capable of controlling the machine.
- They are healthy and do not suffer from tiredness.
- They are not under the influence of drugs.
- They can carry out the work described in this Operator's Manual safely.
- They understand the functions of the machine and can identify and avoid hazards involved in the work.
- They have understood the Operator's Manual and can put the information provided in the Operator's Manual into action.
- They are familiar with the safe driving of vehicles.
- For road travel, they are familiar with the relevant road traffic rules and have the necessary driver's licence.

## **Children in danger**

Children cannot judge hazards and behave unpredictably. This is why children are particularly endangered.

- ▶ Never allow children to accompany you on the machine.
- ▶ Keep children away.
- ▶ Before starting off and before starting any machine movements, ensure that there are no children in the hazard area.

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)