

SERVICE MANUAL

Boomer™ 41
Boomer™ 47
Tier 4B (final)
Compact Tractor


Part number 47941902

2nd edition English

March 2016

Replaces part number 47700457





SERVICE MANUAL

Boomer™ 41 TIER 4B (FINAL), ROPS
Boomer™ 41 TIER 4B (FINAL), Cab
Boomer™ 47 TIER 4B (FINAL), ROPS
Boomer™ 47 TIER 4B (FINAL), Cab

Link Product / Engine

Product	Market Product	Engine
Boomer™ 41 TIER 4B (FINAL), ROPS	North America	N844L-F-30
Boomer™ 41 TIER 4B (FINAL), Cab	North America	N844L-F-30
Boomer™ 47 TIER 4B (FINAL), ROPS	North America	N844L-F-34
Boomer™ 47 TIER 4B (FINAL), Cab	North America	N844L-F-34

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.206] Fuel filters	10.3
[10.304] Engine lubrication system.....	10.4
[10.400] Engine cooling system	10.5
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.6
Clutch	18
[18.100] Clutch mechanical release control	18.1
[18.110] Clutch and components	18.2
[18.112] Slip clutch or flywheel damper	18.3
Transmission	21
[21.114] Mechanical transmission	21.1
[21.140] Mechanical transmission internal components.....	21.2
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.310] Final drives	25.4
Rear axle system	27
[27.106] Rear bevel gear set and differential	27.1
[27.120] Planetary and final drives	27.2
Hydrostatic drive	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.202] Hydrostatic transmission	29.2

[29.218] Pump and motor components.....	29.3
Power Take-Off (PTO).....	31
[31.101] Rear mechanical control	31.1
[31.104] Rear electro-hydraulic control.....	31.2
[31.110] One-speed rear Power Take-Off (PTO)	31.3
[31.120] Central Power Take-Off (PTO)	31.4
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.120] Mechanical service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.104] Fixed displacement pump	35.2
[35.114] Three-point hitch control valve	35.3
[35.116] Three-point hitch cylinder	35.4
[35.204] Remote control valves	35.5
[35.300] Reservoir, cooler, and filters.....	35.6
[35.350] Safety and main relief valves	35.7
[35.355] Hydraulic hand control	35.8
Hitches, drawbars, and implement couplings.....	37
[37.108] Rear three-point hitch external controls.....	37.1
[37.110] Rear three-point hitch	37.2
Steering.....	41
[41.101] Steering control	41.1
[41.106] Tie rods.....	41.2
[41.200] Hydraulic control components.....	41.3
[41.216] Cylinders	41.4
Wheels	44

[44.511] Front wheels	44.1
[44.520] Rear wheels	44.2
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.011] Fuel tank system	55.2
[55.031] Parking brake electrical system	55.3
[55.048] Rear Power Take-Off (PTO) control system	55.4
[55.100] Harnesses and connectors	55.5
[55.201] Engine starting system	55.6
[55.202] Cold start aid	55.7
[55.302] Battery	55.8
[55.404] External lighting	55.9
[55.405] External lighting switches and relays	55.10
[55.408] Warning indicators, alarms, and instruments	55.11
[55.513] Cab transmission controls	55.12
[55.525] Cab engine controls	55.13
[55.610] Ground speed control	55.14
[55.640] Electronic modules	55.15
[55.989] Exhaust Gas Recirculation (EGR) electrical system	55.16
[55.DTC] FAULT CODES	55.17
Platform, cab, bodywork, and decals	90
[90.100] Engine hood and panels	90.1
[90.114] Operator protections	90.2
[90.116] Fenders and guards	90.3

[90.120] Mechanically-adjusted operator seat..... 90.4

[90.150] Cab..... 90.5

[90.151] Cab interior..... 90.6

[90.154] Cab doors and hatches 90.7

[90.156] Cab glazing 90.8

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com