

Product: EXCAVATOR

Model: 320-A EXCAVATOR 2DL

Configuration: 320, 320L & 320N TRACK-TYPE EXCAVATORS 2DL00214-UP (MACHINE) POWERED BY 3066 ENGINE

Disassembly and Assembly 3064 and 3066 Engines for Caterpillar Built Machines

Media Number -SEN5553-10

Publication Date -01/05/2012

Date Updated -15/05/2012

i01150941

Inlet and Exhaust Valve Seals - Remove and Install

SMCS - 1104-010-SA

Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	5P-1720	Seal Pick	1

Start By:

- A. Remove the inlet and exhaust valves. Refer to Disassembly and Assembly, "Inlet and Exhaust Valves - Remove and Install".

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.



Illustration 1

g00610601




Illustration 2

g00610605

1. Use Tool (A) to remove valve stem seal (1) from the inlet and exhaust valve guide.

Illustration 1 shows the removal of the valve stem seal, when the valve guide (2) is removed from cylinder head (4) .

Illustration 2 shows the removal of the valve stem seal, while the valve guide (2) is installed in cylinder head (4) .

Installation Procedure

Table 2

Required Tools			
Tool	Part Number	Part Description	Qty
A	5P-1720	Seal Pick	1

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

Note: Do not apply any oil or sealant to the mating surface of the valve seal that comes into contact with the valve guide. When the valve seal is installed, coat the surface of the valve stem with engine oil in order to ensure initial lubrication of the seal lip.




Illustration 3

g00610601




Illustration 4

g00610605

1. Place the new valve stem seal in position on the valve guide.
2. Use Tool (A) to assist in installing the new valve stem seal.

Illustration 3 shows the installation of the valve stem seal, when the valve guide (2) is removed from the cylinder head (4) .

Illustration 4 shows the installation of the valve stem seal, while the valve guide (2) is installed in the cylinder head (4) .

Note: After the valve stem seal is installed on the valve guide, ensure that the seal is properly installed in the groove of the valve guide.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com