



Model: 385C FRONT SHOVEL MMA

Configuration: 385C FS Excavator MMA00001-UP (MACHINE) POWERED BY C-18 Engine

Disassembly and Assembly C15 and C18 Engines for Caterpillar Built Machines

Media Number -REN8261-28

Publication Date -01/08/2015

Date Updated -28/08/2018

i02905549

Valve Actuator (Variable) - Remove

SMCS - 1105-011

Removal Procedure

Start By:

- a. Remove the valve mechanism cover. Refer to Disassembly and Assembly, "Valve Mechanism Cover - Remove and Install".

Note: Do not disassemble the variable valve actuator after the component has been removed. Any attempt to disassemble the variable valve actuator will void the warranty of the component.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

Dispose of all fluids according to local regulations and mandates.

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.




Illustration 1

g01446246

1. Disconnect harness assembly (4). Disconnect harness assembly (1).
2. Remove bolt (2). Remove four nuts (3) and two nuts (6).
3. Remove variable valve actuator (5).




Illustration 2

g01446248

4. Remove support (11) and stud (10).

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com