Product: EXCAVATOR
Model: 385C FS EXCAVATOR T2F
Configuration: 385C FS Excavator T2F00001-UP (MACHINE) POWERED BY C18 Engine

Disassembly and Assembly C15 and C18 Engines for Caterpillar Built Machines

Media Number -RENR8261-28 Publication Date -01/08/2015

Date Updated -28/08/2018

i02905633

Valve Actuator (Variable) - Install


SMCS - 1105-012

Installation Procedure

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.






Illustration 2

g01446408

- 1. Install two studs (9) at Location 6 and Location 7. Tighten studs (9) to a torque of 47 ± 9 N·m (35 ± 7 lb ft).
- 2. Install stud (10) at Location 2. Tighten stud (10) to a torque of 65 ± 10 N·m (48 ± 7 lb ft). Install support (11).
- 3. Position rocker arm assembly (8). Install three studs (7) at Location 3, Location 4, and Location 5. Tighten studs (7) to a torque of 50 ± 5 N·m (37 ± 4 lb ft). Turn studs (7) for an additional 45 ± 5 degrees.




Illustration 3

g01446246

- 4. Install variable valve actuator (5).
- 5. Install bolt (2). Install four nuts (3). Install two nuts (6). Refer to the tightening sequence.
- 6. Tighten bolt (2) to a torque of 105 ± 20 N⋅m (77 ± 15 lb ft). Tighten nuts (3) to a torque of 105 ± 20 N⋅m (77 ± 15 lb ft). Tighten nuts (6) to a torque of 47 ± 9 N⋅m (35 ± 7 lb ft). Tighten the nuts and the bolt in a numerical sequence.
- 7. Connect harness assembly (4). Connect harness assembly (1) to variable valve actuator (5).

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com