

CURSOR I3 NON EMISSIONS CERTIFIED

Power generation

**CRI3 TE 7W
F3HFA6I5A*D00I**

**CRI3 TE 6W
F3HFA6I5B*D00I**

Technical repair manual

Introduction

	Section
GENERAL INFORMATION	3
SYMBOLS	3
<input type="checkbox"/> Warnings	3
<input type="checkbox"/> Service operations	3
GENERAL WARNINGS	5
GENERAL WARNINGS REGARDING THE ELECTRICAL SYSTEM ..	7
<input type="checkbox"/> Grounding and screening	8
CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND THE MOST COMMONLY USED DERIVED SIZES	9
PAGE HEADER AND FOOTER INTERPRETATION	10

GENERAL INFORMATION

Manuals for repairs are split into Parts and Sections, each one of which is marked by a number; the contents of these sections are indicated in the general table of contents.

Sections with mechanical contents include technical data, tightening torque collections, tool lists, assembly connections - disconnections, overhauls at the bench, troubleshooting and scheduled maintenance.

On sections or parts of the electric/electronic system section there are the descriptions of the electric network and the electronic systems of the assembly, wiring diagrams, electric characteristics of components, component codes and troubleshooting relative to the control units specific to the electric system.

Section 1 describes the engine operation and its general features.

Section 2 describes the type of fuel supply and the engine operating diagrams.

Section 3 refers specifically to the electrical equipment and regards wiring, electrical and electronic appliances which differ depending on use.

Section 4 describes scheduled maintenance and specific overhauling.

Section 5 deals with removal-refitting operations of the main components of the engine.

Section 6 describes the general mechanical overhaul of the engine fitted on the rotating stand.

Section 7 provides the technical specifications of the engine such as data, fitting clearance and tightening torques.

Section 8 deals with the equipment required for carrying out the operations.

The appendix provides a list of the general safety regulations which all operators, whether installers or maintenance technicians, must comply with to prevent any serious injury.

The manual uses proper symbols in its descriptions; the purpose of these symbols is to classify information. In particular, a set of symbols has been defined to classify warnings, while another set has been specified for service operations.

SYMBOLS - Warnings



Danger for persons

Missing or incomplete observance of these prescriptions can cause serious danger for persons' safety.



Risk of serious damage to the assembly

The partial or total non-observance of these instructions could cause serious damage to the assembly and may nullify the warranty.



General danger

Includes the dangers of both above described signals.




Environmental protection

Indicates correct behaviour in order for the assembly use to be as environmentally friendly as possible.

NOTA Indicates an additional explanation for a piece of information.

Service operations

Example:


































Ø 1 = Housing for connecting rod small end bush.

Ø 2 = Housing for connecting rod bearings



Tighten to torque
Tighten to torque + angle value

	Removal Disconnect		Intake
	Refitting Connect		Exhaust
	Disassembly Dismantling		Operation
	Assembly Assemble	ϱ	Compression ratio
	Tighten to the specified torque		Tolerance Weight difference
	Tighten to the specified torque + angle value		Rolling torque
	Press or caulk		Rotation
	Registration Adjustment		Angle Angle value
	Visual check Fitting position check		Preload
	Measuring Value to be found Check		Revolutions per time unit
	Tools		Temperature
	Surface for machining Finished workpiece		Pressure
	Interference Forced assembly	$>$	Oversized Oversized by no more than Max.
	Clearance Shim	$<$	Undersized Undersized by no more than..... Min.
	Lubricate Moisten Grease		Selection of oversizing class
	Coolant Sealant		Temperature $< 0^{\circ} \text{C}$ Cold Winter
	Bleeding air		Temperature $> 0^{\circ} \text{C}$ Hot Summer

GENERAL WARNINGS



The warnings shown may not be representative of all the dangerous situations that may occur. Therefore, supervisors should be contacted whenever a dangerous situation that has not been described occurs.

Use both specific and general-purpose toolings according to the prescriptions contained in respective use and maintenance handbooks. Check the working condition and suitability of tools not subject to periodic review.

The manual handling of loads must be assessed in advance since it also depends not only on weight but also on its size and on the path.

Handling by mechanical means must be with hoisters proper as for weight as well as for shape and volume. Hoisters, ropes and hooks used must show clear indications regarding maximum acceptable carrying capacity. The use of such tools is strictly permitted by authorised personnel only. Stay at a safe distance from the load and never below it.

In disassembly operations, always observe the provided prescriptions and prevent any mechanical parts being taken out from accidentally striking workshop personnel.

Shop activities performed by two technicians must always been executed with caution; avoid operations that may be dangerous for any collaborators due to lack of field of vision or incorrect position.

Keep any personnel not assigned to the operations clear of working area.

Learn the necessary concepts of operation and safety relating to the vehicle prior to working on it. Scrupulously observe all safety warnings on the assembly.

Do not leave the assembly in motion unattended during repair work.

When working on an assembly off the ground, make sure that it is resting firmly on the appropriate supporting stands and that the manual/automatic safety devices are activated in the event of lifting with a hydraulic ramp.

When working on assemblies fuelled with natural gas, in addition to the instructions given in the document, also observe all the specific safety regulations provided.

Only remove radiator cap when the engine is cold by cautiously unscrewing it in order to let system residual pressure out.

Flammable fuels and all fluids and liquids must be handled with care, according to the indications provided in the 12 point cards of harmful materials. Refuelling must be performed outdoors with the engine off, avoiding lit cigarettes, free flames or sparks, in order to prevent sudden fires/explosions. Adequately store inflammable, corrosive and polluting fluids and liquids according to what provided by regulations in force. Strictly avoid using containers for food to store harmful liquids. Avoid drilling or burning pressurised containers and discard cloths impregnated with inflammable substances into suitable containers.

Worn out, damaged or consumable parts must be replaced with original spare parts.

During workshop activities, always keep the workplace clean; promptly free or clean floors of any accidental spills and stains of liquids and oils. Electric sockets and electrical equipment necessary to perform repair operations must meet safety rules.



Wear all required P.P.E and garments when called for by the operation at issue. Contact with moving parts may cause serious injuries. Use suitable, preferably tight-fitting garments and avoid wearing jewellery, scarves, etc.

Do not leave the engine running in workshops not equipped with a pipe to extract exhaust fumes outside.

Do not breathe fumes from heating or welding of paint, as they are harmful; operate outdoors or in well-ventilated areas. Wear an appropriate respirator in the presence of paint dust.

Avoid contact with hot water or steam from the engine, radiator and hoses as they could cause serious burns. Avoid direct contact with liquids and fluids inside vehicle systems; consult the 12 remedy points sheet if accidental contact occurs.



Before overhauling, clean the assemblies and make sure they are integral and complete. Tidy up detached or disassembled parts with their securing elements (screws, nuts, etc.) into special containers.

Check the integrity of the parts that prevent the loosening of screws: split washers, split pins, clips, etc. Self-locking nuts with nylon inserts must always be replaced.

Avoid contact of rubber with diesel fuel, petrol or other incompatible substances.

Before pressure washing mechanical parts, protect electrical connectors and any control units.

The tightening of screws and nuts should always be carried out according to directions. FPT's sales and assistance network is available to provide any clarifications necessary to carry out any repair work not covered by this document.

Before welding:

- Disconnect all electronic control units and unplug the power cable from the battery's positive terminal (connecting it to the chassis ground) and connectors.
- Remove paint by using proper solvents or paint removers and clean relevant surfaces with soap and water.
- Wait approximately 15 minutes before proceeding with welding.
- Use suitable fire-resistant protections to protect hoses or other components in which fluids or other flammable materials flow when welding.

Should the vehicle be subjected to temperatures exceeding 80°C (dryer ovens), remove the electronic control units.



The disposal of all liquids and fluids should be carried out in strict compliance with specific regulations in force.

GENERAL WARNINGS REGARDING THE ELECTRICAL SYSTEM



When having to operate on the electrical/electronic circuit, disconnect the batteries from the circuit, disconnecting the chassis earth cable first of all from the negative terminal of the battery.

Before connecting the batteries to the system make sure the latter is well insulated.

Disconnect the external recharging apparatus from the public utility network before removing the apparatus pins from the battery terminals.

Do not cause sparks to verify the presence of voltage in a circuit.

Do not use a test bulb to check the continuity of a circuit. Only use the appropriate testing devices.

Make sure that the wirings of electronic devices (length, type of cable, location, strapping, connection of screen braiding, grounding, etc.) conform with the FPT system and that they are carefully restored after repair or maintenance work.

Measurements on the ECUs, jack connections and electrical connections of components must be done only on regular test lines, with special jacks and jack bushings. Never use improvised equipment like metal wires, screwdrivers, pins or similar. This may not only cause short circuits, but also damage the jack connectors, resulting in poor contact.



Do not use fast chargers to start up the engine. Start up must only be performed with either separate batteries or special truck.

Incorrect polarisation of the power supply voltage for the electronic control units (e.g. erroneous battery polarisation) may damage the components irreversibly.

Disconnect the batteries from the system before recharging them by means of an external unit.

On connecting, only screw connector (temperature sensors, pressure sensors, etc.) nuts to the prescribed tightening torque.

Isolate the circuit prior to disconnecting the junction connector from an electronic control unit.

Do not directly supply current to components served by electronic control units with rated vehicle voltage.

The cables must be routed in such a way as to be parallel to the reference plane, as close as possible to the chassis/body.

Upon completing work on the electrical circuit, restore the electrical connectors and wiring as originally provided.

NOTE The connectors are shown from cable side. Connector views contained in the manual are representative of cable side.


Grounding and screening

The negative conductors connected to circuit ground point must be as short as possible and connected in "star" form, ensuring that their tightening is done neatly and sufficiently (Figure 1 ref. M).

The following precautions must be observed regarding the electronic components:


- electronic control units must be connected to the system ground when equipped with metal housings.
- The negative cables of the electronic control units must be connected at a circuit ground point, such as dashboard compartment ground (avoiding "serial" or "chain" connections), as well as to the negative terminal of the battery or batteries.
- Even if not connected to the circuit ground/battery negative terminal, analogue ground (sensors) should have optimal insulation. Consequently, particular care should be given to terminal parasitic resistances: oxidation, clinching defects, etc.
- The metal braid of shielded circuits must be in contact only at the ECU side to which the signal is to be sent (Figure 2).
- In the case of junction connectors, the unshielded section (**d**) near to the latter must be as short as possible (Figure 2).
- The cables must be routed in such a way as to be parallel to the reference plane, as close as possible to the chassis/body.

Figure 1



1. "STAR" CONNECTIONS OF NEGATIVE CABLES TO THE CIRCUIT GROUND M

Figure 2



2. SHIELDING BY METAL BRAID OF A CABLE TO AN ELECTRONIC COMPONENT - C. CONNECTOR
d. DISTANCE → 0

88039

CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND THE MOST COMMONLY USED DERIVED SIZES**Power**

1 kW	=	1.36 HP
1 kW	=	1.34 hp
1 HP	=	0.735 kW
1 HP	=	0.986 hp
1 hp	=	0.746 kW
1 hp	=	1,014 HP

NOTA The unit HP is converted into hp for simplicity according to a 1:1 ratio

$$1 \text{ hp} = 1 \text{ CV.}$$

Torque

1 Nm	=	0.1019 kgm
1 kgm	=	9.81 Nm

Revolutions per time unit

1 rpm	=	0.1047 rad/s
1 rad/s	=	9.55 rpm

Pressure

1 bar	=	1.02 kg/cm ²
1 kg/cm ²	=	0.981 bar
1 bar	=	10 ⁵ Pa

NOTA Where accuracy is not particularly required:

- the unit Nm is converted into kgm for simplicity according to a ratio of 10:1
1 kgm = 10 Nm;
- the unit bar is converted into kg/cm² for simplicity according to a ratio of 1:1
1 kg/cm² = 1 bar.

Temperature

0° C	=	273.15 K
0° F	=	255.37 K
0° C	=	32° F (the conversion factor between Celsius and Fahrenheit is 1:1.8)

PAGE HEADER AND FOOTER INTERPRETATION

Type of engine	Section title	Page number
----------------	---------------	-------------

MOTORI NEF F4HE

SEZIONE 4 - REVISIONE MECCANICA GENERALE 11


REVISIONE MOTORE 4 E 6 CIL. SMONTAGGIO DEL MOTORE AL BANCO

La trattazione seguente prevede che il motore sia stato montato sul cavalletto rotativo e si sia proceduto alla rimozione di tutti i componenti specifici dell'applicazione Iveco Motors (vedere la Sezione 3 del presente manuale).

La sezione riguarda quindi tutte le più importanti procedure di revisione del basamento motore.

Le operazioni seguenti riguardano il motore 4 cilindri, ma risultano analoghe per il 6 cilindri.


Figura 1



SVITARE LE VITI DI FISSAGGIO (1) E RIMUOVERE I CAPPELLI DI BIELLA (2). Sfilare gli stantuffi completi di bielle dalla parte superiore del basamento.


NOTA Mantenere i semicuscinetti nei rispettivi alloggiamenti, poiché, in caso di un loro utilizzo, dovranno essere montati nella posizione riscontrata allo smontaggio.

Figura 2



Rimuovere le viti (1) e smontare i cappelli di banco (2).

Figura 3




Il penultimo cappello di banco (1) e il relativo supporto (2) hanno il semicuscinetto (2) dotato di spallamento.

NOTA Le viti M12 dei cappelli di banco, devono essere sostituite se il diametro nominale della parte filettata che non lavora, presenta un diametro < 0,1 mm rispetto al valore nominale.


NOTA Annotare la posizione di montaggio dei semicuscinetti inferiori e superiori, poiché in caso di un loro utilizzo, dovranno essere montati nella posizione riscontrata allo smontaggio.

Figura 4



Con l'attrezzo 99360500 (1) e sollevatore rimuovere l'albero motore (2) dal basamento.

Figura 5



Smontare i semicuscinetti di banco (1). Rimuovere le viti (2) e smontare gli spruzzatori olio (3).

Print P2D32N003

Base - Dicembre 2006
Revi - Febbraio 2007

Number of printed copies	Language of Publication
--------------------------	-------------------------

Basic edition referring to closing phase of drafting month-year	When present, a month-year update (Revi) to the basic edition
---	---

CURSOR SERIES

Section


General information	I
Operating diagrams	2
Electrical equipment	3
Scheduled Maintenance	4
Removal - Refitting of the main engine components	5
General mechanical overhaul	6
Technical specifications	7
Tools	8
Standard safety precautions	Appendix

SECTION I**General information**

	Page
IDENTIFICATION DATA	3
CORRESPONDENCE BETWEEN TECHNICAL CODES AND COMMERCIAL CODES	4
PRODUCT TECHNICAL CODE	5
VPRODUCT COMMERCIAL CODE	6
ENGINE VIEWS	7
ENGINE CHARACTERISTICS	10

IDENTIFICATION DATA
F3HFA615A*D001 - F3HFA615B*D001


Figure 1



225053

A. Serial number - B. Month and year construction date - C. Engine type - D. Engine family name - E. FPT Engine P/N
 I. Bar code
 (The Bar code contains: Serial number, Manufacturing date, FPT Engine P/N)

Figure 2



227744

I. Label position on "gear train cover" - 2. Label position on "cover cylinder head"

CORRESPONDENCE BETWEEN TECHNICAL CODES AND COMMERCIAL CODES

Technical codes	Commercial Codes
F3HFA6I5A*D00I	CRI3 TE 7W
F3HFA6I5B*D00I	CRI3 TE 6W

PRODUCT TECHNICAL CODE

The technical code is assigned during production; it is used to identify the main characteristics, characterise the application and the corresponding level of power output. It is stamped on one side of the crankcase near the oil filter.

F	3	H	F	A	6	I	5	A	*	D	0	0	I
F	3	H	F	A	6	I	5	B	*	D	0	0	I

VARIANTS OF THE BASIC ENGINE

TYPE-APPROVAL FOR STANDARDS

TYPE-APPROVAL FOR PERFORMANCE

APPLICATION

MAIN ENGINE SPECIFICATIONS

NUMBER OF CYLINDERS

CYLINDER CONFIGURATION

ENGINE

PROJECT EVOLUTION

ENGINE FAMILY IDENTIFICATION

PRODUCT COMMERCIAL CODE

The commercial name has the aim of making the information on the engine characteristics more easily identifiable, bringing together engines of different families, origin and applications for which they are to be used.

The commercial acronym is not used for any technical purpose to recognise the parts which make up the engine.

CR I3 T E 6 W

CR I3 T E 7 W

CONTROL UNIT TYPE: W = EDC17 hp 41

POWER LEVEL

INJECTION: E= ELECTRONIC


INTAKE: T = TURBOCHARGED WITH INTERCOOLER

DISPLACEMENT: I3 = 13,000 c.c. NOMINAL

ENGINE FAMILY IDENTIFICATION: CR= CURSOR

ENGINE VIEWS

Figure 3




227835

LEFT SIDE VIEW

1. Pipe for intake of external air to turbocharger - 2. Turbocharger oil outlet pipe - 3. Refitting water inlet pipe to crankcase - 5. Radiator support bracket - 6. Radiator grille - 7. Radiator - 8. Hot compressed air pipe from turbocharger to radiator - 9. Turbocharger - 10. Turbocharger exhaust gas outlet

Figure 4




227836

LATERAL VIEW, INTAKE SIDE

1. Alternator protective grille - 2. Radiator support bracket - 3. Oil sump drain plug - 4. Engine cold air inlet pipe - 5. Fuel filter - 6. Electric starter motor - 7. Engine air filter clogged - 8. Air filter support - 9. Fuel pump - 10. Intake manifold - 11. Engine management control unit - 12. Water outlet pipe from h


Figure 5



227837

1. Engine cold air inlet pipe - 2. Electric fan - 3. Water outlet pipe from head - 4. Hot compressed air pipe from turbocharger to radiator - 5. Turbocharger - 6. Pipe for intake of external air to turbocharger - 7. Refitting water inlet pipe to crankcase


Figure 6



227834

1. Oil sump drain plug - 2. Engine flywheel - 3. Oil filter - 4. Air filter - 5. Engine cold air inlet pipe

Figure 7




227833

TOP VIEW

1. Radiator grille - 2. Radiator anchor - 3. Intake manifold - 4. Lubricant oil filling plug -
 5. Fuel pump - 6. Blow-By cover - 7. Air filter - 8. Pipe for intake of external air to turbocharger -
 9. Turbocharger - 10. Hot compressed air outlet pipe from turbocharger to radiator - 11. Radiator -
 12. Water outlet pipe from head

Figure 8



227832

ISOMETRIC VIEW

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com