
SECTION 00 - GENERAL INFORMATION

BOOK 1

Chapter 1 - General Information

CONTENTS

Section	Description	Page
00 000	Introduction	00-2
	Safety	00-3
	Technical Information	00-4
	Safety Precautions	00-5
	Safety Decals - TC35, 40, 45	00-8
	Instruction Decals - TC35, 40, 45	00-9
	Safety Decals - TC35D, 40D, 45D	00-12
	Instruction Decals - TC35D, 40D, 45D	00-13
	International Symbols	00-17
	Specifications - TC35, 40, 45	00-18
	General Dimensions - TC35, 40, 45	00-25
	Specifications - TC35D, 40D, 45D	00-31
	General Dimensions - TC35D, 40D, 45D	00-37
	Minimum Hardware Tightening Torques	00-41
	Special Tools	00-43
	Lubricants	00-44
00 400	Recommended Lubricants	00-44
	Adjustments	00-45
	Tire Inflation Pressure - Adjustments	00-45
00 100	Pre-Season and Pre-Delivery Checklist	00-46

SECTION 10 - ENGINE

BOOK 1

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	10-3
	Metric Bolt Torque Specifications	10-12
	Special Tools	10-13
	General Information	10-15
	Description of Operation	10-15
	Troubleshooting	10-16
10 101	Cylinder Head Removal	10-53
10 106	Timing Gears and Camshaft Removal	10-57
10 102	Oil Sump Removal	10-58
10 110	Balancer Assembly-Removal	10-59
10 105	Connecting Rods, Bearings, and Pistons, Rings Removal	10-59
10 103	Flywheel	10-60
	Disassembly, Inspection, Fits, Clearances, and Assembly of Component Assemblies	10-61
10 101	Cylinder Head Disassembly	10-61
10 105	Pistons, Piston Rings, and Connecting Rods Disassembly and Inspection	10-67
10 103	Crankshaft	10-72
10 106	Timing Gear	10-76
10 103	Flywheel	10-77
10 102	Timing Gear Housing	10-78
	Engine Reassembly	10-79
10 103	Crankshaft and Bearing Holder Reassembly	10-79
10 105	Pistons and Connecting Rods	10-80
10 110	Balancer Assembly-Installation	10-81
10 106	Timing Gear Cover, Timing Gears, and Camshaft Assembly	10-82
10 106	Idle Gear, Oil Pump, and Injection Timing	10-83
10 101	Head Gasket Selection	10-86
10 106	Valve Clearance Adjustment	10-87
10 218	Fuel Piping	10-89
	Engine Lubrication System	10-91
10 304	Engine Lubrication System - Description of Operation	10-91
10 218	Fuel Piping	10-91
10 206	Oil Filter	10-95

10 304	Oil Pump	10-95
	Cooling System	10-99
10 400	Cooling System - Description of Operation	10-99
10 402	Thermostat	10-102
10 402	Water Pump	10-102
10 414	Cooling Fan	10-102
	Cooling System Overhaul	10-103
10 406	Radiator	10-103
10 402	Water Pump Removal	10-105
10 402	Thermostat Removal	10-108

SECTION 10 - ENGINE

BOOK 1

Chapter 2 - Fuel Systems

CONTENT

Section	Description	Page
	Specifications	10-112
	Torque Specifications	10-113
	Special Tools	10-113
10 242	Description of Operation	10-114
	Troubleshooting	10-116
10 244	Fuel Variation Mechanism	10-121
10 244	CTD (Compact Timing Device)	10-122
10 236	Pumping Elements	10-124
10 214	Delivery Valves	10-126
10 242	Injection Pump Removal	10-128
10 230	Timing and Governor Adjustments	10-131
	Spill-Timing Procedure	10-132
	Auto Bleed	10-137
	Bleeding to Fuel System	10-138
	Fuel Scre/High Idle Adjustment	10-138
10 230	Governor Operation	10-139
10 218	Injectors	10-145

SECTION 18 - CLUTCH

BOOK 1

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
18 000	Specifications	18-2
	Bolt Torque Specifications	18-3
	Special Tools	18-3
	Description of Operation	18-4
	Troubleshooting	18-6
	Overhaul	18-7
18 110	Clutch Removal	18-13
18 110	Clutch Installation	18-14
18 110	Clutch Related Components	18-21
	Clutch Linkage Components	18-24
18 100	Clutch Cross Shaft Bushings	18-24
	Clutch Pedal Adjustments	18-27
	Clutch Pedal Maximum Travel Adjustment	18-27

SECTION 21 - TRANSMISSION

BOOK 1

Chapter 1 - 12 x 12 Synchronized Shuttle Shift Gear Transmission

CONTENT

Section	Description	Page
	Specifications	21-2
	Metric Bolt Torque Specifications	21-3
	Special Tools	21-4
21 000	Description of Operation	21-5
	Powerflow	21-8
	Troubleshooting	21-12
	Overhaul	21-13
21 110 10	Overhaul - Removal	21-13
21 114	Separating at the Clutch Housing/Engine	21-13
	Clutch Housing Disassembly	21-19
21 148 63	Retainer Cover	21-23
21 148 63	Main Shift Rails and Shift Forks	21-24
21 148 63	Main Shaft	21-27
21 148 63	Range Shift Rail and Shift Fork	21-30
21 148 63	Range Gear Countershaft	21-31
21 148 63	Input Shaft	21-32
21 148 63	Reverse Idler Shaft	21-33
21 148 63	Shuttle Shift Rail and Fork	21-35
21 148 63	Main Countershaft	21-36
21 148 63	Synchronizers	21-38
21 148 63	Input Shaft	21-45
21 148 63	Main Countershaft End Float	21-46
21 148 63	Range Gear Countershaft	21-46
21 148 63	Range Shift Rail and Fork	21-47
21 148 63	Main Shaft	21-48
21 148 63	Main Shaft End Float	21-51
21 110 10	Clutch Housing	21-56
21 130	Transmission Shift Levers	21-67

SECTION 23 - DRIVELINE

BOOK 1

Chapter 1 - Driveline

CONTENTS

Section	Description	Page
23 000	Bolt Torque Specifications	23-2
	Special Tools	23-3
	Description of Operation	23-4
	Front Wheel Drive Take Off Gearbox	23-4
	Sensitrack	23-5
	Troubleshooting	23-9
	Lubrication	23-9
	Overhaul	23-10
	Front Wheel Drive Take Off Gearbox	23-10
23 260	Sensitrack Removal	23-14
23 260	Sensitrack Installation	23-31

SECTION 25 - 4WD FRONT AXLE, SUPERSTEER™ AND SENSITRACK™

BOOK 2

Chapter 1 - 4WD Front Axle, Supersteer™ and Sensitrack™

CONTENTS

Section	Description	Page
	Specifications	25-3
	Bolt Torque Specifications	25-6
	Special Tools	25-6
25 000	Description of Operation	25-7
	4WD Front Axle	25-7
	Troubleshooting	25-8
	Lubrication	25-10
	Overhaul	25-11
25 108	Disassembly	25-12
25 102	Front Axle and Differential	25-15
	Drive Pinion Disassembly	25-16
	Drive Pinion Inspection	25-17
	Drive Pinion Assembly	25-18
	Differential Gear Assembly	25-18
	Axle and Differential Assembly	25-19
	Differential Case Bearing Preload Check and Adjustment	25-20
	Ring Gear-to-Pinion Backlash Check and Adjustment	25-20
25 108	Gear Reduction Box Assembly	25-23
	Ring Gear-to-Pinion Backlash Check and Adjustment	25-25
	Bevel Gear-to-Pinion Backlash Check	25-26
25 100	Supersteer™	25-27
	Supersteer™ Front Axle	25-30
	Overhaul	25-33
25 100	Supersteer™ Axle Removal	25-35
	Gear Reduction-Drop Box Disassembly	25-40
25 102	Front Axle and Differential Disassembly	25-42
	Drive Pinion Disassembly	25-43
	Inspection	25-44
	Drive Pinion Assembly	25-45
	Differential Gear Assembly	25-45
25 102	Axle and Differential Assembly	25-46

	Differential Case Bearing Preload Check and Adjustment	25-47
	Ring Gear-to-Pinion Backlash Check and Adjustment	25-47
25 108	Gear Reduction Box Assembly	25-50
	Bevel Gear-to-Pinion Backlash Check	25-52
	Supersteer™ Axle Installation	25-53

SECTION 27 - DIFFERENTIAL, REAR AXLE

BOOK 2

Chapter 1 - Differential, Rear Axle

CONTENTS

Section	Description	Page
27 000	Specifications	27-2
	Bolt Torque Specifications	27-3
	Special Tools	27-3
	Description of Operation	27-4
27 110	Differential	27-5
27 110	Differential Lock	27-5
27 126	Rear Axle	27-6
27 106	Differential Overhaul	27-7
27 126	Rear Axle Overhaul	27-16
27 126	Final Pinion Overhaul	27-25

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2

Chapter 1 - Hydrostatic Transmission

CONTENT

Section	Description	Page
	Specifications	29-2
	Metric Bolt Torque Specifications	29-4
	Special Tools	29-4
29 202	Description of Operation	29-5
29 212	Variable Displacement Pump Operation	29-11
29 212	Two Position Displacement Motor Operation	29-12
29 134	Hi/Lo Speed Control/Control Pod	29-13
29 200	Foot Control Pedals	29-13
	Troubleshooting	29-16
	Pressure Testing and Adjustments	29-19
	Separating the Tractor	29-23
	TC35D, TC40D, and TC45D w/HST Transmission	29-23
29 202	Hydrostatic Transmission Disassembly	29-44
29 130	Port Block Removal	29-47
29 218	Cylinder Block Assembly for Pump	29-50
29 218	Cylinder Block Assembly for Motor	29-51
29 130	Port Block Assembly	29-52
29 204	Check Valve	29-54
29 300	Hydrostatic Transmission Gearbox	29-55
	Gearbox Identification	29-56
29 214	Hi/Lo Solenoid Valve Assembly	29-68
	Cruise Control	29-76
	Electromagnet Air Gap Adjustment	29-77
29 200	HST Foot Control Pedals Neutral Adjustment	29-78

SECTION 31 - POWER TAKE-OFF (PTO) SYSTEMS

BOOK 2

Chapter 1 - Power Take-Off (PTO) Systems

CONTENT

Section	Description	Page
	Specifications	31-2
	Metric Bolt Torque Specifications	31-3
	Special Tools	31-4
31 000	Description of Operation	31-5
31 110	Rear PTO-Power Flow Diagram - 12x12 Synchronized Shuttle Shift Transmission ...	31-6
31 110	Rear PTO-Power Flow Diagram - Hydrostatic Transmission (HST)	31-7
31 120	Mid PTO-Power Flow Diagram - Tractors Equipped with a Mid PTO Kit	31-8
31 104	Hydraulic Fluid Flow to the PTO Clutch Assembly	31-9
	Troubleshooting	31-12
	Pressure Testing	31-13
31 104 82	Overhaul	31-15
31 104 82	PTO Clutch Control Valve	31-18
31 114 62	PTO Clutch Assembly	31-23
31 114 68	PTO Clutch Disassembly	31-26
31 114 62	PTO Clutch Installation	31-34
31 114 42	PTO System Overhaul - 12x12 Synchronized Shuttle Shift Transmission	31-38
31 114 46	PTO Countershaft and Rear PTO Shaft	31-40
31 114 46	Countershaft Disassembly	31-42
31 114 00	PTO System Overhaul - Hydrostatic Transmission (HST) - Removal	31-47
31 114 42	PTO Input Shaft	31-47
31 114 46	PTO Countershaft and Rear PTO Shaft	31-49
31 114 42	PTO Countershaft and Rear PTO Shaft - Disassembly	31-53
31 114 19	PTO Countershaft and Rear PTO Shaft - Installation	31-57
31 120 00	Mid PTO Countershaft and Drop Box Overhaul	31-60

SECTION 33 - BRAKES

BOOK 2

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
33 000	Specifications	33-2
	Bolt Torque Specifications	33-3
	Description of Operation	33-4
33 120	Brakes	33-4
31 120	Brake Operation	33-5
33 110	Parking Brake	33-6
33 120	Overhaul	33-7
	Brake Adjustment	33-12

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2

Chapter 1 - Hydraulic System

CONTENT

Section	Description	Page
	Specifications	35-2
	Metric Bolt Torque Specifications	35-3
	Special Tools	35-4
35 100	Description of Operation	35-5
35 180	Combination System Relief - Diverter Valve Manifold Assembly	35-8
35 200	Control Valve Assembly (HPL)	35-9
35 210	Neutral Position - Fluid Flow	35-10
35 210	Raising Position - Fluid Flow	35-11
35 210	Lowering Position - Fluid Flow	35-12
35 200	Bypass Spool - Fluid Flow - Closed Position	35-13
35 200	Bypass Spool - Fluid Flow - Open Position	35-13
35 183	Flow Control Valve	35-14
35 108	Linkage Operation - Single Lever - Position Control	35-14
35 108	Position Control Operation - Neutral Position to Raise	35-15
35 112	Linkage Operation - Dual Lever Position Control (Draft Control)	35-16
35 124	Linkage Operation - Combining Position and Draft Control Settings	35-18
	Troubleshooting	35-19
	Pressure Testing	35-21
35 110	Hydraulic System Overhaul	35-23
35 200	Hydraulic Control Valve	35-34
35 180	Combination System Relief and Diverter Valve Assembly	35-38
35 182	PTO System Diverter Valve	35-41
35 124	Adjustments	35-44
35 304	Hydraulic Pump and Filter	35-45
35 304	Hydraulic Pump	35-46
35 300	Sump Tube and Screen Filter	35-52
35 204	Remote Valves	35-55
35 184	Front (Double-Spool) Remote Control System	35-61
35 184	Fluid Flow - Bucket Control - Dumping and Lift Control - Neutral	35-62
35 184	Fluid Flow - Bucket Control - Dumping Regen and Lift Control - Neutral	35-63
35 184	Fluid Flow - Bucket Control - Roll Back and Lift Control - Neutral	35-64
35 184	Fluid Flow - Bucket Control - Neutral and Lift Control - Raising	35-65
35 184	Fluid Flow - Bucket Control - Neutral and Lift Control - Lowering	35-66
35 184	Fluid Flow - Bucket Control - Neutral and Lift Control - Float	35-67
35 204	Overhaul	35-68
35 184	Front (Double Spool) Remote Control Valve	35-70

SECTION 41 - STEERING

BOOK 3

Chapter 1 - Steering

CONTENTS

Section	Description	Page
41 000	Specifications	41-2
	Bolt Torque Specifications	41-3
	Special Tools	41-4
	Description of Operation - Supersteer	41-5
	Description of Operation - Power Steering	41-7
41 204	Power Steering Control Motor	41-9
41 206	Power Steering Pump	41-10
41 216	Steering Cylinders	41-10
41 216	Power Steering Cylinders - 2WD and Standard 4WD	41-11
41 206	Power Steering Operation - Supersteer	41-12
41 200	Fluid Flow - Left Turn	41-13
41 200	Fluid Flow - Right Turn	41-14
41 200	Manual Operation	41-15
41 200	Power Steering Operation - 2WD and Standard 4WD	41-16
41 200	Fluid Flow - Left Turn	41-17
41 200	Fluid Flow - Right Turn	41-18
41 200	Manual Operation	41-19
	Troubleshooting	41-20
	Pressure Testing	41-22
	Lubrication	41-24
	Overhaul	41-25
41 204	Steering Control Motor Removal	41-25
41 204	Steering Control Motor	41-41
41 216	Steering Cylinder Removal - 4WD and Supersteer	41-42
41 216	Steering Cylinder Removal - 2WD	41-43
41 216	Steering Cylinder Installation - 4WD and Supersteer	41-52
41 216	Steering Cylinder Installation - 2WD	41-54
41 206	Power Steering Pump and Reservoir Tank	41-56
41 206	Pump Installation	41-58
	Steering Tubes	41-59

SECTION 44 - 2WD FRONT AXLE

BOOK 3

Chapter 1 - 2WD Front Axle

CONTENTS

Section	Description	Page
44 000	Specifications	44-2
	Bolt Torque Specifications	44-2
44 101	Description of Operation	44-3
	Troubleshooting	44-4
	Overhaul	44-5
44 103	Installation	44-12

SECTION 55 - ELECTRICAL

BOOK 3

Chapter 1 - Electrical

CONTENTS

Section	Description	Page
	Bolt Torque Specifications	55-3
	Introduction	55-4
55 100	Description	55-4
	Component Location and Function	55-4
55 100	Wire Harnesses	55-6
	Electrical System Components - Description and Testing	55-7
	Battery	55-7
	Main Fuse	55-9
	Fuse Block	55-10
	Key Switch	55-11
	Light Switch	55-13
55 404	Headlight	55-18

55 404	Taillight	55-19
	Rear Work Light (optional)	55-19
	Hazard Light Switch	55-20
	Hazard Light Switch Testing	55-21
55 408	Transmission Range Safety Switch	55-23
	Transmission Range Safety Switch Testing	55-24
55 408	Rear (Main) PTO Safety Switch	55-25
	Rear (Main) PTO Safety Switch Testing	55-25
55 408	Mid PTO Safety Switch	55-26
55 408	Seat Safety Switch	55-27
55 408	Parking Brake Safety Switch	55-29
	Relays	55-30
	Headlight and Neutral Start Relays	55-33
	Diodes	55-36
	Operator Safety Module	55-38
	Glow Plug Timer	55-40
55 201	Engine Glow Plugs	55-41
	NASO Hazard/Directional Signal Converter and Flasher Relay	55-44
55 410	Fuel Level Sending Unit	55-47
	Fuel Shutoff Solenoid	55-50
55 414	Engine Oil Pressure Switch	55-52
	Engine Coolant Temperature Switch (Economy)	55-53
	Engine Coolant Temperature Sending Unit (Deluxe)	55-53
	Hi/Low Transmission Range Switch	55-55
	Hi/Low Transmission Range Solenoid	55-58
	Electric Cruise Control Switch (Deluxe)	55-61
	Cruise Control Magnet (Deluxe)	55-63
	Cruise Control Brake Release Switch	55-65
	Instrument Panel - Component Operation and Servicing	55-67
	Instrument Panel (Economy)	55-68
	Instrument Panel (Deluxe)	55-69
	Instrument Panel Removal	55-70
	Instrument Panel Disassembly	55-70
	Fuel Gauge Removal	55-70
	Fuel Gauge Testing	55-70
	Temperature Gauge Removal (Deluxe)	55-72
	Temperature Gauge Testing	55-72
	Tachometer Removal	55-73
	Tachometer Testing	55-74

	PTO Speed Indicator Adjustment (Deluxe)	55-74
	Instrument Lights	55-75
	Circuit Diagrams and Troubleshooting	55-77
	Alternator Specifications	55-170
	Alternator Troubleshooting	55-171
	Charging System	55-173
55 301	Description of Operation	55-173
	Preliminary Alternator Tests	55-176
	Alternator Component Testing and Inspection	55-182
	Starter Motor Specifications	55-192
	Starter Motor Troubleshooting	55-193
55 201	Starting System	55-195
	Description of Operation	55-195
	Components	55-195
	Electrical Testing	55-205

SECTION 90 - PLATFORM

BOOK 3

Chapter 1 - Platform

CONTENTS

Section	Description	Page
90 105	Hood	90-2
90 100	Rear Hood Side Panels	90-4
90 110	Dash Console	90-6
90 120	Seat	90-11
90 114	ROPS	90-30
	Fuel Tank	90-34
90 116	Fenders	90-36
90 115	Deck	90-40

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com