

CLAAS



SCORPION

9040 (404-03)
7045 (403-03)
7040 (402-03)
7030 (401-03)
6030 (400-01)

Repair Manual

SERVICE & PARTS

Table of Contents

1 Machine, applications, operation (overview)

1.1	Machine outside view	1-2
1.2	Inside of cab (overview)	1-3
1.3	Instrument panel, multifunctional lever, switch consoles (overview)	1-4
1.4	Fields of application and using a telehandler with an attachment	1-5
1.5	Legal regulations regarding telehandler operation	1-8
1.6	Type labels and component numbers	1-11

2 Specifications

2.1	Model and trade names (overview)	2-2
2.2	Frame	2-2
2.3	Engine	2-2
2.4	Oil/water fan	2-3
2.5	Drive	2-3
2.6	Axles	2-4
2.7	Service and parking brake	2-4
2.8	Steering system	2-5
2.9	Work hydraulics	2-6
2.10	Electrical system	2-8
2.11	Tyres for models 401-03/402-03/403-03	2-12
2.12	Tyres for model 404-03	2-12
2.13	Machine weights, axle loads	2-13
2.14	Noise levels	2-13
2.15	Vibrations, oscillation and acceleration value	2-14
2.16	Coolant compound table	2-14
2.17	Tightening torques	2-15
2.18	Trailer couplings: trailer weight/drawbar load	2-15
2.19	Pallet forks model 400-01	2-16
2.20	Load on pallet forks model 401-03 (without counterweight)	2-17
2.21	Load on pallet forks model 401-03 (with counterweight 2 x 150 kg)	2-18
2.22	Pallet forks model 402-03 (with counterweight 2 x 150 kg)	2-19
2.23	Pallet forks model 402-03 (with counterweight 2 x 300 kg)	2-20
2.24	Load on pallet forks model 403-03	2-21
2.25	Payloads model 404-03	2-22
2.26	Dimensions with bucket	2-26
2.27	Dimensions with bucket	2-27
2.28	Dimensions with pallet forks	2-28
2.29	Dimensions with pallet forks	2-29

3 Maintenance and servicing work

3.1	Explanation of symbols on the maintenance label	3-2
3.2	Maintenance label	3-3
3.3	Fluids and lubricants (overview)	3-4
3.4	Maintenance plan	3-5
3.5	Introduction	3-9
3.6	Safety prop for telescopic boom	3-9
3.7	Fuel system	3-10
3.8	Maintenance of engine lubrication system	3-14
3.9	Maintenance of the engine and hydraulics cooling system	3-18
3.10	Cleaning the radiator with the reversing fan (option)	3-23
3.11	Air filter maintenance	3-24
3.12	Maintenance: V-belts	3-26
3.13	Gearbox and axle maintenance	3-27

3.14	Safety instructions regarding the hydraulic system	3-32
3.15	Monitoring the hydraulic oil and the return filter	3-33
3.16	Checking the hydraulic oil level	3-33
3.17	Filling up hydraulic oil	3-34
3.18	Replacing the return filter of the hydraulic system	3-34
3.19	Replacing the microfilter of the hydraulic system	3-34
3.20	Replacing the microfilter in the LS line	3-35
3.21	Replacing hydraulic oil	3-36
3.22	Important notices on the use of biodegradable oil	3-37
3.23	Checking hydraulic pressure lines	3-38
3.24	Lubrication work	3-39
3.25	Maintenance of the brake system	3-42
3.26	Replacing/bleeding the service brake fluid with bleed equipment	3-43
3.27	Maintenance of compressed-air brake system (option)	3-46
3.28	Tyre maintenance	3-47
3.29	Heating and ventilation maintenance	3-49
3.30	Maintenance of air conditioning (option)	3-50
3.31	Maintenance of the electrical system	3-55
3.32	Maintenance of trailer coupling	3-59
3.33	General maintenance work on the machine	3-60
3.34	Cleaning inside the cab	3-61
3.35	Cleaning the seat belt	3-61
3.36	Cleaning the exterior of the machine	3-61
3.37	Checking screw connections	3-61
3.38	Checking pivots and hinges	3-61
3.39	Cleaning the engine compartment	3-62
3.40	Maintenance and servicing work "Aggressive Media"	3-63
3.41	Maintenance and servicing of attachments on the quickhitch	3-65

4 Engine

4.1	Electrical system/hydraulics – fan (electrical diagram)	4-2
4.2	Fan (functional description)	4-6
4.3	Fan connector assignment for models 402, 403, 404	4-7
4.4	Diesel engine connector assignment (88 kW)	4-8
4.5	Diesel engine connector assignment (103 kW)	4-9
4.6	Fuel preheater connector assignment	4-10
4.7	Diagnosis connector assignment	4-11
4.8	88 kW diesel engine electrical system (electrical diagram)	4-14
4.9	103 kW diesel engine electrical system (electrical diagram)	4-18
4.10	Fuel preheater (electrical diagram)	4-22
4.11	Engine diagnosis (electrical diagram)	4-24
4.12	Engine oil cooler side (88 kW) (overview)	4-25
4.13	Engine drive side (88 kW) (overview)	4-26
4.14	Engine turbocharger side (88 kW) (overview)	4-27
4.15	Engine oil cooler side (103 kW) (overview)	4-28
4.16	Fuel: high-pressure unit	4-29
4.17	Engine drive side (103 kW) (overview)	4-30
4.18	Engine turbocharger side (103 kW) (overview)	4-31
4.19	Electronics overview (103 kW)	4-32
4.20	Electronic engine speed setting (103 kW) (overview)	4-35
4.21	Function: warning indicator light in tip switch (103 kW diesel engine)	4-36
4.22	Engine drive – clutch (88/103 kW) (overview)	4-41
4.23	Installing the fan pump	4-42
4.24	Fuel system (88/103 kW) (overview)	4-43
4.25	Bleeding the fuel system (88/103 kW)	4-44
4.26	Fan circuit (not in reversing operation)	4-45
4.27	Fan circuit with reversing fan	4-46

4.28	Reversing valve block	4-47
4.29	Setting maximum fan speed (reversing fan)	4-48
4.30	Setting maximum fan speed (without reversing fan)	4-48
4.31	Cleaning the radiator with the reversing fan (option)	4-49
4.32	Function: reversing fan operation	4-50

5 Power train

5.1	40 kph drive hydraulic diagram for models 400, 401, 402	5-2
5.1	30 – 40 kph drive hydraulic diagram for models 402, 403, 404	5-4
5.2	40 kph drive hydraulic diagram for models 402 – 404	5-6
5.3	Drive hydraulic diagram (designations)	5-7
5.4	40 kph drive electrics diagram for models 402, 403, 404	5-10
5.5	30 – 40 kph drive electrics diagram for models 400 – 404	5-12
5.6	Electrical diagram (designations)	5-13
5.7	Functional description of drive hydraulics and electrical system	5-15
5.8	Drive electrics connector assignment for models 400 – 404	5-18
5.9	Towing and transporting the machine	5-19
5.10	Hydraulic pump TMP 89 (models 402, 403, 404)	5-21
5.11	Hydraulic pump H1 P078 (models 400, 401, 402)	5-22
5.12	High speed gearbox (0 – 40 kph)	5-23
5.13	High-speed gearbox with auxiliary motor (0 – 40 kph)	5-23
5.14	Function without auxiliary motor (0 – 40 kph)	5-24
5.15	Function with auxiliary motor (0 – 40 kph)	5-24
5.16	Gearbox overview (0 – 40 kph)	5-25
5.17	Overview of control cover and diagram up to serial no. (0 – 40 kph)	5-26
5.18	Overview of control cover and diagram from serial no. (0 – 40 kph)	5-27
5.19	Control cover component parts for gearbox (0 – 40 kph)	5-28
5.20	Hydraulic drive circuit (0 – 40 kph)	5-29
5.21	Legend for gearbox circuit diagram (0 – 40 kph)	5-30
5.22	Gearbox circuit diagram (0 – 40 kph)	5-31
5.23	Legend for gearbox circuit diagram with auxiliary motor (0 – 40 kph)	5-32
5.24	Gearbox circuit diagram with auxiliary motor (0 – 40 kph)	5-33
5.25	Measurement reports	5-34
5.26	Test report for model 400/401/402 with H1 pump without auxiliary motor (0 – 40 kph) 5-36	
5.27	Test report for model 403/404/402 with TMP89 pump and auxiliary motor (fixed displacement motor) (0 – 40 kph) 5-37	
5.28	Test report for model 403/404 diesel engine 103 kW and TMP89 pump and auxiliary motor (variable displacement motor) (0 – 40 kph) 5-38	
5.29	Test report for model 402/403/404 (30 kph)	5-39
5.30	Error description for test report	5-40
5.31	Checking and setting boost pressure (0 – 40 kph gearbox)	5-41
5.32	Checking high pressure (0 – 40 kph)	5-42
5.33	Checking engine droop (pump) (0 – 40 kph)	5-43
5.34	Checking driving direction identification (0 – 40 kph)	5-44
5.35	Setting engine droop on the gearbox with/without auxiliary motor (fixed displacement motor 0 – 40 kph)	5-45
5.36	Control initiation set screw (0 – 40 kph gearbox)	5-46
5.37	Checking the cardan shaft speed (0 – 40 kph gearbox)	5-47
5.38	Troubleshooting work on drive	5-48
5.39	Hydraulic pump report	5-49
5.40	Report for measurement 1 of hydraulic pump (engine speed and boost pressure)	5-50
5.41	Report for forward/reverse measurement 2 of hydraulic pump	5-51
5.42	Report for measurement of forward driving direction of hydraulic pump:	5-52
5.43	Report for forward measurement 3 of hydraulic pump:	5-53
5.44	Variable displacement pump test for models 400/401 and 402	5-54
5.45	Variable displacement pump test for models 402/403/404	5-56
5.46	Checking the high-speed gearbox	5-58

5.47	Measurement 1 (driving direction identification)	5-59
5.48	Measurement 2 (M4 pressure at shuttle throttle)	5-59
5.49	Measurements 3 and 4 (proportional solenoid and proportional regulator)	5-60
5.50	Measurement 5 (pressure relief valve M3, PCOR valve)	5-60
5.51	High-speed gearbox report: measurement 1 (driving direction identification)	5-61
5.52	High-speed gearbox report: measurement 2 (M4 shuttle pressure)	5-62
5.53	High-speed gearbox report: measurements 3 and 4 (proportional solenoid and proportional regulator)	5-63
5.54	Report: measurement 5 (pressure relief valve M3, PCOR valve)	5-64
5.55	Repair work on the high-speed gearbox	5-65
5.56	Repair work on the high-speed gearbox	5-68
5.57	Repair work on the high-speed gearbox	5-69
5.58	Checking or replacing the shuttle throttle	5-72
5.59	Removing the shuttle throttle	5-73
5.60	Installing the shuttle throttle	5-76
5.61	Checking the auxiliary motor	5-77
5.62	Switching off rear axle/4 wheel drive	5-78
5.63	Disabling 4 wheel drive (overview)	5-79
5.64	Installation position	5-80
5.65	Drive electronics Operator's Manual (SUSMIC)	5-81
5.66	Error table	5-82
5.67	Checking the proportional valves by means of current measurement	5-83
5.68	Removing the consumers circuit from the hydraulic drive	5-84
5.69	Sealing work on the drive shaft (0 – 40 kph gearbox)	5-85
5.70	Mounting the rotary shaft seal (0 – 40 kph gearbox)	5-86
5.71	Mounting the drive flange (0 – 40 kph gearbox)	5-87
5.72	Sealing the Ecospeed gearbox	5-88
5.73	Removing the control cover (old) from the Ecospeed gearbox	5-89
5.74	Travelling drive with reduced engine speed	5-98
5.75	Overview: auxiliary motor (variable displacement motor)	5-99
5.76	Overview: auxiliary motor (variable displacement motor)	5-100
5.77	Checking control initiation/engine droop of auxiliary motor (variable displacement motor) 5-101	
5.78	Drive (electrical diagram)	5-104
5.79	20 kph hydraulic drive diagram for models 400 – 404	5-106
5.80	Drive hydraulic diagram (descriptions)	5-107
5.81	Functional description of drive hydraulics and electrical system	5-109
5.82	Drive electrics connector assignment for models 400 – 404	5-112
5.83	Variable displacement motor 110 cm ³ /rev (20 kph)	5-113
5.84	Variable displacement motor 110 cm ³ /rev (20 kph, seen from the side)	5-114
5.85	Variable displacement motor 160 cm ³ /rev (20 kph)	5-115
5.86	Test report for model 400 – 404 (20 kph)	5-116
5.87	Error description for test report models 400/401 (20 kph)	5-117
5.88	Hydraulic circuit: drive with hydraulic pump H1 P078 (20 kph)	5-118
5.89	Hydraulic circuit: drive with hydraulic pump TMP 89 (20 kph)	5-119
5.90	Setting boost pressure (20 kph)	5-120
5.91	Checking high pressure (20 kph)	5-121
5.92	Checking engine droop – variable displacement pump (20 kph)	5-122
5.93	Setting engine droop – hydraulic motor (20 kph)	5-123
5.94	Setting final speed (20 kph)	5-124

6 Axles/differential lock

6.1	Differential lock diagrams (serial no.)	6-2
6.2	Designations: differential lock electrical diagram	6-3
6.3	Differential lock diagrams	6-6
6.4	Functional description of differential lock	6-7
6.5	Differential lock connector assignment	6-8
6.6	20 kph gearbox (overview)	6-9

6.7	Removing the 20 kph gearbox	6-10
6.8	Installing the 20 kph gearbox	6-17
6.9	Front and rear axle flanges	6-25
6.10	Type label and oil filler neck (overview)	6-26
6.11	Conversion table and tightening torques	6-27
6.12	Removing the joint housing	6-28
6.13	Installing the joint housing	6-30
6.14	Removing the double cardan shaft	6-31
6.15	Mounting the double cardan shaft	6-33
6.16	Remove the planetary drive	6-35
6.17	Replacing the seals of the planetary drive	6-37
6.18	Installing the planetary drive	6-38
6.19	Installing the planetary drive	6-40
6.20	Sealing the front axle differential	6-42
6.21	Removing the front axle differential lock	6-44
6.22	Installing the front axle differential lock	6-47
6.23	Differential lock: hydraulic circuit	6-50
6.24	Special tools (overview)	6-51

7 Brakes

7.1	Brake (20 kph) diagrams (electric/hydraulic)	7-2
7.2	Brake (40 kph) diagrams (electric/hydraulic)	7-4
7.3	Hydraulic diagram – trailer brake valve	7-6
7.4	Designations: hydraulic brake diagram	7-7
7.5	Designations: electric brake diagram	7-8
7.6	Functional description of brakes	7-9
7.7	Brakes connector assignment	7-10
7.8	40 kph brake circuit (overview)	7-11
7.9	20 kph brake circuit (overview)	7-12
7.10	Disabling (releasing) the parking brake in the front axle	7-13
7.11	Enabling (adjusting) the parking brake in the front axle	7-13
7.12	Wear check: service brake discs	7-14
7.13	Setting the brake linkage – master brake cylinder	7-14
7.14	Service and parking brake (overview)	7-15
7.15	Removing the brake discs	7-16
7.16	Brake discs (overview)	7-19
7.17	Installing the brake pistons of the service and parking brake	7-20
7.18	Installing the belleville spring washers and the brake cylinder housing	7-21
7.19	Installing the service brake	7-23
7.20	Towing and transporting the machine	7-26
7.21	Hydraulic trailer brake circuit (option)	7-28
7.22	Air compressor	7-29
7.23	Air compressor overview	7-30
7.24	Air compressor components	7-31
7.25	Valves (air compressor)	7-32
7.26	Circuit (air compressor)	7-33

8 Steering system

8.1	Electrical/hydraulic diagrams for steering system up to serial no. 400 01 0167, 401 03 0195, 402 03 0176, 403 03 0145, 404 03 0146 8-2	8-2
8.2	Electrical/hydraulic diagrams for steering system from serial no. 400 01 0168, 401 03 0196, 402 03 0177, 403 03 0146, 404 03 0147, 8-4	8-4
8.3	Designations: electric steering diagram	8-5
8.4	Designations: hydraulic steering diagram	8-6
8.5	Functional description of steering system	8-7
8.6	Steering system connector assignment	8-8

8.7	Steering circuit with variable displacement pump (LS = load sensing)	8-9
8.8	Hydraulic steering diagram: priority valve – variable displacement pump (LS = load sensing) 8-10	
8.9	Steering circuit with gear pump	8-11
8.10	Hydraulic steering diagram: priority valve – gear pump	8-12
8.11	Hydraulic steering diagram: 4 wheel steering/front axle steering	8-13
8.12	Diagonal steering circuit (crab steering)	8-14
8.13	Hydraulic steering diagram: front axle steering with diagonal steering valve (crab steering)	8-15
8.14	Hydraulic steering diagram: diagonal steering with diagonal steering valve (crab steering)	8-16
8.15	Hydraulic steering diagram: 4 wheel steering with diagonal steering valve (crab steering) 8-17	
8.16	Steering system goes out of line (20/40 kph)	8-18
8.17	Steering valve (overview)	8-19
8.18	Pressure relief valve – servostat: settings	8-20
8.19	Front and rear axle steering sensor (magnetic sensor)	8-21
8.20	Removing the steering rams	8-22
8.21	Installing the steering rams	8-26
8.22	Adjusting the steering angle	8-30

9 Work hydraulics

9.1	Work hydraulics fixed displacement pump (diagram) – raising/lowering the telescopic boom (HUSCO)	9-2
9.2	Work hydraulics fixed displacement pump (diagram) – raising/lowering the telescopic boom (Bucher)	9-4
9.3	Work hydraulics variable displacement pump (diagram) – raising/lowering the telescopic boom (HUSCO)	9-6
9.4	Work hydraulics variable displacement pump (diagram) – raising/lowering the telescopic boom (Bucher)	9-8
9.5	Raising/lowering the telescopic boom (electrical diagram)	9-10
9.6	Load stabiliser (electrical diagram)	9-12
9.7	Work hydraulics (diagram) – extending/retracting the telescopic boom, fixed displacement pump (HUSCO)	9-14
9.8	Work hydraulics fixed displacement pump (diagram) – extending/retracting the telescopic boom	9-16
9.9	Work hydraulics variable displacement pump (diagram) – extending/retracting the telescopic boom (HUSCO)	9-18
9.10	Work hydraulics variable displacement pump (diagram) – extending/retracting the telescopic boom (Bucher)	9-20
9.11	Work hydraulics variable displacement pump (diagram) – extending/retracting the telescopic boom	9-22
9.12	Extending/retracting the telescopic boom (electrical diagram)	9-24
9.13	Retracting/extending the telescopic boom (designations)	9-25
9.14	Work hydraulics fixed displacement pump (diagram) – dumping in/out (HUSCO)	9-28
9.15	Work hydraulics fixed displacement pump – dumping in/out (diagram)	9-30
9.16	Work hydraulics variable displacement pump (diagram), dumping in/out (HUSCO)	9-32
9.17	Work hydraulics variable displacement pump (diagram) – dumping in/out (Bucher)	9-34
9.18	Dumping in/out (electrical diagram)	9-36
9.19	4 wheel drive OFF (electrical diagram)	9-38
9.20	Dumping in/out (electrical diagram)	9-40
9.21	Bucket repositioning (electrical diagram)	9-42
9.22	Work hydraulics fixed displacement pump (diagram) – locking/unlocking (HUSCO)	9-44
9.23	Work hydraulics fixed displacement pump (diagram) – locking/unlocking (Bucher)	9-46
9.24	Work hydraulics variable displacement pump (diagram) – locking/unlocking (HUSCO)	9-48
9.25	Work hydraulics variable displacement pump (diagram) – locking/unlocking (Bucher)	9-50
9.26	Locking/unlocking (electrical diagram)	9-52
9.27	Work hydraulics fixed displacement pump (diagram) – rear additional control circuit (HUSCO)	9-54
9.28	Work hydraulics fixed displacement pump (diagram) – additional control circuit (Bucher)	9-56
9.29	Work hydraulics variable displacement pump (diagram) – rear additional control circuit (HUSCO)	9-58
9.30	Work hydraulics variable displacement pump (diagram) – additional control circuit (Bucher)	9-60
9.31	Work hydraulics fixed displacement pump (diagram) – rear additional control circuit, Autohitch (HUSCO)	9-62
9.32	Work hydraulics fixed displacement pump (diagram) – additional control circuit, Autohitch (Bucher)	9-64
9.33	Work hydraulics variable displacement pump (diagram) – rear additional control circuit, Autohitch (HUSCO)	9-66
9.34	Work hydraulics variable displacement pump (diagram) – additional control circuit, Autohitch (Bucher)	9-68
9.35	Work hydraulics fixed displacement pump (diagram) – rear additional control circuit, Autohitch, tipping trailer (HUSCO)	9-70
9.36	Work hydraulics fixed displacement pump (diagram) – additional control circuit, Autohitch, tipping trailer (Bucher)	9-72
9.37	Work hydraulics variable displacement pump (diagram) – rear additional control circuit, Autohitch, tipping trailer (HUSCO)	

9-74	
9.38	Work hydraulics variable displacement pump (diagram) – additional control circuit, Autohitch, tipping trailer (Bucher) 9-76
9.39	Work hydraulics fixed displacement pump (diagram) – rear additional control circuit, tipping trailer (HUSCO) 9-78
9.40	Work hydraulics fixed displacement pump (diagram) – additional control circuit, tipping trailer (Bucher) 9-80
9.41	Work hydraulics variable displacement pump (diagram) – rear additional control circuit, tipping trailer (HUSCO) 9-82
9.42	Work hydraulics variable displacement pump (diagram) – additional control circuit, tipping trailer (Bucher) 9-84
9.43	Work hydraulics fixed displacement pump (diagram) – Autohitch (HUSCO) 9-86
9.44	Work hydraulics fixed displacement pump (diagram) – Autohitch (Bucher) 9-88
9.45	Work hydraulics variable displacement pump (diagram) – Autohitch (HUSCO) 9-90
9.46	Work hydraulics variable displacement pump (diagram) – Autohitch (Bucher) 9-92
9.47	Work hydraulics fixed displacement pump (diagram) – Autohitch, tipping trailer (HUSCO) 9-94
9.48	Work hydraulics fixed displacement pump (diagram) – Autohitch, tipping trailer (Bucher) 9-96
9.49	Work hydraulics variable displacement pump (diagram) – Autohitch, tipping trailer (HUSCO) 9-98
9.50	Work hydraulics variable displacement pump (diagram) – Autohitch, tipping trailer (Bucher) 9-100
9.51	Work hydraulics fixed displacement pump (diagram) – tipping trailer (HUSCO) 9-102
9.52	Work hydraulics fixed displacement pump (diagram) – tipping trailer (Bucher) 9-104
9.53	Work hydraulics variable displacement pump (diagram) – tipping trailer (HUSCO) 9-106
9.54	Work hydraulics variable displacement pump (diagram) – tipping trailer (Bucher) 9-108
9.55	Work hydraulics variable displacement pump (diagram) – additional control circuit for quick couplers on telescopic boom (HUSCO) 9-110
9.56	Work hydraulics fixed displacement pump (diagram) – additional control circuit for quick couplers on telescopic boom 9-112
9.57	Work hydraulics (diagram) – safe load indicator 9-114
9.58	Work hydraulics (diagram) – safe load indicator (HUSCO) 9-116
9.59	Front/rear additional control circuit for quick couplers, Autohitch, tipping trailer (electrical diagram) 9-118
9.60	Front socket, safe load indicator (electrical diagram) 9-120
9.61	Front socket, safe load indicator (electrical diagram) 9-122
9.62	Work hydraulics variable displacement pump (diagram) – additional control circuit for quick couplers on quickhitch (HUSCO) 9-124
9.63	Work hydraulics variable displacement pump (diagram) – work platform with radio control 9-126
9.64	Work hydraulics variable displacement pump (diagram) – work platform with radio control 9-128
9.65	Work platform with radio control: electrical diagram 9-130
9.66	Remote radio controls (diagram designations) 9-131
9.67	Work platform with radio control (electrical diagram) with common rail 9-134
9.68	Work platform with radio control (electrical diagram) without common rail 9-136
9.69	Tilt ram lock (electrical diagram) 9-138
9.70	Tilt ram lock (electrical diagram) 9-140
9.71	Work hydraulics variable displacement pump (diagram) – frame levelling, oscillating axle interlock 9-142
9.72	Frame levelling, oscillating axle interlock (electrical diagram) 9-144
9.73	Frame levelling, oscillating axle interlock (electrical diagram) 9-146
9.74	Oscillating axle interlock (electrical diagram) 9-148
9.75	Work hydraulic diagram (designations) 9-149
9.76	Functional description of work hydraulics 9-153
9.77	Work hydraulics connector assignment 9-157
9.78	Test report: models 400/401 Husco control valve 9-158
9.79	Test report: models 400/401 Bucher control valve 9-159
9.80	Test report: models 402/403/404 Husco control valve 9-160
9.81	Test report: models 402/403/404 Bucher control valve 9-161
9.82	Work hydraulics test ports 9-162
9.83	Variable displacement pump (hydraulic pump) 9-163
9.84	Checking and setting the work hydraulics 9-165
9.85	Work hydraulics circuit (gear pump) 9-167
9.86	Work hydraulics circuit (variable displacement pump LS) 9-168
9.87	Control valve connections (4-fold) HUSCO 9-169
9.88	Control valve (4-fold) (overview) HUSCO 9-170
9.89	Control valve connections (5-fold) HUSCO 9-171
9.90	Control valve (5-fold) (overview) HUSCO 9-172
9.91	Control valve connections (5-fold) Bucher 9-173

9.92	Control valve (5-fold) (overview) Bucher	9-174
9.93	Lift ram circuit	9-175
9.94	Tilt ram circuit	9-176
9.95	Compensating ram circuit	9-177
9.96	Push-out ram circuit	9-178
9.97	3rd control circuit	9-179
9.98	Control valve (4-fold) pilot control circuit	9-180
9.99	Valve block connections (overview)	9-181
9.100	Pilot control unit, pilot valve	9-182
9.101	Load stabiliser	9-183
9.102	Load stabiliser circuit	9-185
9.103	Changeover valve: Autohitch/tipping trailer connection/additional control circuit	9-186
9.104	Autohitch, rear additional control circuit	9-187
9.105	Tipping trailer connection circuit	9-188
9.106	Front additional control circuit	9-189
9.107	Frame levelling with oscillating axle interlock (option) telehandler 404 (overview)	9-190
9.108	Bleeding the hydraulic ram of the oscillating axle interlock	9-193
9.109	Frame levelling circuit	9-194
9.110	Frame levelling valve overview	9-195
9.111	Lift ram with hose burst valve (overview)	9-196
9.112	Tilt ram (overview)	9-197
9.113	Push-out ram with final position damping (overview)	9-198
9.114	Compensating ram (overview)	9-198
9.115	Quickhitch	9-199
9.116	Installing the telescopic boom	9-200
9.117	Replacing the flexible line in the telescopic boom	9-209
9.118	Replacing the control valve	9-212
9.119	Replacing the priority valve	9-212
9.120	Replacing the fan pump	9-213
9.121	Replacing the A 10 work hydraulics pump	9-214
9.122	Replacing the pilot valve	9-214

10 Electrical systems

10.1	Machine lights (electrical diagram)	10-2
10.2	Machine lights (electrical diagram)	10-4
10.3	Turn indicators/horn/rotating beacon (electrical diagram)	10-6
10.4	Turn indicators, horn, rotating beacon (electrical diagram)	10-8
10.5	Mirror adjustment/heating (electrical diagram)	10-10
10.6	Mirror adjustment/heating (electrical diagram)	10-12
10.7	Wiper/washer diagram	10-14
10.8	Hydraulics monitoring diagram	10-16
10.9	Hydraulics monitoring (electrical diagram)	10-18
10.10	Wiper/washer diagram	10-20
10.11	Washer system (electrical diagram)	10-22
10.12	Heating – air conditioning system/air-suspension seat (electrical diagram)	10-24
10.13	Multimedia/cigarette lighter (electrical diagram)	10-28
10.14	Multimedia/cigarette lighter (electrical diagram)	10-30
10.15	Cab legend (SLP II)	10-33
10.16	Cab wiring diagram (SLP II)	10-34
10.17	Cab legend (SLP II)	10-35
10.18	Cab wiring diagram (SLP III)	10-36
10.19	Cab legend (SLP III)	10-37
10.15	Cab wiring harness	10-41
10.16	Cab option wiring harness	10-42
10.17	Armrest wiring harness	10-44
10.18	Mirror adjustment wiring harness	10-45

10.19	Engine vat signals wiring diagram (SLP IV)	10-46
10.20	Engine vat wiring harness	10-47
10.21	Engine compartment legend	10-48
10.22	Frame signal wiring diagram (SLP V)	10-49
10.23	Frame wiring harness	10-51
10.24	Frame legend	10-52
10.25	Options signals wiring diagram (SLP VI)	10-53
10.26	Socket wiring harness X3	10-54
10.27	Additional valves wiring harness	10-55
10.28	Mirror/preheating option wiring harness	10-56
10.29	Overall diagrams legend	10-57
10.30	Electric machine components (overview)	10-59
10.31	Electrical diagram designations and positions	10-61
10.32	Connector positions on machine	10-62
10.33	Functional description of hydraulics monitoring	10-65
10.34	Hydraulics monitoring connector assignment	10-65
10.35	Lights connector assignment	10-66
10.36	Turn indicator/horn connector assignment	10-67
10.37	Rotating beacon connector assignment	10-68
10.38	Mirror adjustment connector assignment	10-68
10.39	Mirror heating connector assignment	10-68
10.40	Window wiper/wash connector assignment	10-69
10.41	Heating/air conditioning connector assignment	10-69
10.42	Air-suspension seat connector assignment	10-70
10.43	Multimedia connector assignment	10-70
10.44	Cigarette lighter connector assignment	10-70
10.45	Ohm's Law (current, voltage, resistance); power	10-71
10.46	Multifunction measuring device	10-71
10.47	Terminal description	10-72
10.48	Cable colour coding	10-76
10.49	Electric components	10-78
10.50	Fuses (overview)	10-79
10.51	Electronic components (overview)	10-83
10.52	Functional description of the steering electronics	10-85
10.53	Proportional controls (overview and connections)	10-88
10.54	Proportional electronics	10-89
10.55	Hold electronics	10-90
10.56	Retrofitting the front right and rear right working lights	10-91
10.57	Retrofitting a rotating beacon	10-92
10.58	Retrofitting a radio	10-93
10.59	Retrofitting the low-speed control	10-93
10.60	Retrofitting the air conditioning system	10-94
10.61	Retrofitting a front or rear socket	10-95
10.62	Retrofitting a load stabiliser	10-95
10.63	Wiring harness disconnect (cab – machine frame)	10-96
10.64	Radio control system (transmitter) operation	10-97
10.65	Overview of transmitter and receiver system control elements	10-98
10.66	"STOP switch" safety feature on the transmitter	10-100
10.67	Indications regarding the transmitter battery	10-100
10.68	Taking the transmitter into service	10-101
10.69	Emergency lowering of the telescopic boom	10-102
10.70	Removing the work platform from the quickhitch	10-103
10.71	Maintenance work on the work platform	10-104
10.72	Maintenance work on the transmitter and receiver system	10-105
10.73	Charging the transmitter battery	10-106
10.74	Troubleshooting the transmitter and receiver system	10-107
10.75	Transmitter and receiver system specifications	10-107

10.76	List of frequencies for radio control system	10-108
10.77	Specifications – work platform	10-109
10.78	Inspection and maintenance work report	10-110
10.79	Remote radio control (hydraulic circuit)	10-111
10.80	Relays (overview)	10-112
10.81	Remote radio control valves (overview)	10-113
10.82	Safe load indicator	10-114
10.83	Safety instructions regarding the safe load indicator	10-115
10.84	Overview of displays	10-117
10.85	Safe load indicator for telescopic boom (version A)	10-118
10.86	Safe load indicator for telescopic boom (version B)	10-119
10.87	Safe load indicator for telescopic boom (version C)	10-121
10.88	Setting the safe load indicator (version C)	10-122
10.89	Safe load indicator settings for telescopic boom (version B)	10-125
10.90	Setting the safe load indicator (100 % point stability)	10-126
10.91	Removing the load sensor	10-128
10.92	Overload control in bucket mode	10-129
10.93	Overload control in fork lift mode	10-130
10.94	Disabling the overload control manually	10-131
10.95	Adjustment work on the overload control	10-132
10.96	Circuit diagram: overload control enabled	10-136
10.97	Circuit diagram: overload control disabled	10-137
10.98	Overview of valves	10-138
10.99	Overview of valve connections and ports	10-139
10.100	Circuit diagram: raising/lowering, switch S116 actuated (bucket operation)	10-140
10.101	Circuit diagram: raising/lowering under 36° and at 80 – 100 % load	10-141
10.102	Circuit diagram: raising/lowering over 100 % load and angle detection under 36°	10-142
10.103	Circuit diagram: raising/lowering, switch S84 actuated (overload control OFF)	10-143
10.104	Circuit diagram: raising/lowering, switch S125 retract (pallet forks operation)	10-144
10.105	Circuit diagram: raising/lowering, switch S125 ON (bucket operation)	10-145
10.106	Circuit diagram: extend telescopic boom, load less than 100 %	10-146
10.107	Circuit diagram: extend telescopic boom, load over 100 %	10-147
10.108	Circuit diagram: retract telescopic boom	10-148
10.109	Circuit diagram: retraction/extension switch S84 (telescopic boom extension)	10-149
10.110	Cab wiring harness (overload control)	10-150
10.111	Legend: cab wiring harness (overload control)	10-151
10.112	Frame wiring harness (overload control)	10-152
10.113	Relay wiring harness (overload control)	10-153
10.114	Legend: relays (overload control)	10-154
10.115	Electric components (overload control)	10-155


A Appendix

A.1	4-fold control valve (Bucher), fixed displacement pump (overall hydraulic diagram)	A-2
A.1	4-fold control valve (Bucher), variable displacement pump (overall hydraulic diagram)	A-4
A.2	4-fold control valve (HUSCO) (overall hydraulic diagram)	A-6
A.3	Hydraulics – 4-fold control valve: overall diagram	A-8
A.4	Fixed displacement pump – 5-fold control valve (Bucher) (overall hydraulic diagram)	A-10
A.5	Fixed displacement pump – 5-fold control valve (HUSCO) (overall hydraulic diagram)	A-12
A.6	Variable displacement pump – 5-fold control valve (Bucher) (overall hydraulic diagram)	A-14
A.7	Variable displacement pump – 5-fold control valve (HUSCO) (overall hydraulic diagram)	A-16

3.9 Maintenance of the engine and hydraulics cooling system

The combined engine/hydraulic oil cooler is located in the engine compartment. It cools the diesel engine, and the hydraulic oil of the drive and work hydraulics.

Specific safety instructions

**Danger!**

All work involving antifreeze carries an increased

Danger of poisoning and causticisation!

- ☞ Seek medical attention immediately if antifreeze has been swallowed
- ☞ Wear protective clothing and gloves
- ☞ Keep antifreeze out of reach of children

- Dirt on the radiator fins reduces the radiator's heat dissipation capacity! To avoid this:
 - Clean the outside of the radiator at regular intervals. Refer to the maintenance plans for the cleaning intervals
 - In dusty or dirty work conditions, clean more frequently than indicated in the maintenance plans
- An insufficient coolant level reduces the heat dissipation capacity as well and can lead to engine damage! Therefore:
 - Check the coolant level at regular intervals. Refer to the maintenance plans in the appendix for the intervals
 - If the coolant must be replaced frequently, have the cooling system checked for leaks by an authorised workshop!
 - Never fill in cold water/coolant if the engine is warm!
 - After filling the expansion tank, make a test run with the engine and check the coolant level again after stopping the engine
- The use of the wrong coolant can destroy the engine and the radiator. Therefore:
 - Add enough antifreeze to the coolant.
 - Use brand-name antifreeze compounds with anticorrosion additives – *see Fluids and lubricants (overview)* on page 3-4
 - Do not use radiator cleaning compounds if an antifreeze compound has been added to the coolant – otherwise this causes sludge to form that can damage the engine

**Environment!**

Use a suitable container to collect the coolant as it drains and dispose of it in an environmentally friendly manner!

Checking the coolant level and quality



Notice!

Check the coolant level every **10 s/h (service hours)** or once a day.

We recommend checking it before starting the engine.

Check the antifreeze at regular intervals, especially at temperatures below 4 °C!

Replace the coolant every 2 years!




Fig. 13: Checking the coolant expansion tank

Check the coolant level as follows

- Park the machine on level ground
- Lower the telescopic boom fully
- Apply the parking brake with the switch
- Stop the engine
- Switch off ignition and remove the ignition key
- Open the engine cover
- Check the coolant level in the expansion tank **A**

If the coolant level is below the **MIN** mark **B** of the expansion tank:

- Fill up coolant to the **MAX** mark **C**

Check the coolant quality (antifreeze) with suitable testing equipment (antifreeze tester)

- – see *Fluids and lubricants (overview)* on page 3-4 and
 - see *chapter 2 "Coolant compound table"* on page 2-14

Filling up coolant



Danger!

Never open the coolant tank and never drain coolant if the warm engine is running since the cooling system is under high pressure

Danger of burns!

- ☞ Wait at least 10 minutes after stopping the engine!
- ☞ Wear protective gloves and clothing
- ☞ Always actuate the safety valve in the filler cap of the expansion tank first.
To do this:
Unscrew the filler cap to the first notch and release the pressure




Fig. 14: Filling up coolant in the expansion tank

☞ Fill up coolant as follows

- Park the machine on level ground
- Lower the telescopic boom fully
- Apply the parking brake with the switch
- Switch off ignition and remove the ignition key
- Allow the engine/cooling system to cool down

Release the overpressure in the coolant expansion tank A. To do this:

- Open cap D to the first notch and release the pressure
- Open filler cap D fully
- Fill up coolant to the MAX mark C
- Use brand-name antifreeze compounds with anticorrosion additives – [see Fluids and lubricants \(overview\) on page 3-4](#) and
– [see chapter 2 "Coolant compound table" on page 2-14](#)
- Close filler cap D
- Start and warm up the engine, as you do so:
- Open the heating circuit fully (see Operator's Manual)
- Stop the engine
- Check the cooling system and the heating water circuit for leaks
- If necessary, have leaks immediately repaired by qualified and trained staff
- Check the coolant level again
- If necessary, fill in coolant and repeat the procedure until reaching the correct coolant level

Buy Now



Our support email:

ebooklibonline@outlook.com