


International 4300 Four-Wheel Drive Tractor

Operators Manual

1014467R1

Reprinted








If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates a potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates a potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

TABLE OF CONTENTS

TO THE OWNER	Inside Front Cover	SECTION III MAINTENANCE	
		General	23
		Periodic Maintenance	23
		10 Hour Maintenance Operations	23
		100 Hour Maintenance Operations	27
		200 Hour Maintenance Operations	31
		500 Hour Maintenance Operations	39
		1000 Hour Maintenance	
		Operations	41
		General Maintenance	44
		Fuel and Oil Handling	44
		Care of Hydraulic Systems	44
		Steering Gear	49
		Implement Control Valve	51
		Brake System	55
		Transmission	59
		Torque Converter Stall Check . .	59
		Drive Shafts	64
		Drive Line Noise	64
		Drive Axles	65
		Planet Carrier and Brake Drum	
		Removal	66
		Planet Carrier and Brake Drum	
		Assembly	68
		Adjust Wheel Brakes	68
		Hand Brake Adjustment	69
		Steering Linkage Adjustment . .	69
		Tire Care	72
		Electrical Systems	72
		Welding Repairs	76
		Cab Removal	77
-----*-----			
LIST OF CHARTS		LIST OF DIAGRAMS	
TABLE I	Transmission Speed	Figure 31. Air Brake System	16
	Ranges	Figure 37. Chassis Lubrication Diagram . .	27
TABLE II	Vehicle Speed Chart	Figure 43. Lubrication and Refill Diagram	32
TABLE III	Tire Pressures	Figure 52. Steering System Oil Flow	
TABLE IV	Chassis Lubrication	Diagram	46
TABLE V	Engine Oil Chart	Figure 56. Implement System Oil Flow	
TABLE VI	Specific Gravity Tem-	Diagram	51
	perature Correction	Figure 68. Wiring Diagram	73
	Chart		
TABLE VII	Lubrication and Refill		
	Chart		
TABLE VIII	Fan Belt Tension		
	General Torque Speci-		
	fications - Bolts and		
	Screws		
TABLE X	Transmission Trouble		
	Shooting		




Figure 1. 4300 FOUR-WHEEL DRIVE TRACTOR

OPERATOR'S MANUAL FOR 4300 FOUR-WHEEL DRIVE TRACTOR

SECTION I INTRODUCTION

GENERAL

Operation and periodic service instructions for the 4300, four-wheel drive tractor are contained in this handbook. The tractor is made by THE FRANK G. HOUGH CO., Libertyville, Illinois. Its capacity for work, maneuverability and fast-acting hydraulic steering system make it a good piece of equipment for handling large capacity, heavy duty agricultural implements.

The drive train consists of a high speed, turbocharged, four-cycle diesel engine transmitting power to the drive axles through a torque converter and power shift transmission.

Two gear type pumps supply fluid for the hydraulic circuits of the tractor. They are gear driven by the engine. The hydraulic system reservoirs are pressure sealed units that are mounted so they are easily accessible on the right side of the tractor. A control valve, mounted in front of the implement reservoir, regulates the flow of oil to the implement and accessory disconnects at the rear of the tractor. Control of the steering-assist cylinders is regulated by a control valve on the steering gear.

The tractor wheel brakes are operated by a compressed air system. Compressed air for the system is pumped by a two-cylinder, engine driven compressor and is stored in an air tank. A treadle control valve in the operator's compartment varies the flow of compressed air to the wheel brake chambers.

Satisfactory performance of the tractor can always be obtained if the operator and maintenance personnel adapt the unit to existing work conditions. Being acquainted with necessary

operation and service requirements will assist personnel in using the tractor to best advantage.

There are few rules which must be observed. A neglect of operating or service instructions will result in decreased tractor efficiency. It may also cause costly down-time and repairs due to accidents and premature failures. The important job which the operator performs while working the tractor will determine to a large degree its effectiveness.

LEFT and RIGHT in this manual indicate the left and right sides of the tractor when facing forward in the operator's seat. Reference to FRONT indicates the radiator end of the tractor; to REAR - the drawbar end.

All replaceable parts for this tractor are illustrated in the parts book for the 4300 four-wheel drive tractor. Requests for parts or additional information for a particular tractor should specify the tractor serial number and also the engine and transmission serial numbers.

SERIAL NUMBERS.

Record the tractor, engine and transmission serial numbers for service and parts replacement purposes. The tractor serial number plate (figure 2) is mounted on the steering column shrouding below the steering post. The engine serial number (figure 3) is stamped on the right side of the engine block below the rear exhaust manifold. The transmission serial number plate (figure 4) is located on the left side of the transmission housing near the rear of the housing. Record these numbers in the operator's and parts books that accompany each tractor.

INTRODUCTION




Figure 2. Tractor serial number plate

PRELIMINARY CHECKS.

Upon receipt of a new 4300, four-wheel drive tractor or when servicing it for active operation after a long period of storage, the tractor should be thoroughly inspected.

Note

Drain and refill crankcase with series #3 oil prior to any operation.

Check that such components as the engine, transmission, axles, drive shafts, steering gear linkages, etc., are securely mounted. Operate all control levers to check operation of the control linkages. Should the controls fail to work properly, check for bent control rods and loose fittings. Inspect all lines and connections in the cooling, hydraulic, brake, fuel and transmission systems.




Figure 3. Engine serial number

Open the fuel line shut off at the tank and check the condition and supply of fuel. Check the

fluid levels in the hydraulic oil reservoirs, transmission, engine crankcase, cooling system and the differentials and hubs of both axles. Refer to Section III, Periodic Maintenance.

The tractor battery cables are disconnected at the factory for shipping purposes. Before connecting the cables, check that each battery cell is filled with enough electrolyte to cover the cell plates. Do not connect the cables if the tractor is to remain in storage any length of time.

Prior to connecting the cables, refer to figure 68. Clean the battery terminals and the inside of the cable clamps with sandpaper or a wire brush. Then wipe the battery tops clean.

It is good practice after connecting cables to the battery terminals to grease them with a heavy bodied mineral grease or petroleum. Do not apply an excess amount as it may flow onto the battery sealing compound and soften it.

Always observe correct polarity. Connect the long negative lead to the negative battery power source as shown in figure 68. Connect the long positive lead to the positive battery power source as shown in figure 68. Proper battery hookup is necessary to protect the tractor charging system and to provide proper system voltage.

Connect the negative cable last. Arrange the cable clamps so they will not interfere with removal of the vent plugs and arrange the cables so they will not be chaffed.

Check that the batteries rest level in the holder and are properly secured. The hold-down nuts should be tight enough to hold the batteries secure but not so tight that either the battery hold-down or cases are distorted.




Figure 4. Transmission serial number plate




Figure 5. General arrangement



SAFETY PRECAUTIONS.

Farm tractors of this size, if not properly used, are dangerous. For this reason the operator should be aware of hazardous conditions and develop safe working habits. In this way, he can protect himself, other personnel and the tractor. Avoid all safety risks. Safe operation of the tractor, for the most part, is the responsibility of the operator.

The following safety precautions are those which are most common to a majority of working conditions. Safety precautions that are peculiar to certain specific work situations should be added to this list.

- a. Make sure no one is in the path of the tractor and the attached implement before moving the tractor.
- b. Always mount and dismount the tractor on the left side. Use the ladder provided to avoid falls and accidental movement of control levers. Keep the ladder clean.
- c. Select the direction and a speed range that is safe for the particular job. Operate at reduced road speeds when slippery conditions exist.
- d. Always face the direction the tractor is traveling.
- e. Do not carry passengers on the tractor.
- f. Never leave the tractor unattended with the engine running. Place the transmission lever in neutral, set the hand brake and shut down the engine before leaving the operator's seat.
- g. Stop the engine and set the hand brake before refueling, lubricating or cleaning the tractor.
- h. Avoid smoking while refueling or using starting fluid.
- i. Do not add makeup fluid to the cooling system of a hot engine. Give it a chance to cool before removing the radiator cap. Remove the cap slowly to release all pressure build-up in the system.
- j. Keep operating controls and hands free of grease, water and mud to insure positive control lever movement. The deck of the operator's compartment and the ladder must be kept free of oil and grease to lessen the danger of slipping.
- k. Apply the hand brake when the tractor is parked or when the operator's seat is vacated. Wheel blocks may also be needed to hold the tractor if it is parked on a grade.
- l. Disconnect the battery ground when working on the engine or electrical system.
- m. Keep the tractor in gear while traveling on steep slopes.

TRACTOR SPECIFICATIONS

ENGINE.

Make International Harvester
 Model DT-817 (Turbo-Charged)
 Type High Speed, Four Cycle Diesel
 Governed Speed 2100 rpm
 Low Idle Speed 650 rpm
 Horsepower (2100 rpm) 300
 Maximum Torque (1500 rpm) 825 ft. lb.
 Number of Cylinders 6
 Type Injectors Open
 Fuel Pump Make International Harvester
 Fuel Pump Model Type "C" - Twin Plunger
 Piston Displacement 817 cu. in.
 Stroke 6 in.
 Bore 5-3/8 in.
 Compression Ratio 15.04 to 1
 Lubricating Pressure 20 to 55 psi
 Crankcase Capacity 34 qt.

Oil Cooler Liquid to Liquid Type
 Oil Filtration Three Radial Fin, Mechanical
 Type Units
 Air Cleaner Dry Type
 Operating Temperature Range 180° - 195°

GENERAL.

A Height With Cab 10 ft. 9 in.
B Height to Top of Steering Wheel 8 ft. 10-1/2 in.
C Height to Top of Exhaust Stack 12 ft. 4 in.
D Width at Axle Hubs 9 ft. 4 in.
E Length (Grille to Drawbar) 21 ft. 9-1/4 in.
F Wheel Base 10 ft. 0 in.
G Ground Clearance 1 ft. 7-1/2 in.
 Total Rear Axle Oscillation 13°
 Inside Turning Radius
 (Four Wheel Steer) 10 ft. 2 in.
 (Two Wheel Steer) 23 ft. 6 in.

INTRODUCTION




Figure 6. Exterior dimensions

Outside Turning Radius
 (Four Wheel Steer) 17 ft. 0 in.
 (Two Wheel Steer) 30 ft. 6 in.
 Weight on Front Axle . 19,000 lb. (estimated)
 (Standard Tractor)
 Weight on Rear Axle . . 11,000 lb. (estimated)
 (Standard Tractor)
 Total Weight 30,000 lb. (estimated)
 (Standard Tractor)

TRANSMISSION.

Make . . . Allison Division of General Motors Corp.
 Model CLBT 4460 Series
 Type . . Torque Converter and Planetary Gear
 Rotation (looking at input). . Input: Clockwise
 Output: Clockwise (in forward gears)
 Torque Converter Type. . Single-stage, Polyphase, Three-element
 Stall Torque Ratio 2.55 to 1

Transmission Capacity . . Initial fill: 10 gal.
 Refill: 6-3/4 gal.
 Oil Specification . . . Type C-1 or SAE 10W, MS (sequence tested) qualified to MIL-L-2104A Supplement 1 or MIL-L-2104B
 Maximum Temperature . . 250°F. at Torque Converter Outlet
 Heat Exchanger Oil to Water
 Remote Mounted Oil . . . Pleated Paper Type
 Filter Element 55 Micron Rating
 Input Pressure External-Tooth Spur
 Pump Type Gear, Positive Displacement, Dual Section
 Scavenge Pump Type. . External-Tooth Spur Gear, Positive Displacement
 Oil Pressure Fwd. Ranges 205 psi min. Schedule (1000 . . Rev. Range - 280 psi max.
 Engine RPM - 235 psi min.
 Output Shaft . . . Converter Out - 40 to 65 psi Stalled) Lubrication - 25 to 30 psi
 Parking Brake . . . Two-Shoe, Internal, Drum Type



Our support email:

ebooklibonline@outlook.com