

Panther II Tractor

Operators Manual

37-042

Reprinted





*This symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED.** The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.*

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
2. MAKE SURE THE OPERATOR READS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS MACHINE.

WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.

BEFORE STARTING THE ENGINE, DO THE FOLLOWING:

1. READ THE OPERATOR'S MANUAL.
2. READ ALL SAFETY DECALS ON THE MACHINE.
3. CLEAR THE AREA OF OTHER PERSONS.

LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

OPERATOR'S MANUAL

PANTHER II



STEIGER TRACTOR INC. 3101 1st Ave. N. Fargo, N. Dak. 58102

SERVICE RECORD

ENGINE

[illegible]

KEEP AN ACCURATE RECORD OF SERVICING ON THE CHART BELOW

CRANKCASE LUBE
8 OIL FILTER

[illegible]

FUEL FILTERS

[illegible]

ENGINE
AIR FILTER

[illegible]

TRANSMISSION & DROP BOX COOLING

TRANSMISSION
FILTER[illegible]

CENTRAL SUMP

[illegible]

HYDRAULICS

RETURN FILTER

[illegible]

HYD. OIL FILTER

[illegible]

MISCELLANEOUS

[illegible]

| |
|--|
| |
|--|



DELIVERY CHECK PANTHER II

Customer Name _____

Address _____

Dealer Name _____

Address _____ Date _____

Engine Serial No. _____ Tractor Serial No. _____

ENGINE:

- ☐ Engine Hi-idle, no load
(Approx. 2200 RPM)
- ☐ Engine Oil Level
- ☐ Belts
- ☐ Oil Pressure (Idle 15 PSI)
(2100 RPM 50-70 PSI)
- ☐ Engine Mounts
- ☐ Engine Temp. Gauge
- ☐ AMP Gauge
- ☐ Fuel Gauge
- ☐ Alternator
- ☐ Battery Performance
- ☐ Battery Cables
- ☐ Radiator Level
- ☐ Fuel Line Leaks
- ☐ Fuel Filter
- ☐ Oil Filter
- ☐ Fuel Tank
- ☐ Fuel Tank Cover
- ☐ Electric Wire System
- ☐ Engine Air Cleaner Elements
- ☐ Engine Air Cleaner Tube Clamps
- ☐ Engine Shut Down System
Operations

DROP BOX:

- ☐ Oil Level
- ☐ Flange Bolts
- ☐ U-Joints
- ☐ Mount Bolts
- ☐ Swing Box Mounts

CAB:

- ☐ Cab Appearance
- ☐ Vinyl Covering
- ☐ Window Glass
- ☐ Door Latches
- ☐ Weather Stripping
- ☐ Window Wipers
- ☐ Seat & Arm Rests
- ☐ Floorboard Mat
- ☐ Interior Lights
- ☐ Tach & Hour Meter
- ☐ Radio
- ☐ Throttle Linkage
- ☐ Throttle Lever

DIFFERENTIAL:

- ☐ Oil Level
- ☐ Oil Level Planet
- ☐ Axle Bolts
- ☐ Lug Bolts & Nuts
- ☐ Drive Line Joints
- ☐ Tire Pressure & Size

HYDRAULICS:

- ☐ Tank Level
- ☐ Oil Line Leaks
- ☐ Filters
- ☐ Control Valve
- ☐ Pump
- ☐ Steering Cylinders
- ☐ Quick Couplers
- ☐ Hose Connectors

TRANSMISSION:

- ☐ Leaks
- ☐ Oil Level
- ☐ Filter
- ☐ Flange Bolts
- ☐ Drive Shafts
- ☐ U-Joints
- ☐ Mounts
- ☐ Clutch Adjustment
- ☐ Transmission Pressure (5 - 20 PSI
hot oil)


BRAKES:

- ☐ Brake Fluid
- ☐ Brakes

THIS TRACTOR HAS BEEN DELIVERED TO ME IN GOOD CONDITION WITH AN OPERATOR'S MANUAL AND I HAVE BEEN INSTRUCTED IN THE FUNCTION SAFE OPERATION AND ADJUSTMENTS OF THE ITEMS LISTED ABOVE.

OWNER'S SIGNATURE _____

TRACTOR APPLICATION _____



200 HOUR CHECK PANTHER II

THIS FORM MUST BE FILLED OUT BY THE DEALER AND SIGNED BY THE CUSTOMER AT THE TIME THE 200 HOUR CHECK IS PERFORMED IN ORDER FOR THE WARRANTY TO BE VALID.

Dealers Name _____

Address _____

Customers Name _____

Address _____

Tractor Model _____ Tractor Serial No. _____

Engine Model _____ Engine Serial No. _____

Hours _____ Date _____

ENGINE:

- ☐ Engine Idle (Min. 850 RPM)
- ☐ Engine Hi-idle, no load (Approx. 2200 RPM)
- ☐ Throttle Linkage (Check setting)
- ☐ Throttle Lever (Adjust)
- ☐ Oil Pressure (Idle 15 PSI)
(2100 RPM 50-70 PSI)
- ☐ Fuel Pressure (Min. 30)
- ☐ Temp. Gauge (Max. setting 210)
- ☐ Fuel Lines (Check for leaks)
- ☐ Clutch Adjustment (Per Operators Manual)
- ☐ Fuel Filters (Replace)

TRANSMISSION:

- ☐ Leaks (Find cause)
- ☐ Filter (Check for leaks)
- ☐ Oil Level (Check sump)
- ☐ U-Joints (Check zerks)
- ☐ Drive Shafts (Check zerks)
- ☐ Flange Bolts (Tighten)

HYDRAULICS:

- ☐ Pump Operation - 1800 Steering Implement (2000 PSI)
- ☐ Control Valves (Check for leaks)
- ☐ Pump Couplers (Visual check)
- ☐ Pump Mount (Correct alignment)
- ☐ Steering Cylinders (Check for leaks)
- ☐ Return Filter (Replace)

ELECTRICAL SYSTEM:

- ☐ Battery Performance (Water level)
- ☐ Alternator Performance (Operational)
- ☐ AMP Gauge (Operational)
- ☐ Hour Meter (Operational)
- ☐ Lights & Wires (Operational)
- ☐ Fuel Gauge (Operational)

FRAME:

- ☐ Hinge Pins (Torque to 1200 Ft. Lbs.)

POWER DIVIDER:

- ☐ Oil Level (Check sump)
- ☐ Seal Leaks (Check)
- ☐ U-Joints (Check zerks)

BRAKES:

- ☐ Line Leaks (Check mounting clips)
- ☐ Fluid (Check level clips)

DIFFERENTIAL:

- ☐ Oil Level (Check)
- ☐ Axle Bolts (Torque)
- ☐ Dual Bolts (Torque to 200 Ft. Lbs.)
- ☐ Drive Line Joints (Check)

CUSTOMERS SIGNATURE

COMMENTS: _____



DELIVERY CHECK PANTHER II

Customer Name _____

Address _____

Dealer Name _____

Address _____ Date _____

Engine Serial No. _____ Tractor Serial No. _____

ENGINE:

- ☐ Engine Hi-idle, no load
(Approx. 2200 RPM)
- ☐ Engine Oil Level
- ☐ Belts
- ☐ Oil Pressure (Idle 15 PSI)
(2100 RPM 50-70 PSI)
- ☐ Engine Mounts
- ☐ Engine Temp. Gauge
- ☐ AMP Gauge
- ☐ Fuel Gauge
- ☐ Alternator
- ☐ Battery Performance
- ☐ Battery Cables
- ☐ Radiator Level
- ☐ Fuel Line Leaks
- ☐ Fuel Filter
- ☐ Oil Filter
- ☐ Fuel Tank
- ☐ Fuel Tank Cover
- ☐ Electric Wire System
- ☐ Engine Air Cleaner Elements
- ☐ Engine Air Cleaner Tube Clamps
- ☐ Engine Shut Down System
Operations

DROP BOX:

- ☐ Oil Level
- ☐ Flange Bolts
- ☐ U-Joints
- ☐ Mount Bolts
- ☐ Swing Box Mounts

CAB:

- ☐ Cab Appearance
- ☐ Vinyl Covering
- ☐ Window Glass
- ☐ Door Latches
- ☐ Weather Stripping
- ☐ Window Wipers
- ☐ Seat & Arm Rests
- ☐ Floorboard Mat
- ☐ Interior Lights
- ☐ Tach & Hour Meter
- ☐ Radio
- ☐ Throttle Linkage
- ☐ Throttle Lever

DIFFERENTIAL:

- ☐ Oil Level
- ☐ Oil Level Planet
- ☐ Axle Bolts
- ☐ Lug Bolts & Nuts
- ☐ Drive Line Joints
- ☐ Tire Pressure & Size

HYDRAULICS:

- ☐ Tank Level
- ☐ Oil Line Leaks
- ☐ Filters
- ☐ Control Valve
- ☐ Pump
- ☐ Steering Cylinders
- ☐ Quick Couplers
- ☐ Hose Connectors

TRANSMISSION:

- ☐ Leaks
- ☐ Oil Level
- ☐ Filter
- ☐ Flange Bolts
- ☐ Drive Shafts
- ☐ U-Joints
- ☐ Mounts
- ☐ Clutch Adjustment
- ☐ Transmission Pressure (5-20 PSI
hot oil)

BRAKES:

- ☐ Brake Fluid
- ☐ Brakes

THIS TRACTOR HAS BEEN DELIVERED TO ME IN GOOD CONDITION WITH AN OPERATOR'S MANUAL AND I HAVE BEEN INSTRUCTED IN THE FUNCTION SAFE OPERATION AND ADJUSTMENTS OF THE ITEMS LISTED ABOVE.

OWNER'S SIGNATURE _____

TRACTOR APPLICATION _____



Our support email:

ebooklibonline@outlook.com