

OPERATOR'S MANUAL

755A


TRACTOR-LOADER-BACKHOE

42075511



Reprint





L-17854

FOREWORD

This manual has been prepared to assist you in the proper break-in, daily care, and operation of your new Ford 755A Tractor-Loader-Backhoe. It contains specific information on its many features; the attachments that are available; instructions for making minor repairs and adjustments; safety precautions; general specifications; suggested operating techniques; and your Tractor Warranty.

Your Ford 755A has been carefully inspected before leaving the factory and also by your Ford Tractor-Equipment Dealer, prior to delivery, to see that it is "ready to go". To keep it in this "ready to go" condition, it is important to follow regularly scheduled service periods as recommended in this manual.

Any references to right, left, front or rear, when referring to the loader or tractor portions of the Ford 755A is as viewed from the operator's seat when the seat is facing forward for forward travel. When referring to the backhoe portion of the Ford 755A, all references to left and right are viewed from the operator's seat while facing rearward, which is normal for backhoe operation.

When ordering parts, whether they be for the tractor, loader, or backhoe portion of the Ford 755A, left and right is established as viewed from behind the entire unit.

The Ford 755A serial number is important should your unit require future service. Have your Dealer record this number, along with the other information called for in the spaces below.

Read this manual carefully before operating your Ford 755A and keep it in a convenient location for future reference. If, at any time, you have a service problem concerning your new Ford 755A, remember that your Ford Tractor-Equipment Dealer has factory trained service personnel, genuine Ford parts, and the necessary tools and equipment to best satisfy your service needs.

Do not modify or alter or permit anyone else to modify or alter this tractor or any of its components or any tractor function without first consulting a Ford Tractor Dealer. If you have any questions regarding tractor modifications contact the Ford Tractor Operations of Ford Motor Company.

Ford Tractor Operations

Ford Motor Company

ISSUED TO:

Owner's Name
Mailing Address
City
State

ISSUED BY:

Ford Tractor-Equipment Dealer
City
State
Delivery Date

Ford 755A Serial Number


DEAR CUSTOMER — PLEASE READ CAREFULLY

The warranty coverage that is extended to your Ford 755A is explained in the Warranty and Limitaton of Liability, Ford Tractor and Equipment form. Your dealer will provide you with a copy of the warranty and retain a copy which you have signed. After you read the warranty, ask your dealer to explain any points that you may not understand.

For a complete list of the pre-delivery service checks performed by your dealer, refer to PRE-DELIVERY SERVICE on the upper portion of pages 91 and 93. The copy on page 91 is your record of the service performed, and the copy on page 93 which is to be removed from the manual, is your dealer's record. **MAKE SURE THAT YOU AND THE DEALER SIGN BOTH COPIES.**

After you have operated your tractor for fifty hours, take the manual and your tractor to your dealer. He will then perform the factory recommended 50-HOUR SERVICE as listed on the lower portion of pages 91 and 93 — without charge — except for lubricants, hydraulic oil, or filters replaced as part of normal maintenance. **MAKE SURE THAT YOU AND THE DEALER SIGN BOTH COPIES.**

A vehicle identification plate is located on the inside of the right hood panel. The numbers on the plate are important should your tractor-loader require future service. For your convenience, have your dealer record the numbers in the appropriate space below.



TRACTOR NUMBER

MODEL

UNIT

ENGINE

TRANSMISSION

REAR AXLE

HYDRAULIC PUMP

HYDRAULIC LIFT

CONTENTS

	Page
Safety precautions	4
Controls and instruments	7
general	8
brake and rear axle controls	14
transmission controls	15
loader controls	17
backhoe controls	17
Operation	23
break-in procedures	24
starting the engine	24
weighting limitations	29
loader operation	31
backhoe operation	37
loader and backhoe attachments	47
Lubrication and maintenance	53
lubrication and maintenance chart	54
fuels and lubricants	55
fuel and lubricant service procedures	57
general maintenance	67
hydraulic hoses and tubing	79
storing the Ford 755A	80
Specifications	83
decals	88
pre-delivery and 50-hour service	91

SAFETY PRECAUTIONS

The following precautions are suggested to help prevent accidents

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions. Read and take the following precautions before operating this tractor to help prevent accidents. Equipment should be operated only by those who are responsible and instructed to do so.

THE TRACTOR

1. Read the Operator's Manual carefully before using the tractor. Lack of operating knowledge can lead to accidents.
2. Use an approved roll bar and seat belt for safe operation. Overturning a tractor without a roll bar can result in death or injury. If your tractor is not equipped with a roll bar and seat belt, see your Ford Tractor Equipment Dealer.
3. Always use the seat belt when the roll bar is installed. Do not use the seat belt if the roll bar is removed from the tractor.
4. If a front end loader is to be installed, always use a FOPS canopy to avoid injury from falling objects.
5. Use the handholds and step plates when getting on and off the tractor to prevent falls. Keep steps and platform cleared of mud and debris.
6. Do not permit anyone but the operator to ride on the tractor. There is no safe place for extra riders.
7. Replace all missing, illegible or damaged safety decals. See list of decals on Pages 88 and 89.
8. Keep safety decals clean of dirt and grime.

SERVICING THE TRACTOR

1. Cooling system operates under pressure which is controlled by the radiator cap. It is dangerous to remove the cap while system is hot. Always turn cap slowly to the first stop and allow pressure to escape before removing the cap entirely.
2. Do not smoke while refueling the tractor. Keep any type of open flame away. Wait for engine to cool before refueling.
3. Keep the tractor in good operating condition for your safety. An improperly maintained tractor can be hazardous.
4. Keep open flame away from battery or cold weather starting aids to prevent fires or explosions.
5. Stop the engine before performing any service on the tractor.
6. Do not modify or alter or permit anyone else to modify or alter this tractor or any of its components or any tractor function without first consulting a Ford Tractor Equipment Dealer.

OPERATING THE TRACTOR

1. Apply the parking brake, and place the transmission in neutral before starting the tractor.
2. Do not start the engine or operate controls while standing beside the tractor. Always sit in the tractor seat when starting the engine or operating controls.
3. Do not bypass the starter safety switch. Consult your Ford Tractor-Equipment Dealer if your starter safety controls malfunction. Use jumper cables only in the recommended manner, improper use can result in tractor runaway.
4. Do not get off the tractor while it is in motion.

5. Shut off the engine and apply the parking brake before getting off the tractor.
6. Always apply the parking brake and remove the starter key when leaving the unit parked or unattended.
7. Never leave the unit when it is parked on an incline. Always park the unit on level ground where possible. If the unit is to be parked on an incline, always lower the buckets so that the cutting lips contact the ground, apply the parking brake, and securely block the wheels.
8. Do not operate the tractor engine in an enclosed building without adequate ventilation. Exhaust fumes can suffocate you.
9. If power steering or engine ceases operating, stop the tractor immediately.

DRIVING THE TRACTOR

1. Watch where you are going especially at row ends, on roads, around trees and low hanging obstacles.
2. To avoid upsets drive the tractor with care and at speeds compatible with safety, especially when operating over rough ground, when crossing ditches or slopes, and when turning corners.
3. Lock tractor brake pedals together when transporting on roads to provide two wheel braking.
4. Keep the tractor in the same gear when going downhill as used when going uphill. Do not coast or free wheel down hill.
5. Any towed vehicle whose total weight exceeds that of the towing tractor must be equipped with brakes for safe operation.
6. When the tractor is stuck or tires are frozen to the ground, back out to prevent upset.
7. Always check overhead clearance especially when transporting the tractor.

LOADER/BACKHOE OPERATION

1. Always be sure of water, gas, sewage and electrical line locations before you start to dig.
2. Watch out for overhead and underground high-voltage electrical lines when operating the loader or backhoe.
3. Operate the loader or backhoe controls only when properly seated at the controls.
4. Never attempt to lift loads in excess of loader or backhoe capacity.
5. Always lower the loader and backhoe buckets to the ground, shut off the engine and apply the parking brake before getting off the unit.
6. Always be watchful of bystanders when operating the loader, when lowering the stabilizers, or when operating the backhoe.

SAFETY PRECAUTIONS (Continued)

7. Use care when operating on steep grades to maintain proper stability. Always carry the bucket as low as possible.
8. Never attach chains, ropes, cables, etc., to the loader or backhoe for pulling purposes.

LOADER OPERATION

1. Do not transport anyone in the loader bucket.
2. Always carry the loader bucket low for maximum stability and visibility, whether the bucket is loaded or empty.
3. Always use the recommended amount of counterweighting to ensure good stability.
4. Be careful when handling round objects such as round bales, poles, etc. Lifting too high or rolling bucket too far back could result in these objects rolling rearward down the loader arms on the operator.
5. Never allow anyone to get under the loader bucket or reach through the lift arms when the bucket is raised.
6. Exercise caution when operating the loader with a raised loaded bucket or fork.

BACKHOE OPERATION

1. Never allow anyone to get under the backhoe bucket when the bucket is raised.
2. To prevent upsets, avoid full reach and swinging the backhoe bucket to the downhill side when operating on a slope.
3. Watch out for overhead and underground high-voltage electrical lines when operating the backhoe.
4. Do not enter the platform from the rear.
5. Always attach the backhoe transport chains before transporting the Ford 755A.
6. Always place the torque converter shuttle lever in neutral before operating backhoe.

MAINTENANCE

1. Never make repairs or tighten hydraulic hoses or fittings when the system is under pressure, when the engine is running, or when the loader or backhoe cylinders are under a load.
2. Always keep the brakes and power steering system in good operating condition.

3. Do not lubricate or make mechanical adjustments while the unit is in motion or when the engine is running. However, if minor engine adjustments must be made, apply the parking brake, securely block the wheels, and use extreme caution. Be certain that the loader is fully lowered or supported so that it cannot fall.

4. For safe operation, observe proper maintenance and repair of all pivot pins, hydraulic cylinders, hoses, snap rings, and main attaching bolts prior to each day's operation.
5. Always wear safety goggles when servicing or repairing the machine.
6. When necessary to tow the Ford 755A, do not exceed 5 mph (8.0 kph). Avoid towing the Ford 755A over long distances.
7. Adequately block up the backhoe or loader when they are detached from the tractor.
8. Whenever servicing or replacing pins in cylinder ends, buckets, etc., always use a brass drift and a hammer. Failure to do so could result in injury from flying metal fragments.

DIESEL FUEL

1. Under not circumstances should gasoline, alcohol or blended fuels be added to diesel fuel. These combinations can create an increased fire or explosive hazard. Such blends are more explosive than pure gasoline in a closed container such as a fuel tank. **Do not use these blends.**
2. Never remove the fuel cap or refuel the tractor with the engine running or hot.
3. Do not smoke while refueling or when standing near fuel.
4. Maintain control of the fuel filter pipe nozzle when filling the tank.
5. Do not fill the fuel tank to capacity. Allow room for expansion.
6. Wipe up spilled fuel immediately.
7. Always tighten the fuel tank cap securely.
8. If the original fuel tank cap is lost replace it with a Ford approved cap. A non-approved, proprietary cap may not be safe.
9. Keep equipment clean and properly maintained.
10. Do not drive equipment near open fires.
11. Never use fuel for cleaning purposes.
12. Arrange fuel purchases so that winter grade fuels are not held over and used in the spring.

Whenever you see this symbol



it means:

ATTENTION!

BECOME ALERT!

YOUR SAFETY IS INVOLVED!

UNIVERSAL SYMBOLS

As a guide to the operation of your tractor, various universal symbols have been utilized on the instruments and controls. The symbols are shown below with an indication of their meaning.



Engine Speed (rev/min x 100)



Alternator charge



Engine water temperature



Heater temperature control



Fuel level



Air conditioner temperature control



Fuel cut-off



Fan



Lights



Wipe/Wash control



Horn



'Tortoise', slow or minimum setting



Engine oil pressure



'Hare', fast or maximum setting



Air filter



Caution



Transmission oil temperature



Pressurized. Open Slowly.

CONTROLS and INSTRUMENTS

The controls on your new Ford 755A are designed for efficient operation and are located within comfortable reach of the operator, thereby reducing operation fatigue.

All instruments are centrally located so that you can tell at a glance whether the unit is operating properly. The instruments also warn you of possible trouble before it becomes serious.

Before attempting to start or operate your new Ford 755A, familiarize yourself with the location and function of all controls and instruments as described on the following pages.



**Know your controls and instruments
to assure Safe Operation.**



— CONTROLS AND INSTRUMENTS —

GENERAL

OPERATOR'S SEAT

Your new Ford 755A is equipped with a "turnabout" type seat, Figure 1. It can be adjusted forward or rearward a maximum of seven inches (17.8 cm) by moving the seat release lever. The height can also be changed two inches (5.0 cm) to suit the operator by loosening the height adjustment knob.



Figure 1
Operator's Seat

1. Fore and Aft Adjustment Lever
2. Adjustment Knob

Once the seat is adjusted for operator comfort, in the loader operating position, it can be turned to the backhoe position by releasing the seat release lever. See Figures 2 and 3. Once the seat is adjusted for loader operation it will usually suit the operator for backhoe operation without additional adjustments.



Figure 2
Operator's Seat—Traveling and Loader Position
1. Swing Around Seat Release Lever



Figure 3
Operator's Seat—Backhoe Position

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.
You can download the most
perfect and complete manual in
the world immediately.

Our support email:
ebooklibonline@outlook.com