

Magnum™ 250
Magnum™ 280
Magnum™ 310
Magnum™ 340
Magnum™ 380
Magnum™ 310 Rowtrac™
Magnum™ 340 Rowtrac™
Magnum™ 380 Rowtrac™
Tractor

PIN ZERF08100 and above

OPERATOR'S MANUAL

Part number 47824517

3rd edition English

March 2015

Replaces part number 47787634



Contents

NOTE: The Operator's Manual consists of two volumes. The first volume contains operating information, the second volume the maintenance and diagnostic information.

1 GENERAL INFORMATION

Note to the owner.....	1-1
Engine tampering.....	1-2
Tractor intended use.....	1-2
Electro-magnetic compatibility (EMC).....	1-2
ISOBUS certification.....	1-3
Product identification.....	1-4
Manual storage.....	1-7
Machine orientation.....	1-8
Component identification.....	1-9

2 SAFETY INFORMATION

Safety rules and signal word definitions.....	2-1
Safety rules - General.....	2-2
Safety rules - General maintenance safety.....	2-4
Safety rules - Wheels and tires.....	2-4
Safety rules - Driving on public roads and general transportation safety.....	2-4
Safety rules - Fire and explosion prevention.....	2-5
Safety rules - General battery safety.....	2-5
Safety rules - Hydraulic system safety.....	2-6
Safety rules - Instructional seat safety.....	2-6
Safety rules - Operator presence system.....	2-7
Safety rules - Power Take-Off (PTO).....	2-7
Safety rules - Reflectors and warning lights.....	2-7
Safety rules - Seat belts.....	2-7
Safety rules - Roll Over Protective Structure (ROPS).....	2-7
Safety rules - Cab protection.....	2-9
Safety rules - Air conditioning system.....	2-9
Safety rules - Personal Protective Equipment (PPE).....	2-9
Safety rules - Do Not Operate tag.....	2-9
Safety rules - Hazardous chemicals.....	2-9
Safety rules - Utility safety.....	2-10
Safety rules - Electrical storm safety.....	2-10
Safety rules - Mounting and dismounting.....	2-10
Safety rules - Working at heights.....	2-11
Safety rules - Lifting and overhead loads.....	2-11
Safety rules - Implements, tools and trailers.....	2-11
Safety rules - Roll over and tip over.....	2-12
Ecology and the environment.....	2-13
Safety signs.....	2-14

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Tractor access	3-1
Lower step	3-3

OPERATOR'S SEAT

Control identification	3-4
------------------------------	-----

INSTRUCTOR'S SEAT

Overview	3-8
----------------	-----

FORWARD CONTROLS

Steering column	3-9
Front console	3-12
Pedal controls	3-14

LEFT-HAND SIDE CONTROLS

Emergency brake lever	3-16
Pneumatic trailer brake	3-16

RIGHT-HAND SIDE CONTROLS

Armrest console	3-17
Multi function handle	3-18
Minimum/maximum RPM throttles	3-23
Control panel	3-25
Remote valve controls	3-35
Joystick	3-36
Armrest compartment	3-38
Adjusting the armrest console	3-40

REARWARD CONTROLS

Fender console	3-41
Automatic temperature controls	3-44
Automatic temperature control system	3-47
Ventilation	3-48

OVERHEAD CONTROLS

Interior lamps	3-50
----------------------	------

EXTERIOR CONTROLS

Rear fender	3-51
Front hitch	3-53

INSTRUMENT CLUSTER

Overview	3-54
Gauges	3-55
Status and warning icons	3-56

Upper display	3-59
Lower display	3-62
Keypad	3-64
Setup menu	3-66
Rear tire radius chart	3-72
Adjust menu	3-73
Performance features	3-81

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Engine - Safety rules	4-1
-----------------------------	-----

STARTING THE UNIT

Normal engine starting	4-4
Cold starting aids	4-8
Cold temperature operation	4-10

STOPPING THE UNIT

Stopping the engine	4-12
---------------------------	------

MOVING THE UNIT

FULL POWERSHIFT TRANSMISSION	4-14
Powershift transmission	4-14
Best practices for prolonged transmission life	4-15
Inching pedal and throttle	4-16
Powershift transmission controls	4-17
Upper display - Powershift transmission	4-20
Driving the Powershift vehicle	4-22
Setting default gears	4-27
Automatic Productivity Management (APM)	4-29
CONTINUOUSLY VARIABLE TRANSMISSION (CVT)	4-37
Continuously Variable Transmission (CVT) brake, pedal and throttle operation	4-37
Continuously Variable Transmission (CVT) controls	4-42
Upper display	4-47
Continuously Variable Transmission (CVT) operation	4-48
Driving the Continuously Variable Transmission (CVT)	4-51
Transmission messages	4-56
POWERSHIFT AND CVT TRANSMISSIONS	4-58
Mechanical Front Drive (MFD)	4-58
Differential lock system	4-61
Suspended axle	4-63
Ride control	4-68
Engine power boost	4-70
Constant engine speed	4-71
Suspended cab	4-74
Electronic end of row system	4-75

PARKING THE UNIT

Automatic park lock.....	4-81
--------------------------	------

5 TRANSPORT OPERATIONS

ROAD TRANSPORT

Tractor warning lamps and Slow Moving Vehicle (SMV) symbol.....	5-1
Wide transport marker light.....	5-2
Tractor warning lamps.....	5-4
Safe transport speed	5-5
Implement warning lamps and Slow Moving Vehicle (SMV) symbol	5-6
Safety chain	5-7

SHIPPING TRANSPORT

Securing the tractor for shipping	5-8
---	-----

RECOVERY TRANSPORT

Safety rules.....	5-9
Towing the tractor.....	5-10

6 WORKING OPERATIONS

GENERAL INFORMATION

Overview	6-1
----------------	-----

REAR POWER TAKE-OFF (PTO)

Safety rules.....	6-2
Connecting the Power Take-Off (PTO)	6-5
Interchangeable Power Take-Off (PTO) shaft	6-6
Rear Power Take-Off (PTO) operation	6-12
Power Take-Off (PTO) fender switch operation	6-16
Auto Power Take-Off (PTO) operation.....	6-17

FRONT POWER TAKE-OFF (PTO)

Overview	6-20
Front Power Take-Off (PTO) operation.....	6-21

REAR HITCH

Identification	6-24
Link adjustment.....	6-25
Hitch high clearance adjustment	6-29
Hydraulic links	6-32
Sway limiter adjustment	6-34
Lower link block adjustment	6-35
Mechanical float adjustment.....	6-37
Hitch quick coupler - Category III/IIIN	6-38
Hitch quick coupler - Category IVN.....	6-43

Hitch operation	6-47
Hitch remote switch operation	6-52
Position control operation	6-53
Load control operation	6-55
Slip control operation	6-57
Hitch set point	6-59

FRONT HITCH

Overview	6-61
Front hitch operation	6-62

DRAWBARS AND TOWING ATTACHMENTS

Safety rules	6-69
Drawbar capacity/position	6-70
Adjusting the drawbar	6-74

TRAILER BRAKING SYSTEMS

Safety rules	6-76
Trailer brake connections	6-77
Air pressure monitoring	6-78

AUXILIARY CONNECTIONS

Auxiliary power and lighting	6-79
Cab power connections	6-81
Radar connection	6-82
Implement ISOBUS connector	6-83

HYDRAULIC REMOTE CONTROL VALVES

Valve couplers and connections	6-84
Motor return circuit	6-88
Power beyond circuit	6-89
Flow capacity	6-90
Hydraulic transport lock	6-91
Operating the controls	6-92
Remote valve display screens	6-96
Remote hydraulic auto mode	6-99
Auto depth control	6-102
Joystick operation	6-104

BALLASTING THE TRACTOR

Guidelines	6-109
Tire load and inflation charts	6-120
Weights, cast metal	6-134
Wheel slip and power hop performance	6-145

MECHANICAL FRONT DRIVE (MFD) AXLES

Front axle identification	6-148
Tire combinations and tread positions	6-149
Steering and oscillation stops	6-156
Tread and fender settings - Class 4.75 and 5.0 fixed front axles	6-158
Tread and fender settings - Class 4.75 and 5.0 saddle suspended front axles ..	6-168
Tread and fender settings - Class 5.0 wide front axles	6-177
Front wheel fenders	6-179
Front wheel fenders - Class 4.75 and 5.0 fixed and suspended axles	6-180
Front wheel fenders - Class 5.0 wide fixed and suspended axles	6-185

REAR AXLE

Rear wheel installation	6-190
Rear wheel tread settings	6-194
Dual/triple wheel setup for 508 mm (20 in)/559 mm (22 in) row spacing	6-202
Adjustable rear wheel	6-209

REAR TRACKS

Tire load and inflation charts - - Tractors with rear tracks	6-211
Maximum front ballast recommendations	6-213
Front wheel tread settings	6-214
Track preconditioning	6-219

7 MAINTENANCE

GENERAL INFORMATION

Safety rules	7-1
Maintenance guidelines	7-2
Opening the hood	7-3
Closing the hood	7-4
Filling the fuel tank	7-5
Battery disconnect switch	7-7
Battery access and service	7-8
Tire and rim service	7-9
Tractor jacking points	7-11
Capacities	7-13
Consumables - Engine oil	7-14
Consumables - Transmission/hydraulic system fluid	7-15
Consumables - Diesel fuel	7-16
Consumables - Organic Acid Technology (OAT) coolant	7-17
Electrical component location	7-19
Lamps and bulbs	7-25
Maintenance chart notes	7-25
Maintenance summary decal	7-26

MAINTENANCE CHART

Maintenance chart	7-27
-------------------------	------

At warning message display

Air filter service icon/message*	7-29
Water in fuel message	7-32
Transmission oil filter switch	7-34
Hydraulic oil filter switch	7-37

First 10 to 50 hours

Wheel bolt torque	7-40
Weight bolt torque	7-41
Differential and planetary oil	7-42

Every 10 hours or daily

Engine oil level	7-43
Transmission oil level	7-44
Engine coolant level	7-45
Air reservoir	7-45
Rear hitch and front axle	7-45

Every 50 hours or weekly

Engine auxiliary fuel filter	7-46
------------------------------------	------

First 100 hours

Powershift transmission clutch calibration	7-48
--	------

Every 100 hours

Front hitch	7-54
Front Power Take-Off (PTO) drive shaft	7-56

Every 200 hours

Track alignment	7-57
-----------------------	------

Every 300 hours

Battery water level (Note B)	7-58
Engine air intake and exhaust hoses	7-60
Engine coolant level - deaeration tank	7-62
Weight bolt torque	7-63
Front axle (Note A)	7-64
Rear hitch (Note A)	7-66
Fuel tank	7-68
Differential and planetary oil level (Note B)	7-69
Transmission oil pressure	7-70
Front Power Take-Off (PTO) oil level	7-71

Every 400 hours

Cab air filter*	7-72
-----------------------	------

Every 600 hours

Engine oil and filter*	7-75
Engine coolant antifreeze protection	7-78
Engine coolant hoses and clamps	7-78
Engine fuel filter*	7-80
Engine auxiliary fuel filter*	7-83
Fuel system bleeding	7-85
Changeable Power Take-Off (PTO) internal splines	7-86
Front Power Take-Off (PTO) oil and filter*	7-87
Engine air precleaner*	7-89

Every 1000 hours or annually

Pneumatic brake system dryer	7-90
Powershift transmission clutch calibration	7-91

Every 1200 hours or annually

Differential and planetary oil	7-97
Engine air filters*	7-101

Every 1500 hours

Transmission oil	7-104
Hydraulic oil filter*	7-107
Transmission oil filter*	7-108
Idler/roller wheel oil	7-109
Engine crankcase filter*	7-110

Every 3000 hours

Engine valve adjustment (Note C)	7-114
--	-------

Every 4000 hours or every four years

Engine coolant	7-115
----------------------	-------

As required

Vehicle fire prevention	7-118
Track inspection and bolt torque	7-119
Track rotation	7-119
Track drive wheel and idler bolt torque	7-119
Track tension release	7-120
Track alignment	7-122
Cab air filter*	7-124
Grille screen and radiator area	7-127
Fuel tank vent filter	7-128

Transmission clutch and accumulator	7-128
Tire pressure	7-129
Fan belt	7-130
Remote valve collection bottle	7-136
Remote valve couplers	7-137
Cab fabric and carpet	7-138
Seat belt	7-138

STORAGE

Preparing for storage	7-139
Removal from storage	7-140

ELECTRICAL SYSTEM

Radio or audio system	7-141
Battery removal and installation	7-142
Auxiliary battery connections	7-144
Headlight	7-145
Flood and work light	7-146
Fender tail light and warning light	7-146
Roof front warning and work light	7-147
Roof rear warning light	7-148
Side turn indicator light	7-149
Rotating beacon light	7-150
Interior light	7-151

8 TROUBLESHOOTING

ALARM(S)

Display warnings overview	8-1
Display warnings - Level 1	8-2
Display warnings - Level 2	8-4
Display warnings - Level 3	8-7
Display warnings - Level 4	8-9

SYMPTOM(S)

Engine symptoms	8-11
Transmission symptoms	8-13
Hydraulic symptoms	8-14
Hitch symptoms	8-15
Brake symptoms	8-16
Cab environment symptoms	8-16
Electrical power system symptoms	8-17

9 SPECIFICATIONS

Engine specifications	9-1
Power train specifications	9-2
Operating speeds	9-6
Operating speeds - Rowtrac™ tractors	9-7
Vehicle dimensions and shipping weight	9-11

Vehicle dimensions and shipping weight - Rowtrac™ tractors	9-18
Maximum operating weight.....	9-20

10 ACCESSORIES

Farming system displays	10-1
Rear view mirrors.....	10-2
Chemical tank mounting.....	10-4
Loader connection and operation	10-6
General accessories.....	10-7

1 - GENERAL INFORMATION

Note to the owner

This manual contains important information about the safe operation, adjustment and routine maintenance of your Magnum or Magnum Rowtrac™ series tractor. The manual is divided into 10 chapters as outlined in the table of contents. Refer to the index at the end of this manual for locating specific items about your tractor.


Do NOT operate or permit anyone to operate or service this machine until you or the other persons have read this manual. Use only trained operators who have demonstrated the ability to operate and service this machine correctly and safely.

Tractors equipped with rear tracks

On Rowtrac models, refer to the information starting on page 9-7 for transport speed weight limitations.

This Operator's Manual is to be stored in the manual compartment behind the operator's seat in the vehicle. Make sure this manual is in good condition. Contact your dealer to obtain additional manuals.

Your CASE IH dealer will instruct you in the general operation of your new equipment. Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your machine. They will also provide any after-sales service you may need, and genuine CASE IH parts, your guarantee of quality and match.



RAIL14TR03870BA 1

Engine tampering

The fuel system and engine on your machine are designed and built to government emissions standards. Tampering by dealers, customers, operators, and users is strictly prohibited by law.

Failure to comply could result in government fines, rework charges, invalid warranty, legal action, and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!

Tractor intended use

Magnum or Magnum Rowtrac™ series tractors with standard equipment and authorized attachments, are intended to be used for customary farming, land leveling and related agriculture operations (intended use). Installation of utility (dozer) blades, tile plows, or push bars on the tractor is not recommended. Any tractor damage resulting from the installation and/or use of such equipment is not covered by the tractor warranty.

Consult an authorized dealer or CNH Industrial America LLC on changes, additions or modifications that can be required for this machine to comply with various regulations and safety requirements. Unauthorized modifications will cause serious injury or death. Anyone making such unauthorized modifications is responsible for the consequences.

The tractor is not designed for light/heavy forestry applications; usage is prohibited for forestry applications.

Do not use this machine for any purpose or in any manner other than as described in the manual, decals, or other product safety information provided with the machine. These materials define the machine's intended use.

Use in any other way is considered as contrary to the intended use. The manufacture accepts no liability for any damage or injury resulting from this misuse and these risks must be born solely by the user.

Electro-magnetic compatibility (EMC)

Interference may arise as a result of add-on equipment that may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the machine
- The electro-magnetic field generated by the add-on system should not exceed **24 V/m** at any time and at any location in the proximity of electronic components
- The add-on equipment must not interfere with the functioning of the on board electronics

Failure to comply with these rules will render the CASE IH warranty null and void.



Our support email:

ebooklibonline@outlook.com