

ORIGINAL INSTRUCTIONS

# OPERATOR'S MANUAL

---

**T8.320**

**T8.350**

**T8.380**

**T8.410**

**T8.435**

**T8.380 SmartTrax™**

**T8.410 SmartTrax™**

**T8.435 SmartTrax™**

Tractor

*PIN ZFRE05001 and above*

**Part number 47886362**

1<sup>st</sup> edition English

August 2015



# Contents

---

**NOTE:** The Operator's Manual consists of two volumes. The first volume contains operating information, the second volume the maintenance and diagnostic information.

## 1 GENERAL INFORMATION

Note to the owner.....	1-1
Engine tampering.....	1-2
Tractor intended use.....	1-2
Electro-magnetic compatibility (EMC).....	1-3
ISOBUS certification.....	1-4
Product identification.....	1-5
Manual storage.....	1-8
Machine orientation.....	1-9
Component identification.....	1-10
Selective Catalytic Reduction (SCR) system.....	1-16

## 2 SAFETY INFORMATION

Safety rules and signal word definitions.....	2-1
Safety rules - General.....	2-2
Safety rules - General maintenance safety.....	2-4
Safety rules - Wheels and tires.....	2-4
Safety rules - Driving on public roads and general transportation safety.....	2-4
Safety rules - Fire and explosion prevention.....	2-5
Safety rules - General battery safety.....	2-5
Safety rules - Hydraulic system safety.....	2-6
Safety rules - Instructional seat safety.....	2-6
Safety rules - Operator presence system.....	2-7
Safety rules - Power Take-Off (PTO).....	2-7
Safety rules - Reflectors and warning lights.....	2-7
Safety rules - Seat belts.....	2-7
Safety rules - Roll Over Protective Structure (ROPS).....	2-8
Safety rules - Cab protection.....	2-9
Safety rules - Air conditioning system.....	2-9
Safety rules - Personal Protective Equipment (PPE).....	2-9
Safety rules - Do Not Operate tag.....	2-9
Safety rules - Hazardous chemicals.....	2-10
Safety rules - Utility safety.....	2-10
Safety rules - Electrical storm safety.....	2-10
Safety rules - Mounting and dismounting.....	2-10
Safety rules - Working at heights.....	2-11
Safety rules - Lifting and overhead loads.....	2-11
Safety rules - Implements, tools and trailers.....	2-11
Safety rules - Roll over and tip over.....	2-12
Proposition 65.....	2-13
Ecology and the environment.....	2-14
Safety signs.....	2-15
Selective Catalytic Reduction (SCR) exhaust treatment - Safety signs.....	2-25

---

### 3 CONTROLS AND INSTRUMENTS

#### ACCESS TO OPERATOR'S PLATFORM

Tractor access .....	3-1
Lower step .....	3-3

#### OPERATOR'S SEAT

Control identification .....	3-4
------------------------------	-----

#### INSTRUCTOR'S SEAT

Overview .....	3-8
----------------	-----

#### FORWARD CONTROLS

Steering column .....	3-9
Front console .....	3-12
Pedal controls .....	3-14

#### LEFT-HAND SIDE CONTROLS

Pneumatic trailer brake .....	3-16
-------------------------------	------

#### RIGHT-HAND SIDE CONTROLS

Armrest console .....	3-17
Multi function handle .....	3-19
Engine speed control .....	3-24
Control panel .....	3-25
Remote valve controls .....	3-32
Joystick .....	3-33
Rear hitch controls .....	3-35
Armrest compartment .....	3-37
Adjusting the armrest console .....	3-39

#### REARWARD CONTROLS

Fender console .....	3-40
Automatic temperature controls .....	3-43
Automatic temperature control system .....	3-46
Ventilation .....	3-47

#### OVERHEAD CONTROLS

Interior lamps .....	3-49
----------------------	------

#### EXTERIOR CONTROLS

Rear fender .....	3-50
Front hitch .....	3-52

#### INSTRUMENT CLUSTER

Overview .....	3-53
Gauges .....	3-54

---

Status and warning icons .....	3-55
Upper display .....	3-58
Lower display .....	3-62
Keypad .....	3-64
Setup menu .....	3-66
Rear tire radius and track radius charts .....	3-72
Adjust menu .....	3-73
Performance features .....	3-81

## 4 OPERATING INSTRUCTIONS

### COMMISSIONING THE UNIT

Engine - Safety rules .....	4-1
-----------------------------	-----

### STARTING THE UNIT

Normal engine starting .....	4-4
Cold starting aids .....	4-8
Cold temperature operation .....	4-10

### STOPPING THE UNIT

Stopping the engine .....	4-12
---------------------------	------

### MOVING THE UNIT

FULL POWERSHIFT TRANSMISSION .....	4-14
Powershift transmission .....	4-14
Best practices for prolonged transmission life .....	4-15
Inching pedal and throttle .....	4-16
Powershift transmission controls .....	4-17
Upper display - Powershift transmission .....	4-20
Driving the Powershift vehicle .....	4-22
Setting default gears .....	4-27
Ground Speed Management (GSM) .....	4-29
CONTINUOUSLY VARIABLE TRANSMISSION (CVT) .....	4-37
Continuously Variable Transmission (CVT) brake, pedal and throttle operation .....	4-37
Auto Command brake, pedal and throttle operation .....	4-41
Continuously Variable Transmission (CVT) controls .....	4-47
Auto Command controls .....	4-51
Upper display .....	4-56
Continuously Variable Transmission (CVT) operation .....	4-57
Auto Command operation .....	4-59
Driving the Auto Command transmission .....	4-65
Transmission messages .....	4-70
POWERSHIFT AND CVT TRANSMISSIONS .....	4-72
Selective Catalytic Reduction (SCR) system .....	4-72
Engine idling or full catalyst messages .....	4-82
Mechanical Front Drive (MFD) .....	4-83
Differential lock system .....	4-86
Suspended axle .....	4-88
Ride control .....	4-93

---

Engine power boost .....	4-95
Constant engine speed .....	4-96
Suspended cab .....	4-99
Headland management system .....	4-100

## PARKING THE UNIT

Automatic park lock .....	4-106
---------------------------	-------

## 5 TRANSPORT OPERATIONS

### ROAD TRANSPORT

Tractor warning lamps and Slow Moving Vehicle (SMV) symbol .....	5-1
Wide transport marker light .....	5-2
Tractor warning lamps .....	5-4
Safe transport speed .....	5-5
Implement warning lamps and Slow Moving Vehicle (SMV) symbol .....	5-6
Safety chain .....	5-7

### SHIPPING TRANSPORT

Securing the tractor for shipping .....	5-8
---	-----

### RECOVERY TRANSPORT

Safety rules .....	5-9
Towing the tractor .....	5-10

## 6 WORKING OPERATIONS

### GENERAL INFORMATION

Overview .....	6-1
----------------	-----

### REAR POWER TAKE-OFF (PTO)

Safety rules .....	6-2
Connecting the Power Take-Off (PTO) .....	6-5
Interchangeable Power Take-Off (PTO) shaft .....	6-6
Rear Power Take-Off (PTO) operation .....	6-12
Power Take-Off (PTO) fender switch operation .....	6-16
Auto Power Take-Off (PTO) operation .....	6-17

### FRONT POWER TAKE-OFF (PTO)

Overview .....	6-20
Front Power Take-Off (PTO) operation .....	6-21

### REAR HITCH

Identification .....	6-24
Link adjustment .....	6-25
Hitch high clearance adjustment .....	6-29
Hydraulic links .....	6-32

---

Sway limiter adjustment .....	6-34
Lower link block adjustment .....	6-35
Mechanical float adjustment .....	6-37
Hitch quick coupler - Category III/IIIN .....	6-38
Hitch quick coupler - Category IVN .....	6-43
Hitch operation .....	6-47
Hitch remote switch operation .....	6-52
Position control operation .....	6-53
Load control operation .....	6-55
Slip control operation .....	6-57
Hitch set point .....	6-59

## FRONT HITCH

Overview .....	6-61
Front hitch operation .....	6-61

## DRAWBARS AND TOWING ATTACHMENTS

Safety rules .....	6-68
Drawbar capacity/position .....	6-69
Adjusting the drawbar .....	6-73

## TRAILER BRAKING SYSTEMS

Safety rules .....	6-75
Trailer brake connections .....	6-76
Air pressure monitoring .....	6-77

## AUXILIARY CONNECTIONS

Auxiliary power and lighting .....	6-78
Cab power connections .....	6-80
Radar connection .....	6-81
Implement ISOBUS connector .....	6-82

## HYDRAULIC REMOTE CONTROL VALVES

Valve couplers and connections .....	6-83
Motor return circuit .....	6-87
Power beyond circuit .....	6-88
Flow capacity .....	6-89
Hydraulic transport lock .....	6-90
Operating the controls .....	6-91
Remote valve display screens .....	6-95
Remote hydraulic auto mode .....	6-98
Auto depth control .....	6-101
Joystick operation .....	6-103

## BALLASTING THE TRACTOR

Guidelines .....	6-107
Tire load and inflation charts .....	6-118

---

Weights, cast metal.....	6-132
Wheel slip and power hop performance .....	6-146

## MECHANICAL FRONT DRIVE (MFD) AXLES

Front axle identification.....	6-149
Tire combinations and tread positions.....	6-150
Steering and oscillation stops .....	6-158
Tread and fender settings - Class 4.75 and 5.0 fixed front axles.....	6-160
Tread and fender settings - Class 4.75 and 5.0 saddle suspended front axles ..	6-168
Tread and fender settings - Class 5.0 wide front axles.....	6-175
Front wheel fenders .....	6-177
Front wheel fenders - Class 4.75 and 5.0 fixed and suspended axles .....	6-178
Front wheel fenders - Class 5.0 wide fixed and suspended axles .....	6-183

## REAR AXLE

Rear wheel installation .....	6-188
Rear wheel tread settings .....	6-192
Dual/triple wheel setup for 508 mm (20 in)/559 mm (22 in) row spacing.....	6-200
Adjustable rear wheel .....	6-207

## REAR TRACKS

Tire load and inflation charts - - Tractors with rear tracks .....	6-209
Maximum front ballast recommendations .....	6-211
Front wheel tread settings.....	6-212
Track preconditioning.....	6-217
Factory and field track settings .....	6-219

## 7 MAINTENANCE

### GENERAL INFORMATION

Safety rules.....	7-1
Dealer service and parts .....	7-2
Maintenance guidelines .....	7-2
Opening the hood .....	7-3
Closing the hood .....	7-5
Filling the fuel tank .....	7-6
Filling the Diesel Exhaust Fluid (DEF)/AdBlue® tank .....	7-8
Battery disconnect switch .....	7-10
Battery access and service.....	7-11
Tire and rim service.....	7-12
Tractor jacking points.....	7-14
Capacities .....	7-16
Consumables - Engine oil .....	7-17
Consumables - Transmission/hydraulic system fluid .....	7-18
Consumables - Diesel fuel .....	7-19
Consumables - Biodiesel fuels .....	7-20
Consumables - Diesel Exhaust Fluid (DEF)/AdBlue® .....	7-22
Consumables - Organic Acid Technology (OAT) coolant .....	7-24
Maintenance chart notes .....	7-26

---

Maintenance summary decal .....	7-27
<b>Maintenance planning</b>	
Maintenance chart .....	7-28
<b>At warning message display</b>	
Air filter service icon/message* .....	7-30
Water in fuel message .....	7-33
Transmission oil filter switch .....	7-35
Hydraulic oil filter switch .....	7-38
<b>First 10 to 50 hours</b>	
Wheel bolt torque .....	7-41
Weight bolt torque .....	7-42
Differential and planetary oil .....	7-43
<b>Every 10 hours or daily</b>	
Engine oil level .....	7-44
Transmission oil level .....	7-45
Engine coolant level .....	7-46
Air reservoir .....	7-46
Rear hitch and front axle .....	7-46
<b>Every 50 hours or weekly</b>	
Engine auxiliary fuel filter .....	7-47
<b>First 100 hours</b>	
Powershift transmission clutch calibration .....	7-49
<b>Every 100 hours</b>	
Front hitch .....	7-55
Front Power Take-Off (PTO) drive shaft .....	7-57
<b>Every 200 hours</b>	
Track alignment .....	7-58
<b>Every 300 hours</b>	
Battery water level (Note B) .....	7-59
Engine air intake and exhaust hoses .....	7-61
Engine coolant level - deaeration tank .....	7-63
Weight bolt torque .....	7-64
Front axle (Note A) .....	7-65
Rear hitch (Note A) .....	7-67
Fuel tank .....	7-69
Differential and planetary oil level (Note B) .....	7-70

---



Transmission oil pressure .....	7-71
Front Power Take-Off (PTO) oil level .....	7-72

## Every 400 hours

Cab air filter* .....	7-73
-----------------------	------

## Every 600 hours

Engine oil and filter* .....	7-76
Engine coolant antifreeze protection .....	7-79
Engine coolant hoses and clamps .....	7-79
Engine fuel filter* .....	7-81
Engine auxiliary fuel filter* .....	7-84
Fuel system bleeding .....	7-86
Changeable Power Take-Off (PTO) internal splines .....	7-87
Diesel Exhaust Fluid (DEF)/AdBlue® in-line filter .....	7-88
Front Power Take-Off (PTO) oil and filter* .....	7-89
Front Power Take-Off (PTO) dropbox oil .....	7-91
Engine air precleaner* .....	7-92

## Every 1000 hours or annually

Pneumatic brake system dryer .....	7-93
Powershift transmission clutch calibration .....	7-94

## Every 1200 hours or annually

Differential and planetary oil .....	7-100
Engine air filters* .....	7-104

## Every 1500 hours

Transmission oil .....	7-107
Hydraulic oil filter* .....	7-110
Transmission oil filter* .....	7-111
Idler/roller wheel oil .....	7-112
Engine crankcase filter* .....	7-113

## Every 3000 hours

Engine valve adjustment (Note C) .....	7-117
--	-------

## Every 3600 hours

Diesel Exhaust Fluid (DEF)/AdBlue® supply module filter .....	7-118
---	-------

## Every 4000 hours or every four years

Engine coolant .....	7-121
----------------------	-------

## As required

Vehicle fire prevention .....	7-123
Track inspection and bolt torque .....	7-124
Track rotation .....	7-124
Track drive wheel and idler bolt torque .....	7-124
Track tension release.....	7-125
Track alignment.....	7-127
Cab air filter* .....	7-129
Grille screen and radiator area .....	7-132
Fuel tank vent filter .....	7-133
Transmission clutch and accumulator .....	7-133
Tire pressure .....	7-134
Fan belt .....	7-135
Diesel Exhaust Fluid (DEF)/AdBlue® tank .....	7-141
Remote valve collection bottle.....	7-143
Remote valve couplers .....	7-144
Cab fabric and carpet.....	7-145
Seat belt .....	7-145

## Fuse and relay locations

Electrical component location .....	7-146
Lamps and bulbs .....	7-151

## STORAGE

Preparing for storage .....	7-152
Removal from storage .....	7-153

## ELECTRICAL SYSTEM

Radio or audio system.....	7-154
Battery removal and installation .....	7-155
Auxiliary battery connections .....	7-157
Headlight .....	7-158
LED work lights.....	7-159
Grille work light .....	7-159
Fender tail light and warning light .....	7-160
Roof warning light .....	7-161
Roof work light.....	7-161
High intensity work light .....	7-162
Wide transport marker light.....	7-163
Rotating beacon light .....	7-164
Interior light .....	7-165

## 8 TROUBLESHOOTING

### ALARM(S)

Display warnings overview .....	8-1
Display warnings - Level 1 .....	8-2
Display warnings - Level 2 .....	8-4
Display warnings - Level 3 .....	8-7
Display warnings - Level 4 .....	8-9

---

## SYMPTOM(S)

Engine symptoms .....	8-11
Transmission symptoms.....	8-13
Hydraulic symptoms.....	8-14
Hitch symptoms .....	8-15
Brake symptoms.....	8-16
Cab environment symptoms.....	8-16
Electrical power system symptoms.....	8-17

## 9 SPECIFICATIONS

Engine specifications .....	9-1
Power train specifications .....	9-2
Operating speeds.....	9-6
Operating speeds - SmartTrax™ tractors .....	9-7
Vehicle dimensions and shipping weight .....	9-11
Vehicle dimensions and shipping weight - SmartTrax™ tractors .....	9-17
Maximum operating weight.....	9-19

## 10 ACCESSORIES

Farming system displays .....	10-1
Rear view mirrors.....	10-2
Chemical tank mounting .....	10-4
Loader connection and operation .....	10-6
General accessories.....	10-7

## 11 FORMS AND DECLARATIONS

Delivery report - owner copy .....	11-1
Delivery report - dealer copy .....	11-2
First service - owner copy .....	11-4
First service - owner copy .....	11-6

---

# 1 - GENERAL INFORMATION

## Note to the owner

This manual contains important information about the safe operation, adjustment and routine maintenance of your T8. or T8. **SmartTrax™** series tractor. The manual is divided into 10 chapters as outlined in the table of contents. Refer to the index at the end of this manual for locating specific items about your tractor.

Do NOT operate or permit anyone to operate or service this machine until you or the other persons have read this manual. Use only trained operators who have demonstrated the ability to operate and service this machine correctly and safely.

This Operator's Manual is to be stored in the manual compartment behind the operator's seat in the vehicle. Make

sure this manual is in good condition. Contact your dealer to obtain additional manuals.

Your NEW HOLLAND dealer will instruct you in the general operation of your new equipment. Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your machine. They will also provide any after-sales service you may need, and genuine NEW HOLLAND parts, your guarantee of quality and match.

NEW HOLLAND **Top Service™** is also available. Call 1-866-NEWHLND (1-866-639-4563) or email [na.topservice@cnh.com](mailto:na.topservice@cnh.com).

## Tractors equipped with rear tracks

On **SmartTrax™** models, refer to the information starting on page **Operating speeds - SmartTrax™ tractors** for transport speed weight limitations.

See Operator's Manual for Transport Speed Weight Guidelines

Speed (kph)	Speed (mpg)	Weight (Kg)	Weight (lbs)
10	6.2	1000	2200
15	9.3	1000	2200
20	12.4	1000	2200
25	15.5	1000	2200
30	18.6	1000	2200
35	21.7	1000	2200
40	24.8	1000	2200
45	27.9	1000	2200
50	31.0	1000	2200
55	34.1	1000	2200
60	37.2	1000	2200
65	40.3	1000	2200
70	43.4	1000	2200
75	46.5	1000	2200
80	49.6	1000	2200
85	52.7	1000	2200
90	55.8	1000	2200
95	58.9	1000	2200
100	62.0	1000	2200
105	65.1	1000	2200
110	68.2	1000	2200
115	71.3	1000	2200
120	74.4	1000	2200
125	77.5	1000	2200
130	80.6	1000	2200
135	83.7	1000	2200
140	86.8	1000	2200
145	89.9	1000	2200
150	93.0	1000	2200
155	96.1	1000	2200
160	99.2	1000	2200
165	102.3	1000	2200
170	105.4	1000	2200
175	108.5	1000	2200
180	111.6	1000	2200
185	114.7	1000	2200
190	117.8	1000	2200
195	120.9	1000	2200
200	124.0	1000	2200
205	127.1	1000	2200
210	130.2	1000	2200
215	133.3	1000	2200
220	136.4	1000	2200
225	139.5	1000	2200
230	142.6	1000	2200
235	145.7	1000	2200
240	148.8	1000	2200
245	151.9	1000	2200
250	155.0	1000	2200
255	158.1	1000	2200
260	161.2	1000	2200
265	164.3	1000	2200
270	167.4	1000	2200
275	170.5	1000	2200
280	173.6	1000	2200
285	176.7	1000	2200
290	179.8	1000	2200
295	182.9	1000	2200
300	186.0	1000	2200
305	189.1	1000	2200
310	192.2	1000	2200
315	195.3	1000	2200
320	198.4	1000	2200
325	201.5	1000	2200
330	204.6	1000	2200
335	207.7	1000	2200
340	210.8	1000	2200
345	213.9	1000	2200
350	217.0	1000	2200
355	220.1	1000	2200
360	223.2	1000	2200
365	226.3	1000	2200
370	229.4	1000	2200
375	232.5	1000	2200
380	235.6	1000	2200
385	238.7	1000	2200
390	241.8	1000	2200
395	244.9	1000	2200
400	248.0	1000	2200
405	251.1	1000	2200
410	254.2	1000	2200
415	257.3	1000	2200
420	260.4	1000	2200
425	263.5	1000	2200
430	266.6	1000	2200
435	269.7	1000	2200
440	272.8	1000	2200
445	275.9	1000	2200
450	279.0	1000	2200
455	282.1	1000	2200
460	285.2	1000	2200
465	288.3	1000	2200
470	291.4	1000	2200
475	294.5	1000	2200
480	297.6	1000	2200
485	300.7	1000	2200
490	303.8	1000	2200
495	306.9	1000	2200
500	310.0	1000	2200
505	313.1	1000	2200
510	316.2	1000	2200
515	319.3	1000	2200
520	322.4	1000	2200
525	325.5	1000	2200
530	328.6	1000	2200
535	331.7	1000	2200
540	334.8	1000	2200
545	337.9	1000	2200
550	341.0	1000	2200
555	344.1	1000	2200
560	347.2	1000	2200
565	350.3	1000	2200
570	353.4	1000	2200
575	356.5	1000	2200
580	359.6	1000	2200
585	362.7	1000	2200
590	365.8	1000	2200
595	368.9	1000	2200
600	372.0	1000	2200
605	375.1	1000	2200
610	378.2	1000	2200
615	381.3	1000	2200
620	384.4	1000	2200
625	387.5	1000	2200
630	390.6	1000	2200
635	393.7	1000	2200
640	396.8	1000	2200
645	399.9	1000	2200
650	403.0	1000	2200
655	406.1	1000	2200
660	409.2	1000	2200
665	412.3	1000	2200
670	415.4	1000	2200
675	418.5	1000	2200
680	421.6	1000	2200
685	424.7	1000	2200
690	427.8	1000	2200
695	430.9	1000	2200
700	434.0	1000	2200
705	437.1	1000	2200
710	440.2	1000	2200
715	443.3	1000	2200
720	446.4	1000	2200
725	449.5	1000	2200
730	452.6	1000	2200
735	455.7	1000	2200
740	458.8	1000	2200
745	461.9	1000	2200
750	465.0	1000	2200
755	468.1	1000	2200
760	471.2	1000	2200
765	474.3	1000	2200
770	477.4	1000	2200
775	480.5	1000	2200
780	483.6	1000	2200
785	486.7	1000	2200
790	489.8	1000	2200
795	492.9	1000	2200
800	496.0	1000	2200
805	499.1	1000	2200
810	502.2	1000	2200
815	505.3	1000	2200
820	508.4	1000	2200
825	511.5	1000	2200
830	514.6	1000	2200
835	517.7	1000	2200
840	520.8	1000	2200
845	523.9	1000	2200
850	527.0	1000	2200
855	530.1	1000	2200
860	533.2	1000	2200
865	536.3	1000	2200
870	539.4	1000	2200
875	542.5	1000	2200
880	545.6	1000	2200
885	548.7	1000	2200
890	551.8	1000	2200
895	554.9	1000	2200
900	558.0	1000	2200
905	561.1	1000	2200
910	564.2	1000	2200
915	567.3	1000	2200
920	570.4	1000	2200
925	573.5	1000	2200
930	576.6	1000	2200
935	579.7	1000	2200
940	582.8	1000	2200
945	585.9	1000	2200
950	589.0	1000	2200
955	592.1	1000	2200
960	595.2	1000	2200
965	598.3	1000	2200
970	601.4	1000	2200
975	604.5	1000	2200
980	607.6	1000	2200
985	610.7	1000	2200
990	613.8	1000	2200
995	616.9	1000	2200
1000	620.0	1000	2200

## Engine tampering

The fuel system, exhaust after-treatment system, and engine on your machine are designed and built to government emissions standards. Tampering by dealers, customers, operators, and users is strictly prohibited by law.

Failure to comply could result in government fines, rework charges, invalid warranty, legal action, and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!

## Tractor intended use

T8. or T8. **SmartTrax™** series tractors, with standard equipment and authorized attachments, are intended to be used for customary farming, land leveling and related agriculture operations (intended use). Installation of utility (dozer) blades, tile plows, or push bars on the tractor is not recommended. Any tractor damage resulting from the installation and/or use of such equipment is not covered by the tractor warranty.

The tractor is not designed for light/heavy forestry applications; usage is prohibited for forestry applications.

Do not use this machine for any purpose or in any manner other than as described in the manual, decals, or other product safety information provided with the machine. These materials define the machine's intended use.

Consult an authorized dealer or CNH Industrial America LLC on changes, additions or modifications that can be required for this machine to comply with various regulations and safety requirements. Unauthorized modifications will cause serious injury or death. Anyone making such unauthorized modifications is responsible for the consequences.

Use in any other way is considered as contrary to the intended use. The manufacture accepts no liability for any damage or injury resulting from this misuse and these risks must be born solely by the user.

## Electro-magnetic compatibility (EMC)

Interference may arise as a result of add-on equipment that may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the machine
- The electro-magnetic field generated by the add-on system should not exceed **24 V/m** at any time and at any location in the proximity of electronic components
- The add-on equipment must not interfere with the functioning of the on board electronics

Failure to comply with these rules will render the NEW HOLLAND warranty null and void.

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)