

ORIGINAL INSTRUCTIONS - according to Directive 2006/42/EC, Annex I 1.7.4.1

Magnum™ 250
Magnum™ 280
Magnum™ 310
Magnum™ 340
Magnum™ 380
Magnum™ 310 Rowtrac™
Magnum™ 340 Rowtrac™
Magnum™ 380 Rowtrac™
Tractor
PIN ZGRF05001 and above

OPERATOR'S MANUAL

Part number 48048291

1st edition English
September 2016



Contents

NOTE: The Operator's Manual consists of two volumes. The first volume contains operating information, the second volume the maintenance and diagnostic information.

1 GENERAL INFORMATION

Note to the owner.....	1-1
Engine tampering.....	1-2
Tractor intended use.....	1-2
Electro-magnetic compatibility (EMC).....	1-3
Manual scope.....	1-4
ISOBUS certification.....	1-5
Product identification.....	1-6
Manual storage.....	1-9
Machine orientation.....	1-10
Component Identification.....	1-11
Declaration of conformity.....	1-17
Selective Catalytic Reduction (SCR) system.....	1-19

2 SAFETY INFORMATION

Safety rules and signal word definitions.....	2-1
Safety rules - General.....	2-2
Safety rules - General maintenance safety.....	2-4
Safety rules - Wheels and tires.....	2-4
Safety rules - Driving on public roads and general transportation safety.....	2-4
Safety rules - Fire and explosion prevention.....	2-5
Safety rules - General battery safety.....	2-5
Safety rules - Hydraulic system safety.....	2-6
Safety rules - Passenger seat safety.....	2-6
Safety rules - Operator presence system.....	2-7
Safety rules - Power Take-Off (PTO).....	2-7
Safety rules - Reflectors and warning lights.....	2-7
Safety rules - Seat belts.....	2-7
Safety rules - Roll Over Protective Structure (ROPS).....	2-7
Safety rules - Cab protection.....	2-9
Safety rules - Air conditioning system.....	2-9
Safety rules - Personal Protective Equipment (PPE).....	2-9
Safety rules - Do Not Operate tag.....	2-9
Safety rules - Hazardous chemicals.....	2-10
Safety rules - Utility safety.....	2-10
Safety rules - Electrical storm safety.....	2-10
Safety rules - Mounting and dismounting.....	2-10
Safety rules - Working at heights.....	2-11
Safety rules - Lifting and overhead loads.....	2-11
Safety rules - Implements, tools and trailers.....	2-11
Safety rules - Roll over and tip over.....	2-12
Ecology and the environment.....	2-13
Safety signs.....	2-14

Selective Catalytic Reduction (SCR) exhaust treatment - Safety signs	2-27
Global warming potential	2-29
Safety aspects	2-30
Noise levels	2-37
Vehicle vibration levels	2-38
Fire extinguisher	2-39
Emergency exit	2-40
Wheel wedges	2-41

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Tractor access	3-1
Lower step	3-3

OPERATOR'S SEAT

Control identification	3-4
------------------------------	-----

PASSENGER'S SEAT

Overview	3-8
----------------	-----

FORWARD CONTROLS

Steering column	3-9
Front console	3-12
Pedal controls	3-14

LEFT-HAND SIDE CONTROLS

Emergency brake lever	3-16
-----------------------------	------

RIGHT-HAND SIDE CONTROLS

Armrest console	3-17
Multi function handle	3-18
Minimum/maximum RPM throttles	3-23
Control panel	3-26
Remote valve controls	3-35
Joystick	3-36
Armrest compartment	3-38
Adjusting the armrest console	3-40

REARWARD CONTROLS

Fender console	3-41
Automatic temperature controls	3-44
Automatic temperature control system	3-47
Ventilation	3-48

OVERHEAD CONTROLS

Interior lamps	3-50
----------------------	------

EXTERIOR CONTROLS

Rear fender	3-51
Front hitch	3-53

INSTRUMENT CLUSTER

Overview	3-54
Gauges	3-55
Status and warning icons	3-56
Upper display	3-59
Lower display	3-63
Keypad	3-65
Setup menu	3-67
Rear tire radius and track radius charts	3-73
Adjust menu	3-74
Performance features	3-83

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Engine - Safety rules	4-1
-----------------------------	-----

STARTING THE UNIT

Normal engine starting	4-3
Cold starting aids	4-7
Cold temperature operation	4-9

STOPPING THE UNIT

Stopping the engine	4-11
---------------------------	------

MOVING THE UNIT

FULL POWERSHIFT TRANSMISSION	4-13
Powershift transmission	4-13
Best practices for prolonged transmission life	4-14
Inching pedal and throttle	4-15
Powershift transmission controls	4-16
Upper display - Powershift transmission	4-19
Driving the Powershift vehicle	4-21
Setting default gears	4-25
Automatic Productivity Management (APM)	4-27
CONTINUOUSLY VARIABLE TRANSMISSION (CVT)	4-35
Introduction	4-35
CVX brake, pedal and throttle operation	4-36
CVX controls	4-41
Upper display	4-46
CVX operation	4-48
Eco-Draft or Shuttle mode	4-51
Driving the CVX transmission	4-53
Transmission messages	4-58
POWERSHIFT AND CVT TRANSMISSIONS	4-60

Mechanical Front Drive (MFD)	4-60
Differential lock system	4-63
Suspended axle	4-65
Ride control	4-69
Engine power boost	4-71
Constant engine speed	4-72
Suspended cab	4-75
Electronic end of row system	4-76

PARKING THE UNIT

Automatic park lock	4-82
---------------------------	------

5 TRANSPORT OPERATIONS

ROAD TRANSPORT

Tractor warning lamps	5-1
Safe transport speed	5-3

SHIPPING TRANSPORT

Securing the tractor for shipping	5-4
---	-----

RECOVERY TRANSPORT

Safety rules	5-5
Towing the tractor	5-6

6 WORKING OPERATIONS

GENERAL INFORMATION

Overview	6-1
----------------	-----

REAR POWER TAKE-OFF (PTO)

Safety rules	6-2
Connecting the Power Take-Off (PTO)	6-6
Interchangeable Power Take-Off (PTO) shaft	6-7
Rear Power Take-Off (PTO) operation	6-13
Power Take-Off (PTO) fender switch operation	6-17
Auto Power Take-Off (PTO) operation	6-18

FRONT POWER TAKE-OFF (PTO)

Overview	6-21
Front Power Take-Off (PTO) operation	6-22

REAR HITCH

Identification	6-25
Link adjustment	6-26
Hitch high clearance adjustment	6-30
Hydraulic links	6-33

Sway limiter adjustment	6-35
Automatic telescoping stabilizers	6-36
Lower link block adjustment	6-38
Mechanical float adjustment	6-40
Hitch quick coupler - Category III/IIIN	6-41
Hitch operation	6-46
Hitch remote switch operation	6-51
Position control operation	6-53
Load control operation	6-55
Slip control operation	6-57
Hitch set point	6-59

FRONT HITCH

Overview	6-61
Front hitch operation	6-62

DRAWBARS AND TOWING ATTACHMENTS

Safety rules	6-69
Drawbar capacity/position	6-70
Adjusting the drawbar	6-74

TRAILER HITCHES

Clevis and special drawbars	6-76
Automatic trailer hitch	6-78
Auto pickup hitch operation	6-81
Manual trailer hitch	6-83

TRAILER BRAKING SYSTEMS

Safety rules	6-85
Trailer brake connections	6-86
Air pressure monitoring	6-87

AUXILIARY CONNECTIONS

Auxiliary power and lighting	6-88
Cab power connections	6-90
Radar connection	6-91
Implement ISOBUS connector	6-92

HYDRAULIC REMOTE CONTROL VALVES

Valve couplers and connections	6-93
Motor return circuit	6-97
Power beyond circuit	6-98
Flow capacity	6-99
Hydraulic transport lock	6-101
Operating the controls	6-102
Remote valve display screens	6-106
Remote hydraulic auto mode	6-109

Auto depth control	6-112
Joystick operation	6-114

BALLASTING THE TRACTOR

Guidelines	6-117
Tire load and inflation charts	6-126
Weights, cast metal.....	6-128
Wheel slip and power hop performance	6-137

MECHANICAL FRONT DRIVE (MFD) AXLES

Front axle identification	6-140
Tire combinations and tread positions.....	6-141
Steering and oscillation stops	6-146
Tread and fender settings - Class 4.75 and 5.0 fixed front axles.....	6-148
Tread and fender settings - Class 4.75 and 5.0 saddle suspended front axles ..	6-153
Tread and fender settings - Class 5.0 wide front axles.....	6-158
Front wheel fenders	6-160
Front wheel fenders - Class 4.75 and 5.0 fixed and suspended axles	6-161
Front wheel fenders - Class 5.0 wide fixed and suspended axles	6-166

REAR AXLE

Rear wheel installation	6-171
Rear wheel tread settings	6-173

REAR TRACKS

Tire load and inflation charts - - Tractors with rear tracks	6-176
Maximum front ballast recommendations	6-177
Front wheel tread settings	6-178
Track preconditioning.....	6-183
Factory and field track settings	6-185

7 MAINTENANCE

GENERAL INFORMATION

Safety rules.....	7-1
Maintenance guidelines	7-2
Opening the hood	7-3
Closing the hood	7-4
Filling the fuel tank	7-5
Filling the Diesel Exhaust Fluid (DEF)/AdBlue® tank	7-7
Battery disconnect switch	7-9
Battery access and service.....	7-10
Tire and rim service.....	7-11
Tractor jacking points.....	7-13
Capacities	7-15
Consumables - Engine oil	7-16
Consumables - Transmission/hydraulic system fluid	7-17
Consumables - Diesel fuel	7-18

Consumables - Biodiesel fuels	7-19
Consumables - Diesel Exhaust Fluid (DEF)/AdBlue®	7-21
Consumables - Organic Acid Technology (OAT) coolant	7-23
Maintenance chart notes	7-25
Maintenance summary decal	7-26

Maintenance planning

Maintenance chart	7-27
-------------------------	------

At warning message display

Air filter service icon/message*	7-29
Water in fuel message	7-32
Transmission oil filter switch	7-34
Hydraulic oil filter switch	7-37

First 10 to 50 hours

Wheel bolt torque	7-40
Weight bolt torque	7-41
Differential and planetary oil	7-42

Every 10 hours or daily

Engine oil level	7-43
Transmission oil level	7-44
Engine coolant level	7-45
Air reservoir	7-45
Rear hitch and front axle	7-45

Every 50 hours or weekly

Engine auxiliary fuel filter	7-46
------------------------------------	------

First 100 hours

Powershift transmission clutch calibration	7-48
--	------

Every 100 hours

Front hitch	7-54
Front Power Take-Off (PTO) drive shaft	7-56
Input shaft for the front Power Take-Off (PTO) dropbox	7-57

Every 200 hours

Track alignment	7-59
-----------------------	------

Every 300 hours

Battery water level (Note B)	7-60
Engine air intake and exhaust hoses	7-62
Engine coolant level - deaeration tank	7-64

Weight bolt torque	7-65
Front axle (Note A)	7-66
Rear hitch (Note A)	7-68
Fuel tank.....	7-70
Differential and planetary oil level (Note B).....	7-71
Transmission oil pressure	7-72
Front Power Take-Off (PTO) oil level	7-73

Every 400 hours

Cab air filter*	7-74
-----------------------	------

Every 600 hours

Engine oil and filter*	7-77
Engine coolant antifreeze protection	7-80
Engine coolant hoses and clamps.....	7-80
Engine fuel filter*	7-82
Engine auxiliary fuel filter*	7-85
Fuel system bleeding	7-87
Changeable Power Take-Off (PTO) internal splines.....	7-88
Diesel Exhaust Fluid (DEF)/AdBlue® in-line filter	7-89
Engine air precleaner*	7-90

Every 1000 hours or annually

Pneumatic brake system dryer	7-91
Powershift transmission clutch calibration.....	7-92
Front Power Take-Off (PTO) oil and filter*.....	7-98
Front Power Take-Off (PTO) dropbox oil	7-100

Every 1200 hours or annually

Differential and planetary oil	7-101
Engine air filters*	7-105

Every 1500 hours

Transmission oil	7-108
Regulated system oil filter*	7-111
Main transmission oil filter*	7-112
Idler/roller wheel oil	7-113
Engine crankcase filter*	7-114

Every 3000 hours

Secondary steering system.....	7-118
Engine valve adjustment (Note C).....	7-118

Every 3600 hours

Diesel Exhaust Fluid (DEF)/AdBlue® supply module filter	7-119
---	-------

Every 4000 hours or every four years

Engine coolant.....	7-122
---------------------	-------

As required

Vehicle fire prevention.....	7-125
Track inspection and bolt torque	7-126
Track rotation	7-126
Track drive wheel and idler bolt torque	7-126
Track tension release.....	7-127
Track alignment.....	7-129
Cab air filter*.....	7-131
Grille screen and radiator area	7-134
Fuel tank vent filter	7-135
Transmission clutch and accumulator	7-135
Tire pressure	7-136
Fan belt.....	7-137
Diesel Exhaust Fluid (DEF)/AdBlue® tank	7-143
Remote valve collection bottle.....	7-145
Remote valve couplers	7-146
Emergency brake lever.....	7-147
Cab fabric and carpet.....	7-148
Seat belt	7-148

Fuse and relay locations

Electrical component location	7-149
Lamps and bulbs	7-154

STORAGE

Preparing for storage	7-155
Removal from storage	7-156

ELECTRICAL SYSTEM

Radio or audio system.....	7-157
Battery removal and installation	7-158
Auxiliary battery connections	7-160
Headlight	7-161
LED work lights	7-162
Fender tail light and warning light	7-162
Roof front warning and work light	7-163
Roof rear warning light	7-164
High intensity work light	7-165
Side turn indicator light	7-165
Rotating beacon light.....	7-166
Number plate light	7-166
Interior light	7-167

8 TROUBLESHOOTING

ALARM(S)

Display warnings overview	8-1
Display warnings - Level 1	8-2
Display warnings - Level 2	8-4
Display warnings - Level 3	8-7
Display warnings - Level 4	8-9

SYMPTOM(S)

Engine symptoms	8-11
Transmission symptoms	8-13
Hydraulic symptoms	8-14
Hitch symptoms	8-15
Brake symptoms	8-16
Cab environment symptoms	8-16
Electrical power system symptoms	8-17

9 SPECIFICATIONS

Engine specifications	9-1
Power train specifications	9-2
Operating speeds - Wheeled tractors	9-5
Operating speeds - Rowtrac™ tractors	9-6
Vehicle dimensions and shipping weight - Wheeled tractors	9-10
Vehicle dimensions and shipping weight - Rowtrac™ tractors	9-16
Maximum operating weight	9-19

10 ACCESSORIES

Farming system displays	10-1
Rear view mirrors	10-2
Chemical tank mounting	10-4
General accessories	10-6

1 - GENERAL INFORMATION

Note to the owner

This manual contains important information about the safe operation, adjustment and routine maintenance of your **Magnum™** or **Magnum™ Rowtrac™** series tractor. The manual is divided into 10 chapters as outlined in the table of contents. Refer to the index at the end of this manual for locating specific items about your tractor.


Do NOT operate or permit anyone to operate or service this machine until you or the other persons have read this manual. Use only trained operators who have demonstrated the ability to operate and service this machine correctly and safely.

Tractors equipped with rear tracks

On **Rowtrac™** models, refer to the information starting on page **Operating speeds - Rowtrac™ tractors** for transport speed weight limitations.

This Operator's Manual is to be stored in the manual compartment behind the operator's seat in the vehicle. Make sure this manual is in good condition. Contact your dealer to obtain additional manuals.

Your CASE IH dealer will instruct you in the general operation of your new equipment. Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your machine. They will also provide any after-sales service you may need, and genuine CASE IH parts, your guarantee of quality and match.



RAIL14TR03870BA 1

Engine tampering

The fuel system, exhaust after-treatment system, and engine on your machine are designed and built to government emissions standards. Tampering by dealers, customers, operators, and users is strictly prohibited by law.

Failure to comply could result in government fines, rework charges, invalid warranty, legal action, and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!

Tractor intended use

Magnum™ or **Magnum™ Rowtrac™** series tractors, with standard equipment and authorized attachments, are intended to be used for customary farming, land leveling and related agriculture operations (intended use). Installation of utility (dozer) blades, tile plows, or push bars on the tractor is not recommended. Any tractor damage resulting from the installation and/or use of such equipment is not covered by the tractor warranty.

Consult an authorized dealer or CNH Industrial America LLC on changes, additions or modifications that can be required for this machine to comply with various regulations and safety requirements. Unauthorized modifications will cause serious injury or death. Anyone making such unauthorized modifications is responsible for the consequences.

The tractor is not designed for light/heavy forestry applications; usage is prohibited for forestry applications.

The tractor is not designed for front end loader operation.

Do not use this machine for any purpose or in any manner other than as described in the manual, decals, or other product safety information provided with the machine. These materials define the machine's intended use.

Use in any other way is considered as contrary to the intended use. The manufacture accepts no liability for any damage or injury resulting from this misuse and these risks must be born solely by the user.



Our support email:

ebooklibonline@outlook.com