

**Farmall 80**  
**Farmall 90**  
**Farmall 100**  
Tractor

**OPERATOR'S MANUAL**

**Part number 48140854**  
1<sup>st</sup> edition English  
October 2018



# Contents

---

## 1 GENERAL INFORMATION

|                                      |     |
|--------------------------------------|-----|
| Note to the owner.....               | 1-1 |
| Identification from the engine ..... | 1-3 |
| Nameplate .....                      | 1-3 |
| Noise levels.....                    | 1-5 |
| Universal symbols .....              | 1-6 |

## 2 SAFETY INFORMATION

|   |      |
|---|------|
| Safety precautions.....                     | 2-1  |
| Roll Over Protection Structure (ROPS) ..... | 2-2  |
| Safety Decals - Cab models .....            | 2-3  |
| Safety decals – Models without cab .....    | 2-9  |
| Before operating the machine .....          | 2-14 |
| Driving the vehicle .....                   | 2-15 |
| Machine operation.....                      | 2-16 |
| Power take off (PTO) operation .....        | 2-17 |
| Maintenance.....                            | 2-17 |
| Diesel fuel .....                           | 2-20 |
| Fire or Explosion Prevention .....          | 2-20 |
| Air conditioner .....                       | 2-21 |
| Intended use statement .....                | 2-22 |

## 3 CONTROLS AND INSTRUMENTS

### ACCESS TO OPERATOR'S PLATFORM

|   |     |
|---|-----|
| General check .....                         | 3-1 |
| Introduction .....                          | 3-2 |
| Rearview mirrors – Models without cab ..... | 3-4 |
| Rearview mirrors - Cab models .....         | 3-5 |
| Cab - Overview .....                        | 3-6 |
| Platform header .....                       | 3-7 |

### OPERATOR'S SEAT

|                       |      |
|-----------------------|------|
| Operator's seat ..... | 3-8  |
| Seat belt .....       | 3-10 |

### FORWARD CONTROLS

|  |      |
|--|------|
| Controls front .....                                 | 3-11 |
| Ignition switch .....                                | 3-12 |
| Four-wheel drive with electro-hydraulic control..... | 3-13 |
| Differential eletro-hydraulic lock .....             | 3-14 |
| Cold starting aids (when fitted) .....               | 3-14 |
| Warning lights .....                                 | 3-15 |
| Clutch pedal .....                                   | 3-16 |
| Inching pedal and throttle.....                      | 3-16 |
| Foot pedals of brake .....                           | 3-16 |

---

|                                       |      |
|---------------------------------------|------|
| Adjustments the steering column ..... | 3-17 |
| Throttle by hand .....                | 3-18 |

## LEFT-HAND SIDE CONTROLS

|                               |      |
|-------------------------------|------|
| Left-hand side controls ..... | 3-19 |
|-------------------------------|------|

## RIGHT-HAND SIDE CONTROLS

|   |      |
|---|------|
| Controls valve .....                        | 3-20 |
| Hydraulic controls .....                    | 3-20 |
| Differential lock system – Mechanical ..... | 3-21 |
| Right hand side controls.....               | 3-21 |

## REARWARD CONTROLS

|                                |      |
|--------------------------------|------|
| Switch - Rear work light ..... | 3-23 |
|--------------------------------|------|

## OVERHEAD CONTROLS

|                           |      |
|---------------------------|------|
| Radio (when fitted) ..... | 3-23 |
| Interior lights.....      | 3-24 |
| Climate controls .....    | 3-25 |

## EXTERIOR CONTROLS

|  |      |
|--|------|
| Power Take-Off (PTO) – Speed selection lever ..... | 3-27 |
|--|------|

## INSTRUMENT CLUSTER

|                       |      |
|-----------------------|------|
| Instrument panel..... | 3-28 |
| Gauges .....          | 3-29 |

## 4 OPERATING INSTRUCTIONS

### COMMISSIONING THE UNIT

|                             |     |
|-----------------------------|-----|
| General instructions .....  | 4-1 |
| Filling the fuel tank ..... | 4-2 |

### STARTING THE UNIT

|  |     |
|--|-----|
| Starting the engine .....              | 4-3 |
| Cold starting aids (when fitted) ..... | 4-4 |
| Booster battery procedure .....        | 4-6 |

### STOPPING THE UNIT

|                           |     |
|---------------------------|-----|
| Stopping the engine ..... | 4-7 |
|---------------------------|-----|

## 5 TRANSPORT OPERATIONS

### PREPARING FOR ROAD TRANSPORT

|  |     |
|--|-----|
| Machine loading in a transporter ..... | 5-1 |
|--|-----|

---

## RECOVERY TRANSPORT

|                          |     |
|--------------------------|-----|
| Towing the machine ..... | 5-1 |
|--------------------------|-----|

## 6 WORKING OPERATIONS

### GENERAL INFORMATION

|   |     |
|---|-----|
| Traction Front Wheel Drive (FWD) .....      | 6-1 |
| Differential lock system – Mechanical ..... | 6-2 |

### TRANSMISSION

|   |      |
|---|------|
| Operation - 12x4 Mechanical transmission .....      | 6-3  |
| Travel speeds – 12x4 Mechanical transmission .....  | 6-4  |
| Operation - 12x12 Mechanical transmission .....     | 6-5  |
| Travel speeds - 12x12 Mechanical transmission ..... | 6-6  |
| Operation - 20x12 Mechanical transmission .....     | 6-7  |
| Travel speeds - 20x12 Mechanical transmission ..... | 6-8  |
| Informational decals - Transmission .....           | 6-9  |
| Inching pedal and throttle.....                     | 6-12 |
| Throttle by hand .....                              | 6-12 |

### REAR POWER TAKE-OFF

|   |      |
|---|------|
| Operating precautions .....   | 6-13 |
| Power Take-Off (PTO) operation – With mechanical drive – Models without cab ..... | 6-14 |
| Power Take-Off (PTO) operation – With mechanical drive – models with cab ...      | 6-17 |
| Power Take-Off (PTO) operation with electrical hydraulic activation .....         | 6-19 |
| Operating speeds of the Power Take-Off (PTO) .....                                | 6-22 |

### HYDRAULIC REMOTE CONTROL VALVES

|  |      |
|--|------|
| Operation – Remote control valves – Models without cab ..... | 6-24 |
| Operation – Remote control valves – Models with cab .....    | 6-26 |
| Installing attachments .....                                 | 6-28 |

### THREE POINT HITCH

|  |      |
|--|------|
| Attach the implement on the hydraulic lift .....   | 6-29 |
| Adjustments - Three-point hydraulic lift .....     | 6-30 |
| Hydraulics .....                                   | 6-33 |
| Operation of the hydraulic system .....            | 6-34 |
| Maximum Work Height of the hydraulic lift .....    | 6-37 |
| Quick guide - Use of hydraulic system levers ..... | 6-38 |

### DRAWBARS AND TOWING ATTACHMENTS

|                          |      |
|--------------------------|------|
| Attaching a trailer..... | 6-39 |
| Tractor drawbar.....     | 6-39 |

### Tractor ballasting

|   |      |
|---|------|
| Tire care – Wheels .....                      | 6-40 |
| Tires – Calibration and assembly safety ..... | 6-43 |

---

|  |      |
|--|------|
| Tires – Parts of the tire .....                                  | 6-44 |
| Tire types – For the application .....                           | 6-45 |
| Wheels - General information – General features .....            | 6-46 |
| Front wheels - General specification – Compatibility table ..... | 6-49 |
| Assembly – Tires .....   | 6-52 |
| Tires – Recommendations for calibration .....                    | 6-54 |
| Tires - Calibration .....  | 6-56 |
| Tire pressures and permissible loads .....                       | 6-57 |
| Tires – Compatibility of front x rear tires .....                | 6-59 |
| Tires .....  | 6-61 |
| Liquid ballast .....   | 6-65 |
| Liquid ballast – Capacity table .....                            | 6-68 |
| Wheels rims - Adjustments .....                                  | 6-72 |

## Front axle

|  |      |
|--|------|
| Steering stops .....   | 6-73 |
| Wheels – Mounting depth .....  | 6-75 |
| Front wheel track adjustment – Version without Auxiliary Front-Wheel Drive (AFWD)<br>..... | 6-76 |
| Front wheel track adjustment.....  | 6-78 |
| Adjustment of the dynamic front mudguards .....  | 6-81 |
| Powered front axle - Alignment.....  | 6-84 |

## Rear axle

|                                   |      |
|-----------------------------------|------|
| Rear wheel track adjustment ..... | 6-85 |
|-----------------------------------|------|

# 7 MAINTENANCE

## GENERAL INFORMATION

|   |      |
|---|------|
| Introduction .....                          | 7-1  |
| Fuel handling precautions .....             | 7-3  |
| Diesel fuel .....                           | 7-5  |
| Specifications - Biodiesel fuel .....       | 7-6  |
| Organic Acid Technology (OAT) coolant.....  | 7-8  |
| General instructions from the machine ..... | 7-9  |
| Protective devices .....                    | 7-10 |

## MAINTENANCE CHART

|                        |      |
|------------------------|------|
| Maintenance chart..... | 7-12 |
|------------------------|------|

## WHEN THE WARNING LAMP LIGHTS

|   |      |
|---|------|
| Engine air filter, primary – Cleaning ..... | 7-14 |
| Brake fluid – Check .....                   | 7-16 |

## EVERY 10 HOURS OR EACH DAY

|   |      |
|---|------|
| Fuel system water separator – Drain ..... | 7-17 |
| Engine coolant concentration level .....  | 7-17 |
| Checking the engine oil level .....       | 7-18 |
| Battery – Cleaning .....                  | 7-19 |

---

|                                    |      |
|------------------------------------|------|
| Cleaning the radiators .....       | 7-19 |
| Wheel nuts tightening torque ..... | 7-20 |

## FIRST 50 HOURS

|                             |      |
|-----------------------------|------|
| First 50 Hour Service ..... | 7-21 |
|-----------------------------|------|

## EVERY 50 HOURS

|  |      |
|--|------|
| Air-conditioning system .....  | 7-22 |
| Transmission housing - Check .....   | 7-22 |
| Cab air filter .....   | 7-23 |
| Lubrication points – Version with Auxiliary Front Wheel Drive (AFWD) ..... | 7-24 |
| Clutch and components - Adjust .....                                       | 7-27 |
| Clutch and components - Adjust .....                                       | 7-27 |

## EVERY 300 HOURS

|   |      |
|---|------|
| Change engine oil and filter .....                  | 7-29 |
| Fuel filter replacement .....                       | 7-31 |
| Fuel transfer pump .....                            | 7-31 |
| Fuel injection system - Cleaning .....              | 7-32 |
| Fuel prefilter replacement .....                    | 7-33 |
| Engine crankcase breather filter – Cleaning .....   | 7-33 |
| Hydraulic oil filter – Replace .....                | 7-33 |
| Hydraulic oil level .....                           | 7-34 |
| Front axle differential – Check the oil level ..... | 7-34 |
| Park brake - Adjust .....                           | 7-35 |
| Activated charcoal filter .....                     | 7-35 |
| Engine fan belt – Adjust .....                      | 7-36 |
| Air conditioning filter drier – Check .....         | 7-36 |

## EVERY 600 HOURS

|   |      |
|---|------|
| Cab air filters - Replace .....         | 7-37 |
| Front axle hub oil - Change fluid ..... | 7-38 |
| Wheel nuts tightening torque .....      | 7-38 |

## EVERY 1200 HOURS OR ANNUALLY

|                                       |      |
|---------------------------------------|------|
| Engine valves clearance – Check ..... | 7-39 |
| Engine air filters - Replace .....    | 7-39 |
| Fuel tank - Cleaning .....            | 7-40 |
| Front axle drive shaft - Check .....  | 7-41 |
| Front axle oil – Change .....         | 7-42 |
| Transmission oil – Change .....       | 7-43 |

## EVERY 1200 HOURS OR EVERY 2 YEARS

|                              |      |
|------------------------------|------|
| Fuel injectors – Check ..... | 7-44 |
|------------------------------|------|

---

## EVERY 4000 HOURS OR 4 YEARS

|                              |      |
|------------------------------|------|
| Engine coolant replace ..... | 7-45 |
|------------------------------|------|

## GENERAL MAINTENANCE

|   |      |
|---|------|
| Fuel system – Bleed .....   | 7-49 |
| PTO clutch adjustment – Models without cab .....                                      | 7-50 |
| PTO clutch adjustment - Cab models .....  | 7-51 |
| Clutch pedal free play – Models without cab .....                                     | 7-52 |
| Clutch pedal free play - Cab models .....   | 7-52 |
| Fuel tank screen filter - Cleaning .....  | 7-53 |
| A/C compressor belt – Adjust .....  | 7-53 |
| Washer fluid reservoir – Check .....  | 7-54 |
| Brakes - Air bleeding .....   | 7-54 |
| Battery – Check .....   | 7-55 |
| Fuses and relays - Cab models .....   | 7-57 |
| Fuses and relays – Models without cab .....   | 7-59 |
| Work lights and lights - Adjustment .....   | 7-61 |
| Lamps - Replace .....   | 7-61 |
| Cab – Check .....   | 7-63 |
| Protecting the electronic and electrical systems during battery charging or welding.. | 7-64 |
| Transmission housing - Check .....  | 7-65 |

## STORAGE

|   |      |
|---|------|
| Storing the machine .....               | 7-66 |
| Preparation for use after storage ..... | 7-67 |

## 8 TROUBLESHOOTING

### SYMPTOM(S)

|                         |     |
|-------------------------|-----|
| Motor .....             | 8-1 |
| Hydraulic System .....  | 8-2 |
| Three-point hitch ..... | 8-2 |
| Brakes .....            | 8-4 |
| Cab .....               | 8-4 |
| Electrical .....        | 8-5 |

## 9 SPECIFICATIONS

|   |     |
|---|-----|
| Overall Dimensions – Models with a cab .....  | 9-1 |
| Overall Dimensions – Models without cab ..... | 9-2 |
| Fluids and lubricants .....                   | 9-3 |
| Motor .....                                   | 9-5 |
| Drive .....                                   | 9-5 |
| Brakes .....                                  | 9-6 |
| Power Take-Off (PTO) .....                    | 9-6 |
| Hydraulic system .....                        | 9-6 |
| Electrical .....                              | 9-7 |

---

# 1 - GENERAL INFORMATION

## Note to the owner

### General Information

This manual has been prepared to assist you in the correct procedure for running in, driving and operating your new machine, and for its maintenance. Read this manual carefully. Your machine is designed to be used in normal and customary agricultural applications.

If you require advice concerning your machine at any time, do not hesitate to contact your CASE IH dealer. He has factory trained personnel, genuine manufacturers' parts and the necessary equipment to carry out all your service requirements.

The specifications are provided for your information and guidance. For further information concerning your machine and equipment, consult your CASE IH dealer.

All data given in this book is subject to production variations. Dimensions and weight are approximate only. The illustrations do not necessarily show machines in standard condition or imply that these features are available in all countries. For exact information about a particular machine, see your CASE IH dealer.

Your machine has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Prior to delivery, the machine was carefully inspected, both at the factory and by your dealer, to ensure that it reaches you in optimum condition. To keep it in this condition and ensure problem-free operation, it is important that you perform routine checks at the recommended intervals, as specified in the maintenance table on the page **7-12**.

### Operator's manual storage

The operator's manual supplied with your machine is an important source of information and should be stored safely.

The manual has been written specifically for your tractor so it is important that you make a note of the print number and issue date, which can be found on the cover. In the event the manual is lost or damaged it can be replaced with the correct version.

### About this manual

This manual gives information for use of your machine, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance.

Read and understand it; keep it in good condition and always keep it in a safe place.

This manual does not contain all the information related to periodical service, converting and repairs to be carried out by CASE IH professional service personnel.

The Table of Contents page(s) are provided to have an overview of main manual's topics. A detailed alphabetic index is available at the end of this manual for locating specific items.

### Normal operation

- Normal operation means the use of the machine for the purpose intended by the manufacturer by an operator familiar with the machine and the mounted or towed equipment and complying with the information for operation and safe practices, as specified by the manufacturer in this manual and by the decals on the machine and the equipment.
- Normal operation includes preparing and storing the machine, swinging components into and out of work position, adding and removing ballast, and connecting and removing accessories.
- Normal operation includes adjusting and setting up the machine and equipment, for the specific conditions of the field and/or the crop.

### Routine service

- Routine servicing and maintenance means activities that must be performed daily by an operator familiar with the machine's characteristics and in compliance with the routine servicing information and with safe practice, as specified by the manufacturer in this manual and by decals on the machine, in order to keep it working properly. The routine service includes activities such as filling up, cleaning, washing, topping up fluid, applying grease, and replacing consumable items such as bulbs.

### Converting, periodical service and repair

- Periodic servicing means activities that must be performed at given intervals by trained personnel familiar with the machine's characteristics and in compliance with the periodic servicing information and with safe practice, as specified by the manufacturer in this manual and in other company literature, in order for the machine to keep to its expected working lifespan.
- Conversion means activities that must be performed by professional service personnel familiar with the machine's characteristics and in compliance with the conversion information, as specified by the manufacturer in this manual, as well as with other company instructions or literature, in order to prepare the machine for a specific configuration.



- Repair means activities that must be performed by professional service personnel familiar with the machine's characteristics and in compliance with the repair information, as specified by the manufacturer in the dealer's manual, in order to restore the machine to correct working order following a fault or reduced performance.

## Machine cleaning

When using a high pressure washer, do not stand too close to the machine and avoid directing the jet at electronic components, electrical connections, breathers, seals, filler necks, etc. Never direct a cold water jet at a hot engine or exhaust.

Failure to comply with these rules will render the warranty null and void.

## Security

The pages in Section 2 list the precautions to be observed to ensure your safety and the safety of others. Read the safety precautions and follow the advice offered before operating the machine.

## Servicing after the first 50 hours

On page 7-21 you will find the operations that need to be performed after the first 50 hours of service.

This service should be performed by your CASE IH dealer.

**NOTICE:** It is important that the 50 h service is carried out in line with the recommendation to guarantee that the machine is providing optimal performance and efficiency.

## Replacement Parts

It should be pointed out that genuine parts have been examined and approved by the Company. Fitting and/or

using non-genuine products could have negative effects on the design characteristics of your machine, thereby affecting its safety. The Company is not liable for any damage caused by the use of 'non-genuine' parts and accessories. Only genuine replacement parts should be used. The use of non-genuine parts may invalidate legal approvals associated with this product.

Making any modifications to the machine is prohibited, without specific written authorization from the manufacturer's After Sales Service department.

## Warranty

Your machine is warranted according to legal rights in your country and the contractual agreement with the selling dealer. No warranty shall, however, apply if the machine has not been used, adjusted and maintained as per the instructions given in the operator's manual.

## Using Biodiesel

Before using biodiesel in your machine, refer to the information on page 7-5 as regards storing and using biodiesel.


## Tampering with the engine or fuel system

**ATTENTION:** Your machine's engine and the fuel system were designed and configured to meet the emissions standards required by the laws in your country or region. Dealers, customers, operators, and users are strictly prohibited from tampering with the machine's factory settings. Failure to comply with this rule invalidates the machine's warranty and could result in government fines, legal action, and possible confiscation of the machine until rework to original condition is completed. Engine maintenance and repairs must be done by an authorized technician only.

## Identification from the engine

The engine identification is engraved on a plate **(1)** on the left-hand side of the engine block. Note down the number here:

Engine Serial No.: \_\_\_\_\_



CUIL13TR01085AA 1

## Nameplate


The Product Identification Number (PIN) can be found on the plate located on the front left-hand axle support.

Product Identification Number (PIN): \_\_\_\_\_  
\_\_\_\_\_



CUIL15TR00483AA 1


Product identification plate **(1)**.



CUIL13TR01265AA 2

The Product Identification Number (PIN) is engraved on the support cradle of the front axle, in front of the battery. Note down that identification here.

PIN: \_\_\_\_\_



CUIL13TR00194AA 3

# 1 - GENERAL INFORMATION

---

A plate in the rear of the cab or platform provides information about the Rollover Protective Structure (ROPS) and the maximum permissible weight of the machine.

| ESTRUTURA DE PROTEÇÃO NO CAPOTAMENTO<br>ROLL-OVER PROTECTIVE STRUCTURE<br>MARCO DE SEGURIDAD |                      |
|--|----------------------|
| MODELOS ATENDIDOS:<br>COVERED MODELS:<br>MODELOS ATENDIDOS:                                  | <input type="text"/> |
| MASSA MAX.:<br>MAX.MASS.:<br>PESO MAX.:  | <input type="text"/> |
| P/N:   | <input type="text"/> |
| N° SERIE:<br>SERIAL:   | <input type="text"/> |
| NORMA:<br>STANDARD:<br>NORMA:  | <input type="text"/> |

CUIL16TR01408AA 4

## Noise levels

### **⚠ CAUTION**

**Avoid possible hearing loss!**  
**The machine operator must wear hearing protection.**  
**Failure to comply could result in minor or moderate injury.**

C0070A

### **⚠ WARNING**

**Personal Protective Equipment (PPE) required.**  
**When assembling, operating, or servicing the machine, wear protective clothing and PPE necessary for the particular procedure. Some PPE that may be necessary includes protective shoes, eye and/or face protection, hard hat, heavy gloves, filter mask, and hearing protection.**  
**Failure to comply could result in death or serious injury.**

W0353A




























Noise is considered the most common of the pollutants that cause physical problems. Brazilian legislation establishes maximum limits for intensity and continuous or intermittent noise exposure durations. The tolerance limits for continuous and intermittent noise are detailed in the Regulatory Standard (NR15). See the legislation in force in your country.

It is important to stress that the use of ear protectors is recommended for the Operator and people who work close to the machines, regardless of the noise intensity and time of exposure.

During operation, the machines may be driving or powering other equipment, and this in turn also produces noise. As a result, the real noise levels perceived by the Operator and people who work close to the machines can vary considerably. Always consider wearing ear protectors that are good quality, intact, and that offer maximum protection.

## Universal symbols

As a guide to the operation of the machine, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

|   |  |   |  |
|---|--|---|--|
|  Heater plug for cold start  |  Turning signal                 |  Power Take-Off (PTO)                          |  Reaction control                             |
|  Alternator charging         | KAM Activated memory   | N Transmission in neutral   |  Accessories socket                           |
|  Fuel Level                  |  Turn signals                   |  Creeper selection                             |  Implement socket                             |
|  Automatic fuel shut-off     |  Turn signals - one trailer     |  Low speed selection                           |  % Percentage slip                            |
|  Engine speed (rpm x 100)    |  Turn signals - two trailers    |  High speed selection                          |  Raising of the hydraulic lift                |
|  Hour meter                  |  Wind shield washer             |  Road speed                                    |  Rear hitch lower                             |
|  Engine Oil Pressure         |  Windscreen wash wipe           |  Differential Lock                             |  Hydraulic lift height threshold              |
|  Engine Coolant Temperature |  Heating temperature control   |  Rear axle oil temperature                    |  Hydraulic lift disabled                     |
|  Coolant Level             |  Cab recirculation fan        |  Trans Oil Pressure                          |  Transmission filters and hydraulic filters |
|  Machine lights            |  Air conditioner              |  Auxiliary Front Wheel Drive (AFWD) operated |  Remote control valve extension             |
|  Main beam head            |  Air Filter Restriction       |  Warning!                                    |  Remote control valve command retraction    |
|  Dip Beam                  |  Parking brake                |  Danger warning lights                       |  Remote control valve flotation             |
|  Work lamps                |  Brake fluid level            |  Variable control                            |  Malfunction! See Operator's                |
|  Stop Lamp                 |  Trailer brake                |  Pressurized! Open carefully                 |  Malfunction! (alternative symbol)          |
|  Horn                      |  Warning! Corrosive substance |  Position control                            |  Brake fluid level                          |
|  Trans Oil Pressure        |  |   |  |

**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)