

ORIGINAL INSTRUCTIONS

OPERATOR'S MANUAL

T5.I10 AutoCommand™

T5.I20 AutoCommand™

T5.I30 AutoCommand™

T5.I40 AutoCommand™

Tractor

Part number 51493747

1st edition English

February 2019



Contents

1 GENERAL INFORMATION

Note to the owner.....	1-1
Intended use.....	1-3
Metric and imperial units abbreviations.....	1-5
Electro-magnetic interference (EMC).....	1-7
Product identification	1-8
Engine identification	1-9
Drive line identification	1-10
Cab — Certification plate	1-11
Product identification plate	1-12
Noise level information sheet.....	1-13
Programming tractor functions	1-14
Operator's manual storage	1-15
Before operating the tractor	1-16
International symbols	1-17
Vibration level information sheet	1-18
Machine orientation.....	1-19
Selective Catalytic Reduction (SCR) system.....	1-20

2 SAFETY INFORMATION

Safety precautions.....	2-1
Safety Decals.....	2-2
Safety rules.....	2-9
Burn prevention.....	2-16
Prevention of fire or explosions.....	2-17
Fire extinguisher.....	2-18
Protection offered by the tractor.....	2-19
Hazardous substances	2-22
Ecology and the environment	2-23
Towing the tractor for recovery	2-24
Emergency exit.....	2-25
Wheel chocks.....	2-26
Intended use statement	2-27
Instructor's seat.....	2-29

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Introduction	3-1
Cab air filters	3-5
In cab storage (where fitted).....	3-7
Cable and wiring routing.....	3-8
Mobile telephone usage	3-8
Implement monitor installation.....	3-9

OPERATOR'S SEAT

Operator's seat	3-10
Air suspension seat deluxe	3-11
Air suspension seat with passive or Dynamic Damping System (DDS).....	3-16
Air suspension seat 'evolution active'	3-22
Seat belt	3-29

INSTRUCTOR'S SEAT

Instructional seat	3-30
--------------------------	------

FORWARD CONTROLS

Ignition key	3-31
Hazard light switch	3-31
Lights and turn indicator lever	3-32
Follow me home lights.....	3-32
Windshield wiper and washer controls	3-33
Electronic parking brake.....	3-34
Clutch pedal	3-39
Foot throttle pedal	3-39
Foot brakes.....	3-40
Steering column	3-43

LEFT-HAND SIDE CONTROLS

Hand brake	3-44
------------------	------

RIGHT-HAND SIDE CONTROLS

Integrated control panel	3-45
Multifunction Handle	3-46

REARWARD CONTROLS

Switches on C-pillar	3-47
Battery isolator control switch	3-49
Heated screens (where fitted)	3-50
ISO bus functionality	3-51
Hydraulic master switch	3-52
Switches on right-hand trim	3-53
Climate controls (Low-profile cab).....	3-54
Manual temperature control (Low-profile cab).....	3-56

OVERHEAD CONTROLS

Switch panel	3-57
Left-hand and right-hand outermost work light switch.....	3-58
Interior light	3-59
Climate controls	3-60
Manual temperature control	3-61
Automatic Temperature Control (ATC)	3-62

INSTRUMENT CLUSTER

Analog Digital Instrument Cluster (ADIC)	3-63
Gauges	3-64
Gauges	3-64
Indicator and warning lights	3-65
Displays	3-67
Keypad basic	3-70
Keypad enhanced	3-71
Keypad enhanced	3-73
Selecting or changing the display settings	3-75
Ground speed calibration	3-76
Active and Manual Catalyst Management	3-79
Performance monitor	3-81
Armrest color display	3-86
Pop-up screens on color display	3-87
Performance monitor on color display	3-92
Programming the displays	3-97
Alarm functions	3-100
Accessing stored fault codes	3-102
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-103
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-112
Warning and advisory symbols	3-113

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Refueling the tractor	4-1
-----------------------------	-----

STARTING THE UNIT

Starting the engine	4-3
Grid heater cold start aid (where fitted)	4-5
Fuel heater (where fitted)	4-5
Coolant immersion heater (where fitted)	4-6
Transmission oil heater (where fitted)	4-7
Starting the engine With a flat battery	4-8

STOPPING THE UNIT

Stopping the engine	4-9
Automatic engine shutdown	4-10

MOVING THE UNIT

Cold temperature operation	4-11
Low idle speed management	4-13

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Carrying the tractor on a transporter	5-1
---	-----

RECOVERY TRANSPORT

Towing the tractor.....	5-2
-------------------------	-----

6 WORKING OPERATIONS

GENERAL INFORMATION

Constant engine speed	6-1
Differential lock	6-4
Four wheel drive	6-6
Front axle suspension (where fitted)	6-8
HTS standard	6-10
Quick guide	6-10
Explanation of symbols	6-12
Recording and replaying	6-14
Recording a sequence	6-16
Replaying a sequence	6-18
Headland function and color display screen	6-22
Deleting a sequence with color display	6-25
HTS advanced	6-26
Headland turn sequence	6-26
Universal Symbols	6-27
Recording a sequence	6-30
Creating a sequence in standstill	6-35
Replaying a sequence	6-37
Saving a sequence	6-41
Edit a sequence	6-44
Recalling a sequence	6-47
Deleting a sequence	6-51
Headland turn sequence error codes	6-52

TRANSMISSION

Transmission operation	6-55
Drive pedal	6-55
Engine speed control	6-56
Shuttle lever	6-58
Speed matching	6-60
Transmission controls	6-61
Program the maximum speed	6-64
Stationary control	6-66
Anti jack knife	6-67
Manual mode	6-68
Automatic mode	6-69
Transmission range lock	6-71
Cruise mode	6-72
Power Take-Off (PTO) mode	6-74

Pneumatic Trailer Brake Stabilization System	6-75
Fault codes	6-77

REAR POWER TAKE-OFF

Power Take-Off (PTO) operating precautions	6-78
Changing the PTO output shaft	6-79
Attaching PTO driven equipment	6-80
Power take-off (PTO) operation	6-81
Two speed PTO systems	6-86
Three speed PTO systems	6-88
Ground speed PTO	6-90
External PTO controls	6-91
Auto PTO operation	6-93

FRONT POWER TAKE OFF

Power Take-Off (PTO) operation	6-96
Auto PTO operation	6-99

REAR HITCH

Electronic Draft Control (EDC)	6-101
Settings and display	6-105
Electronic Draft Control (EDC) operation	6-107
External hitch controls	6-112

FRONT HITCH

Settings and adjustments	6-114
Hitch operation	6-117
External hitch controls	6-124
Front hitch management	6-125
Auxiliary front couplers (where fitted)	6-130
External controls for front couplers	6-134

HYDRAULIC REMOTE CONTROL VALVES

Remote control valve operation	6-135
Remote control valves valves	6-138
Connecting remote cylinders	6-141
Operating with remote valves	6-143
Hydraulic oil level when using remote hydraulic equipment	6-146

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

Remote control valves remote valves	6-148
Settings and adjustments	6-156
Setting the remote valve priority	6-162
Creating timer programs	6-163
Connecting remote cylinders	6-170
Operating with remote valves	6-173
Joystick operation with a front loader	6-175

Mid mount valves	6-179
EHR implement control setting	6-180
External EHR controls — (where fitted)	6-184

HYDRAULIC POWER BEYOND PORT

Hydraulic power beyond for external services	6-185
--	-------

THREE POINT HITCH

Attaching three-point hitch equipment	6-188
Lift rod adjustment	6-190
Top link adjustment	6-193
Flexible link end adjustment	6-195
Quick hitch	6-196
Linkage stabilizer adjustment	6-198

DRAWBARS AND TOWING ATTACHMENTS

Drawbars and towing attachments	6-201
Swinging drawbar	6-204
Automatic pickup hitch	6-206
Rear trailer hitches	6-210

TRAILER BRAKING SYSTEMS

Attaching a trailer	6-218
Trailer brake release switch	6-219
Air-operated trailer brakes	6-220
Hydraulic trailer brakes - Dual-line, compatible with trailers with universal single line	6-224
Hydraulic trailer brakes - With single line, Italy type	6-226

WHEEL TRACK ADJUSTMENT

Front wheel track adjustment	6-228
Rear wheel track adjustment	6-231
Front wheel alignment	6-233
Steering stops	6-234
Front axle oscillation stops	6-235
Front fender	6-236

BALLASTING AND TIRES

Ballasting and tires	6-238
Tire dimensions	6-241
Iron weights (where fitted)	6-247
Single piece ballast	6-250
Liquid ballast	6-251
Tire inflation	6-253

AUXILIARY POWER CONNECTIONS

Diagnostic socket	6-254
-------------------------	-------

Trailer electrical socket	6-255
ELECTRICAL POWER CONNECTORS	6-256
Internal power connectors	6-256
External power connectors	6-258
ISO bus classes	6-260
ISO bus functionality	6-262
Reconfigurable inputs for ISO Bus function	6-271

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Fuel requirement - Diesel fuel	7-2
Fuel - Storage, handling and transport	7-2
Biodiesel - Biodiesel fuels	7-3
Change the engine oil	7-5
Protective devices	7-6
Tractor jacking points	7-8
Engine oils	7-9
General specifications	7-10
Capacities	7-11
Organic Acid Technology (OAT) coolant	7-12
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	7-13

MAINTENANCE CHART

Maintenance chart	7-15
-------------------------	------

WHEN THE WARNING LIGHT IS ON

Change the engine air cleaner outer element	7-17
Drain the fuel system water separator	7-18
Check the brake fluid level	7-19

EVERY 10 HOURS OR EACH DAY

Check the engine coolant level	7-20
Check the engine oil level	7-21
Check the remote control valve drain bottles	7-22
Check windscreen washer reservoir	7-23
Drain air reservoir on air operated trailer brake	7-24

FIRST 50 HOURS

Service operations	7-25
--------------------------	------

EVERY 50 HOURS

Clean the cab air filter	7-26
All grease fittings	7-28
Check the front and the rear wheel nuts	7-34
Check the tire pressures and the tire condition	7-35

EVERY 100 HOURS

Clean the cooler section	7-36
--------------------------------	------

EVERY 600 HOURS

Adjust the hand brake	7-37
Check the battery fluid level	7-38
Change engine oil and filter	7-40
Change the first stage fuel filter and the fuel filter element	7-42
Change the engine air cleaner outer element	7-44
Change the hydraulic charge pump oil filter and the transmission oil filter	7-45
Check the engine air intake connections	7-46
Check the transmission oil cooler pipe couplings	7-47
Clean the DEF/AdBlue in-line filter	7-48
Check the transmission oil level, the rear axle oil level and the hydraulic oil level	7-49
Check the 4WD front axle differential oil level and the hubs oil level	7-50
Check the front PTO gearbox oil level - Oil Level	7-51
Inspect the poly V-belt	7-52
Inspect the compressor drive belt	7-53
Change the 4WD planetary hub oil	7-54

EVERY 1200 HOURS OR ANNUALLY

Change the cab air filters	7-55
Change the hydraulic suction pump oil filter	7-57
Change the 4WD differential oil	7-58
Change the front PTO gearbox oil	7-59
Grease the rear axle shaft bearing	7-60

EVERY 1200 HOURS OR EVERY 2 YEARS

Change the engine air cleaner inner element	7-61
Change the DEF/AdBlue in-line filter	7-62
Change the air brake drier reservoir	7-63
Change the poly V-belts	7-64
Change the transmission oil, the rear axle oil and the hydraulic oil	7-66

EVERY 2 YEARS

Change the air conditioning receiver drier	7-67
--	------

EVERY 1800 HOURS OR EVERY 2 YEARS

Engine - breather filter replacement	7-68
--	------

EVERY 2400 HOURS OR EVERY 2 YEARS

Camshaft Tappets - Check	7-69
--------------------------------	------

EVERY 3600 HOURS OR EVERY 2 YEARS

Change the DEF/AdBlue® main filter	7-70
--	------

EVERY 3600 HOURS OR EVERY 4 YEARS

Change the engine coolant fluid	7-71
---------------------------------------	------

GENERAL MAINTENANCE

Cleaning the tractor	7-75
Check first stage fuel filter and water trap	7-77
Bleeding the fuel system	7-78
Hydraulic system hoses	7-79
Check the brake pedal latching/unlatching	7-79
Adjust the automatic pickup hitch	7-80
Headlight adjustment	7-81
Work light adjustment	7-82
Bulb replacement	7-83
Fuses and relays	7-86
Protecting the electronic and electrical systems during battery charging or welding ..	7-96
Battery removal and installation	7-97

STORAGE

Tractor storage	7-99
Preparation for use after storage	7-99

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Introduction	8-1
--------------------	-----

ALARM(S)

Fault codes and symbols	8-2
-------------------------------	-----

SYMPTOM(S)

Engine	8-4
Transmission	8-5
Hydraulics	8-5
Three-point hitch	8-6
Brakes	8-6
Cab	8-6
Electrical system	8-7

9 SPECIFICATIONS

General dimensions	9-1
Minimum turn radius	9-3
Axle dimension	9-4
Maximum operating angle	9-5
Maximum tractor operating weights	9-6
Tractor weights	9-7
Capacities	9-8
Engine	9-9

Fuel system.....	9-10
Air cleaner system.....	9-11
Cooling System.....	9-12
Transmission	9-13
Rear Power Take-Off (PTO).....	9-14
Front power take-off (PTO).....	9-15
Three-point hitch	9-16
Three-point hitch front.....	9-17
Hydraulic system	9-18
Remote control valves.....	9-19
Front remote control valve couplers	9-20
Brakes	9-21
Steering.....	9-22
Electrical equipment.....	9-23
Minimum hardware tightening torques	9-24

10 ACCESSORIES

Radio (where fitted).....	10-1
External rear view mirrors	10-2
Auxiliary head lights and signature lights.....	10-4
Rotating beacon	10-5
Front-end loader fixation points	10-6

1 - GENERAL INFORMATION

Note to the owner

Introduction to this manual

This manual gives information about the use of your NEW HOLLAND machine as intended and under the conditions foreseen by NEW HOLLAND during normal operation, routine service, and maintenance.

This manual does not contain all the information that relates to periodic service, conversions, and repairs that only trained service personnel can perform. Some of these activities may require appropriate facilities, technical skills, and/or tools that NEW HOLLAND does not supply with the machine.

The manual contains the chapters as shown on the Contents pages. See the Index at the end of this manual to locate specific items about your NEW HOLLAND machine.

Normal operation

Normal operation consists of the use of this machine for the purpose NEW HOLLAND intends by an operator that:

- Is familiar with the machine and any mounted equipment or towed equipment
- Complies with the information on operation and safe practices as specified by NEW HOLLAND in this manual and by the signs on the machine

Normal operation includes:

- Preparation and storage of the machine
- Addition and removal of ballast
- Connection and disconnection of mounted equipment and/or towed equipment
- Adjustment and configuration of the machine and equipment for the specific conditions of the job site, field, and/or crop
- Movement of components into and out of working positions

Routine service and maintenance

Routine service and maintenance consists of the daily activities necessary to maintain the proper machine function. The operator must:

- Be familiar with the machine characteristics
- Comply with the information on routine service and safe practices as specified by NEW HOLLAND in this manual and by the signs on the machine

Routine service can include:

- Fueling
- Cleaning

- Washing
- Topping up fluid levels
- Greasing
- Replacing consumable items such as light bulbs

Periodic service, conversions, and repairs

Periodic service consists of activities that are necessary to maintain the expected life of the NEW HOLLAND machine. These activities have defined intervals.

Trained service personnel familiar with the machine characteristics must perform these activities at the defined intervals. Trained service personnel must comply with the information on periodic service and safe practices as partly specified by NEW HOLLAND in this manual and/or other company literature.

Periodic service includes:

- Oil change service for the engine, hydraulic circuits, or transmission
- Periodic exchange of other substances or components as required

Conversion activities rebuild the NEW HOLLAND machine in a configuration that is appropriate for a specific job site, crop, and/or soil conditions (e.g., installation of dual wheels). Conversion activities must be done:

- By trained service personnel familiar with the machine characteristics
- By trained service personnel that comply with the information on conversion as partly specified by NEW HOLLAND in this manual, assembly instructions, and/or other company literature

Repair activities restore proper function to a NEW HOLLAND machine after a failure or degradation of performance. Dismantling activities occur during the scrapping and/or dismantling of the machine.

Trained service personnel familiar with the machine characteristics must perform these activities. Trained service personnel must comply with the information for repair as specified by NEW HOLLAND in the service manual.

Before you operate

Read this manual before you start the engine or operate this NEW HOLLAND machine. Contact your NEW HOLLAND dealer if:

- You do not understand any information in this manual
- You need more information

- You need assistance

All persons training to operate, or who will operate this NEW HOLLAND machine should be old enough to pos-

sess a valid local vehicle operating permit (or meet other applicable local age requirements). These persons must demonstrate the ability to operate and service the NEW HOLLAND machine in a correct and safe manner.

Intended use

NOTE: *Your tractor is designed according to European directives related to health and safety risks; though it has been designed to minimize all the potential risks it is mandatory to carefully read, understand and observe all the decals and labels and to always refer to information and prescriptions outlined in this manual to prevent all residual potential risks. In case you may need further assistance please do not hesitate to contact your dealer.*

Your tractor is designed and made to pull, to carry and to power a variety of mounted or towed equipment, although within some physical limits. The working speed and performance may depend on a number of various parameters, such as weather and terrain conditions. Though the tractor is designed to perform in combination with a variety of equipment, there may be a number of combinations of above parameters, for which there is severe degradation of performance of the tractor and/or its mounted or trailed equipment. If you notice degradation of performance, contact your dealer for assistance, he may have useful information for improvements, or a kit may be available to enhance the performance.

Please carefully read and consider following precautions:

- Do not use the tractor for purposes other than those intended by the manufacturer and outlined in this manual.
- Do not use the tractor beyond its limits of terrain gradient and stability. Using the tractor beyond these limits may result in a roll-over or a tip-over. Observe the recommendations given in this manual.
- Do not use the tractor on higher speeds than allowed by the load and the environment. A wet surface or other low adherence conditions may increase the braking distance or result in vehicle instability. Always adapt your traveling speed according to the load of the vehicle and the characteristics of the road
- Do not use the tractor near or on soft verges of canals and brooks or banks and verges that are undermined by rodents. The tractor may sink sideways and roll over.
- Do not use the tractor on unstable bridge heads and poor bridge floors. These constructions may collapse and cause roll - over of the tractor. Always check the conditions and load capacity of bridges, crossings and ramps before driving over them.
- Do not use equipment mounted on the tractor which is not correctly matching and firmly fixed. The use of implements or accessories that have not been approved or are not correctly connected may increase the risk of roll-over of the tractor if they come loose. Ensure that the dimensions of the three- point linkage interface of both the tractor and the equipment are matching according to the categories defined in ISO 730. Ensure that the dimensions and speed of the PTO shaft on the tractors are matching those of the equipment.
- Do not use the tractor in combination with equipment, without having consulted the specific Operator's Manual provided with the equipment. The tractor is a universal tool to carry, tow and drive a variety of equipment. This manual alone cannot provide you with all the information required for the safe operation of the combination.
- Do not use the tractor for pulling work, in cases where you do not know whether the load will yield, for instance when pulling stumps; the tractor may flip over when the stump is not yielding.
- Be cautious that the centre of gravity of the tractor may increase when loads on the front – end loader or the three point linkage are raised. In these conditions, the tractor may roll – over earlier than expected.
- Do not step down from the tractor without shutting down the PTO, shifting the transmission to park or neutral and applying the park brake, unless continued PTO operation is required for some equipment, such as pumps or wood chippers. The latter equipment may have an emergency stop device on the equipment itself, as human intervention is needed during operation. But other equipment, engaged and driven by the tractor will have no means to stop the power transmission, other than the PTO clutch of the tractor.
- You shall take the necessary precautions (e.g. assistance) to always be aware of the possible presence of bystanders, certainly when manoeuvring in confined areas, such as the farm yard and sheds. Keep people away from the tractor during work. Ask bystanders to leave the field. There is not only the risk to be overrun by the tractor, but objects ejected by some equipment mounted on the tractor, such as a rotary mower, may cause harm. Stones may be thrown further than the mowed crop. Pay the necessary attention while operating next to public roads or footpaths. Thrown objects can get projected outside the field and hit unprotected people like bikers or pedestrians. Wait to cut the edge of the field till it is clear of bystanders.
- Do not allow riders on the tractor; do not allow people to stand on the access step to the cab when the tractor is moving. Your view to the left will be obstructed and a rider risks falling from the tractor during unexpected or abrupt movements.
- Always stay clear from the implements operating area and especially do not stand between the tractor and the implement or the trailed vehicle when operating lift controls; ensure no bystanders are near these operating areas.
- Certain functions of your tractor are controlled by software and some of them are safety-related. Do not attempt to modify or download software not certified and distributed by the manufacturer. Electronic settings and logics may be destroyed and seriously affect the function of the tractor. This may result in unpredictable and unsafe behaviour of the tractor. Always refer to your dealer; he has the appropriate tools and data sets and owns the officially released software versions and updates for your tractor.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com