

ORIGINAL INSTRUCTIONS - according to Regulation (EU) 2014/1322, Annex XXII

VERSUM® I00 CVX
VERSUM® I10 CVX
VERSUM® I20 CVX
VERSUM® I30 CVX
Tractor

OPERATOR'S MANUAL

Part number 51496433

1st edition English

February 2019



Contents

1 GENERAL INFORMATION

Note to the owner.....	1-1
Intended use.....	1-3
Metric and imperial units abbreviations.....	1-5
Electro-magnetic interference (EMC).....	1-7
Product identification	1-8
Engine identification	1-9
Drive line identification	1-10
Cab — Certification plate	1-11
Product identification plate	1-12
Noise level information sheet.....	1-13
Programming tractor functions	1-14
Operator's manual storage	1-15
Before operating the tractor	1-16
International symbols	1-17
Vibration level information sheet	1-18
Machine orientation.....	1-19
Selective Catalytic Reduction (SCR) system.....	1-20

2 SAFETY INFORMATION

Safety precautions.....	2-1
Safety Decals.....	2-2
Safety rules.....	2-9
Burn prevention.....	2-16
Prevention of fire or explosions.....	2-17
Fire extinguisher.....	2-18
Protection offered by the tractor.....	2-19
Hazardous substances	2-22
Ecology and the environment	2-23
Towing the tractor for recovery	2-24
Emergency exit	2-25
Wheel chocks.....	2-26
Intended use statement	2-27
Instructor's seat.....	2-29
Safety aspects in accordance with Regulation (EU) 1322/2014 - Annex XXII and subsequent amendments and modifications	2-30

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Introduction	3-1
Cab air filters	3-5
In cab storage (where fitted).....	3-7
Cable and wiring routing.....	3-8
Mobile telephone usage	3-8
Implement monitor installation.....	3-9

OPERATOR'S SEAT

Operator's seat	3-10
Air suspension seat deluxe	3-11
Air suspension seat with passive or Dynamic Damping System (DDS).....	3-16
Air suspension seat 'evolution active'	3-22
Seat belt	3-29

INSTRUCTOR'S SEAT

Instructional seat	3-30
--------------------------	------

FORWARD CONTROLS

Ignition key	3-31
Hazard light switch	3-31
Lights and turn indicator lever	3-32
Follow me home lights.....	3-32
Windshield wiper and washer controls	3-33
Electronic parking brake.....	3-34
Clutch pedal	3-39
Foot throttle pedal	3-39
Foot brakes.....	3-40
Steering column	3-43

LEFT-HAND SIDE CONTROLS

Hand brake	3-44
------------------	------

RIGHT-HAND SIDE CONTROLS

Integrated control panel	3-45
Multifunction Handle	3-46

REARWARD CONTROLS

Switches on C-pillar	3-47
Battery isolator control switch	3-49
Heated screens (where fitted)	3-50
ISO bus functionality	3-51
Hydraulic master switch	3-52
Switches on right-hand trim	3-53
Climate controls (Low-profile cab).....	3-54
Manual temperature control (Low-profile cab).....	3-55

OVERHEAD CONTROLS

Switch panel	3-56
Left-hand and right-hand outermost work light switch.....	3-57
Interior light	3-58
Climate controls	3-59
Manual temperature control	3-60
Automatic Temperature Control (ATC)	3-61

INSTRUMENT CLUSTER

Integrated control unit	3-62
Gauges	3-63
Indicator and warning lights	3-64
Displays	3-67
Keypad basic	3-68
Keypad enhanced	3-69
Selecting or changing the display settings	3-71
Adjust menu	3-72
Configure menu	3-77
Active and Manual Catalyst Management	3-80
Performance monitor	3-84
Armrest color display	3-93
Pop-up screens on color display	3-94
Performance monitor on color display	3-99
Programming the displays	3-104
Alarm functions	3-107
Accessing stored fault codes	3-109
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-110
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-120
Warning and advisory symbols	3-121

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Refueling the tractor	4-1
-----------------------------	-----

STARTING THE UNIT

Starting the engine	4-3
Grid heater cold start aid (where fitted)	4-5
Fuel heater (where fitted)	4-5
Coolant immersion heater (where fitted)	4-6
Transmission oil heater (where fitted)	4-7
Starting the engine With a flat battery	4-8

STOPPING THE UNIT

Stopping the engine	4-9
Automatic engine shutdown	4-10

MOVING THE UNIT

Cold temperature operation	4-11
Low idle speed management	4-13

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Carrying the tractor on a transporter	5-1
---	-----

RECOVERY TRANSPORT

Towing the tractor.....	5-2
-------------------------	-----

6 WORKING OPERATIONS

GENERAL INFORMATION

Constant engine speed	6-1
Differential lock	6-4
Four wheel drive	6-6
Front axle suspension (where fitted)	6-8
HTS standard	6-10
Quick guide	6-10
Explanation of symbols	6-12
Recording and replaying	6-14
Recording a sequence	6-17
Replaying a sequence	6-19
Headland function and color display screen	6-23
Deleting a sequence with color display	6-26
HTS advanced	6-27
Headland turn sequence	6-27
Universal Symbols	6-28
Recording a sequence	6-31
Creating a sequence in standstill	6-36
Replaying a sequence	6-38
Saving a sequence	6-42
Edit a sequence	6-45
Recalling a sequence	6-49
Deleting a sequence	6-53
Headland turn sequence error codes	6-54

TRANSMISSION

Transmission operation	6-57
Drive pedal	6-57
Engine speed control	6-58
Shuttle lever	6-61
Speed matching	6-63
Transmission controls	6-64
Program the maximum speed	6-67
Stationary control	6-69
Anti jack knife	6-70
Transmission display	6-71
Manual mode	6-72
Automatic mode	6-73
Transmission range lock	6-74
Power Take-Off (PTO) mode	6-75
Pneumatic Trailer Brake Stabilization System	6-76
Fault codes	6-78

REAR POWER TAKE-OFF

Power Take-Off (PTO) operating precautions	6-79
Changing the PTO output shaft	6-80
Attaching PTO driven equipment	6-81
Power take-off (PTO) operation	6-82
Two speed PTO systems	6-87
Three speed PTO systems	6-89
Ground speed PTO	6-91
External PTO controls	6-92
Auto PTO operation	6-94

FRONT POWER TAKE OFF

Power Take-Off (PTO) operation	6-97
Auto PTO operation	6-100

REAR HITCH

Electronic Draft Control (EDC)	6-102
Settings and display	6-106
Electronic Draft Control (EDC) operation	6-108
External hitch controls	6-114

FRONT HITCH

Settings and adjustments	6-116
Hitch operation	6-119
External hitch controls	6-126
Front hitch management	6-127
Auxiliary front couplers (where fitted)	6-132
External controls for front couplers	6-136

HYDRAULIC REMOTE CONTROL VALVES

Remote control valve operation	6-137
Remote control valves valves	6-140
Connecting remote cylinders	6-143
Operating with remote valves	6-145
Hydraulic oil level when using remote hydraulic equipment	6-148

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

Remote control valves — electrohydraulic	6-150
Settings and adjustments	6-157
Setting the remote valve priority	6-163
Creating timer programs	6-165
Connecting remote cylinders	6-172
Operating with remote valves	6-175
Joystick operation with a front loader	6-177
Mid mount valves	6-181
EHR implement control setting	6-183

External EHR controls — (where fitted)	6-187
HYDRAULIC POWER BEYOND PORT	
Hydraulic power beyond for external services	6-188
THREE POINT HITCH	
Attaching three-point hitch equipment	6-191
Lift rod adjustment	6-193
Top link adjustment	6-196
Flexible link end adjustment	6-198
Quick hitch	6-199
Linkage stabilizer adjustment	6-201
DRAWBARS AND TOWING ATTACHMENTS	
Drawbars and towing attachments	6-204
Swinging drawbar	6-207
Automatic pickup hitch	6-209
Rear trailer hitches	6-213
TRAILER BRAKING SYSTEMS	
Attaching a trailer	6-221
Trailer brake release switch	6-222
Air-operated trailer brakes	6-223
Hydraulic trailer brakes - Dual-line, compatible with trailers with universal single line	6-227
Hydraulic trailer brakes - With single line, Italy type	6-229
WHEEL TRACK ADJUSTMENT	
Front wheel track adjustment	6-231
Rear wheel track adjustment	6-234
Front wheel alignment	6-236
Steering stops	6-237
Front axle oscillation stops	6-238
Front fender	6-239
BALLASTING AND TIRES	
Ballasting and tires	6-241
Tire dimensions	6-244
Iron weights (where fitted)	6-250
Liquid ballast	6-253
Tire inflation	6-255
AUXILIARY POWER CONNECTIONS	
Diagnostic socket	6-256
Trailer electrical socket	6-257
ELECTRICAL POWER CONNECTORS	6-258
Internal power connectors	6-258

External power connectors	6-260
ISO bus classes	6-262
ISO bus functionality	6-264
Reconfigurable inputs for ISO Bus function	6-273

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Fuel requirement - Diesel fuel	7-2
Fuel - Storage, handling and transport	7-2
Biodiesel - Biodiesel fuels	7-3
Change the engine oil	7-5
Protective devices	7-6
Tractor jacking points	7-8
Engine oils	7-9
General specifications	7-10
Capacities	7-11
Organic Acid Technology (OAT) coolant	7-12
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	7-13

MAINTENANCE CHART

Maintenance chart	7-15
-------------------------	------

WHEN THE WARNING LIGHT IS ON

Change the engine air cleaner outer element	7-17
Drain the fuel system water separator	7-18
Check the brake fluid level	7-19

EVERY 10 HOURS OR EACH DAY

Check the engine coolant level	7-20
Check the engine oil level	7-21
Check the remote control valve drain bottles	7-22
Check windscreen washer reservoir	7-23
Drain air reservoir on air operated trailer brake	7-24

FIRST 50 HOURS

Service operations	7-25
--------------------------	------

EVERY 50 HOURS

Clean the cab air filter	7-26
All grease fittings	7-28
Check the front and the rear wheel nuts	7-34
Check the tire pressures and the tire condition	7-35

EVERY 100 HOURS

Clean the cooler section	7-36
--------------------------------	------

EVERY 600 HOURS

Adjust the hand brake	7-37
Check the battery fluid level	7-38
Change engine oil and filter	7-40
Change the first stage fuel filter and the fuel filter element.....	7-42
Change the engine air cleaner outer element	7-44
Change the hydraulic charge pump oil filter and the transmission oil filter	7-45
Check the engine air intake connections	7-46
Check the transmission oil cooler pipe couplings	7-47
Clean the DEF/AdBlue in-line filter	7-48
Check the transmission oil level, the rear axle oil level and the hydraulic oil level	7-49
Check the 4WD front axle differential oil level and the hubs oil level.....	7-50
Check the front PTO gearbox oil level - Oil Level	7-51
Inspect the poly V-belt.....	7-52
Inspect the compressor drive belt	7-53
Change the 4WD planetary hub oil.....	7-54

EVERY 1200 HOURS OR ANNUALLY

Change the cab air filters	7-55
Change the hydraulic suction pump oil filter.....	7-57
Change the 4WD differential oil	7-58
Change the front PTO gearbox oil.....	7-59
Grease the rear axle shaft bearing	7-60

EVERY 1200 HOURS OR EVERY 2 YEARS

Change the engine air cleaner inner element	7-61
Change the DEF/AdBlue in-line filter	7-62
Change the air brake drier reservoir.....	7-63
Change the poly V-belts	7-64
Change the transmission oil, the rear axle oil and the hydraulic oil	7-66

EVERY 2 YEARS

Change the air conditioning receiver drier.....	7-67
---	------

EVERY 1800 HOURS OR EVERY 2 YEARS

Engine - breather filter replacement.....	7-68
---	------

EVERY 2400 HOURS OR EVERY 2 YEARS

Camshaft Tappets - Check	7-69
--------------------------------	------

EVERY 3600 HOURS OR EVERY 2 YEARS

Change the DEF/AdBlue® main filter	7-70
--	------

EVERY 3600 HOURS OR EVERY 4 YEARS

Change the engine coolant fluid.....	7-71
--------------------------------------	------

GENERAL MAINTENANCE

Cleaning the tractor	7-75
Check first stage fuel filter and water trap	7-77
Bleeding the fuel system	7-78
Hydraulic system hoses	7-79
Check the brake pedal latching/unlatching	7-79
Adjust the automatic pickup hitch	7-80
Headlight adjustment	7-81
Work light adjustment	7-82
Bulb replacement	7-83
Fuses and relays	7-85
Protecting the electronic and electrical systems during battery charging or welding ..	7-95
Battery removal and installation	7-96

STORAGE

Tractor storage	7-98
Preparation for use after storage	7-98

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Introduction	8-1
--------------------	-----

ALARM(S)

Fault codes and symbols	8-2
-------------------------------	-----

SYMPTOM(S)

Engine	8-4
Transmission	8-5
Hydraulics	8-5
Three-point hitch	8-6
Brakes	8-6
Cab	8-6
Electrical system	8-7

9 SPECIFICATIONS

General dimensions	9-1
Minimum turn radius	9-3
Axle dimension	9-4
Maximum operating angle	9-5
Maximum tractor operating weights	9-6
Tractor weights	9-7
Capacities	9-8
Engine	9-9
Fuel system	9-10
Air cleaner system	9-11
Cooling System	9-12

Transmission	9-13
Rear Power Take-Off (PTO)	9-14
Front power take-off (PTO)	9-15
Three-point hitch	9-16
Three-point hitch front	9-17
Hydraulic system	9-18
Remote control valves	9-19
Front remote control valve couplers	9-20
Brakes	9-21
Steering	9-22
Electrical equipment	9-23
Minimum hardware tightening torques	9-24

10 ACCESSORIES

Radio (where fitted)	10-1
External rear view mirrors	10-2
Auxiliary head lights and signature lights	10-4
Rotating beacon	10-5
Front-end loader fixation points	10-6

1 - GENERAL INFORMATION

Note to the owner

Introduction to this manual

This manual gives information about the use of your CASE IH machine as intended and under the conditions foreseen by CASE IH during normal operation, routine service, and maintenance.

This manual does not contain all the information that relates to periodic service, conversions, and repairs that only trained service personnel can perform. Some of these activities may require appropriate facilities, technical skills, and/or tools that CASE IH does not supply with the machine.

The manual contains the chapters as shown on the Contents pages. See the Index at the end of this manual to locate specific items about your CASE IH machine.

Normal operation

Normal operation consists of the use of this machine for the purpose CASE IH intends by an operator that:

- Is familiar with the machine and any mounted equipment or towed equipment
- Complies with the information on operation and safe practices as specified by CASE IH in this manual and by the signs on the machine

Normal operation includes:

- Preparation and storage of the machine
- Addition and removal of ballast
- Connection and disconnection of mounted equipment and/or towed equipment
- Adjustment and configuration of the machine and equipment for the specific conditions of the job site, field, and/or crop
- Movement of components into and out of working positions

Routine service and maintenance

Routine service and maintenance consists of the daily activities necessary to maintain the proper machine function. The operator must:

- Be familiar with the machine characteristics
- Comply with the information on routine service and safe practices as specified by CASE IH in this manual and by the signs on the machine

Routine service can include:

- Fueling
- Cleaning

- Washing
- Topping up fluid levels
- Greasing
- Replacing consumable items such as light bulbs

Periodic service, conversions, and repairs

Periodic service consists of activities that are necessary to maintain the expected life of the CASE IH machine. These activities have defined intervals.

Trained service personnel familiar with the machine characteristics must perform these activities at the defined intervals. Trained service personnel must comply with the information on periodic service and safe practices as partly specified by CASE IH in this manual and/or other company literature.

Periodic service includes:

- Oil change service for the engine, hydraulic circuits, or transmission
- Periodic exchange of other substances or components as required

Conversion activities rebuild the CASE IH machine in a configuration that is appropriate for a specific job site, crop, and/or soil conditions (e.g., installation of dual wheels). Conversion activities must be done:

- By trained service personnel familiar with the machine characteristics
- By trained service personnel that comply with the information on conversion as partly specified by CASE IH in this manual, assembly instructions, and/or other company literature

Repair activities restore proper function to a CASE IH machine after a failure or degradation of performance. Dismantling activities occur during the scrapping and/or dismantling of the machine.

Trained service personnel familiar with the machine characteristics must perform these activities. Trained service personnel must comply with the information for repair as specified by CASE IH in the service manual.

Before you operate

Read this manual before you start the engine or operate this CASE IH machine. Contact your CASE IH dealer if:

- You do not understand any information in this manual
- You need more information
- You need assistance

All persons training to operate, or who will operate this CASE IH machine should be old enough to possess a valid local vehicle operating permit (or meet other applica-

ble local age requirements). These persons must demonstrate the ability to operate and service the CASE IH machine in a correct and safe manner.



Our support email:

ebooklibonline@outlook.com