

ORIGINAL INSTRUCTIONS - according to Regulation (EU) 2014/1322, Annex XXII

OPERATOR'S MANUAL

T7.275 AutoCommand™

T7.290 AutoCommand™

T7.315 AutoCommand™

Sidewinder II

Tractor - STAGE V

*PIN HACT7***KD701001 and above*

Part number 51607621

2nd edition English

April 2019

Replaces part number 51449975



Contents

1 GENERAL INFORMATION

Metric and imperial units abbreviations.....	1-1
To the owner.....	1-3
Operator's manual storage	1-5
Product identification	1-6
Engine identification	1-7
Drive line identification	1-8
Cab identification	1-9
Product identification plate	1-10
Noise level information sheet.....	1-11
Programming tractor functions	1-11
Before operating the tractor	1-12
International symbols.....	1-13
Vibration level information sheet	1-14
Machine stability.....	1-15
Selective Catalytic Reduction (SCR) system.....	1-19

2 SAFETY INFORMATION

Safety precautions.....	2-1
Safety decals	2-3
Safety rules.....	2-12
Burn prevention.....	2-19
Prevention of fire or explosions.....	2-20
Fire extinguisher.....	2-21
Protection offered by the tractor.....	2-22
Hazardous substances	2-25
Ecology and the environment	2-26
Emergency exit.....	2-27
Wheel chocks.....	2-28
Intended use statement	2-29
Passenger's seat	2-31
Safety aspects in accordance with Regulation (EU) 1322/2014 - Annex XXII and subsequent amendments and modifications	2-32

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Introduction	3-1
Cab air filters	3-5
In cab storage (where fitted).....	3-6
Cable and wiring routing.....	3-7
Mobile telephone usage	3-8
Implement monitor installation.....	3-9

OPERATOR'S SEAT

Operator's seat	3-10
-----------------------	------

Air suspension seat deluxe	3-11
Air suspension seat with passive or Dynamic Damping System (DDS).....	3-16
Air suspension seat 'evolution active'	3-22
Seat belt	3-29

PASSENGER'S SEAT

Passenger seat.....	3-30
---------------------	------

FORWARD CONTROLS

Ignition key	3-31
Hazard lights switch	3-31
Lights and turn indicator lever	3-32
Follow me home lights.....	3-32
Windshield wiper and washer controls	3-33
Electronic parking brake.....	3-34
Emergency brake.....	3-37
Anti-lock braking system ABS Operation	3-38
Clutch pedal	3-44
Foot brakes	3-44
Exhaust brake (where fitted)	3-48
Steering column	3-48

RIGHT-HAND SIDE CONTROLS

Integrated control panel	3-49
Multifunction Handle	3-50

REARWARD CONTROLS

Switches on C-pillar	3-51
Battery isolator switch (where fitted)	3-52
Heated screens (where fitted)	3-53
ISO bus functionality	3-54
Hydraulic master switch	3-55
Switches on right-hand trim	3-56
Advanced steering system field/road switch	3-57
Variable Ratio Steering (VRS).....	3-58
Autoguidance system.....	3-61
Autoguidance - Variable ratio steering.....	3-62
Variable ratio steering and Autoguidance symbols on color display (where fitted)....	3-63

OVERHEAD CONTROLS

Switches on roof.....	3-64
Left-hand and right-hand outermost work light switch.....	3-65
Interior light	3-66
Automatic Temperature Control (ATC)	3-67

INSTRUMENT CLUSTER

Analog Digital Instrument Cluster (ADIC)	3-68
Gauges	3-68

Indicator and warning lights	3-69
Displays	3-71
Selecting or changing the display settings	3-73
Active and Manual Catalyst Management	3-74
Manual Catalyst Management	3-76
Performance monitor	3-82
Tire Pressure Monitoring System (TPMS) (where fitted)	3-83
Armrest color display	3-86
Pop-up screens on color display	3-89
Performance monitor on color display	3-94
Programming the displays	3-99
Alarm functions	3-102
Accessing stored error codes	3-104
Selective Catalytic Reduction (SCR) exhaust treatment - Overview	3-105
Warning and advisory symbols	3-114
Warning and advisory symbols	3-128

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Refueling the tractor	4-1
-----------------------------	-----

STARTING THE UNIT

Starting the engine	4-3
Grid heater cold start aid (where fitted)	4-5
Fuel heater (where fitted)	4-5
Coolant immersion heater (where fitted)	4-6
Transmission oil heater (where fitted)	4-7

STOPPING THE UNIT

Stopping the engine	4-8
Automatic engine shut down	4-9

MOVING THE UNIT

Operating in cold temperatures	4-11
Low idle speed management	4-14
Variable Pitch Fan (VPF)	4-15

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Carrying the tractor on a transporter	5-1
Secure the high visibility roof panel	5-1

RECOVERY TRANSPORT

Freeing a stuck tractor	5-2
Towing the tractor	5-3

6 WORKING OPERATIONS

GENERAL INFORMATION

Constant engine speed	6-1
Differential lock	6-4
Four wheel drive	6-6
Front axle suspension (where fitted)	6-8
HTS standard	6-11
Headland turn sequence - Quick guide	6-11
Recording and replaying	6-13
Explanation of symbols	6-15
Recording a sequence	6-17
Replaying a sequence	6-19
HTS advanced	6-23
Headland turn sequence	6-23
Universal symbols	6-24
Recording a sequence	6-27
Creating a sequence in standstill	6-32
Replaying a sequence	6-34
Saving a sequence	6-38
Edit a sequence	6-41
Recalling a sequence	6-44
Deleting a sequence	6-48
Headland turn sequence error codes	6-49
HTS advanced with Automatic End Of Row Turn functionality	6-52
Automatic End Of Row Turn functionality	6-52
Implement setup	6-54
Creating field boundaries and headlands	6-55
Recording a sequence	6-59
Replaying a sequence	6-63

TRANSMISSION

Transmission operation	6-67
Anti jack knife	6-68
Stationary control	6-69
Engine speed control	6-70
Shuttle lever	6-72
Transmission controls	6-74
Drive pedal	6-77
Programming maximum speed	6-78
Transmission display	6-80
Manual mode	6-82
Automatic mode	6-83
Cruise mode	6-85
PTO mode	6-88
Speed matching	6-88
Pneumatic Trailer Brake Stabilization System	6-89
Fault codes	6-91

REAR POWER TAKE-OFF (PTO)

Power Take-Off (PTO) operating precautions	6-92
Changing the PTO output shaft	6-92
Attaching PTO driven equipment	6-93
PTO operation	6-94
PTO shiftable multi speed	6-98
External PTO controls	6-101
Auto PTO operation	6-103

FRONT POWER TAKE OFF

PTO operation	6-106
Auto PTO operation	6-111
External PTO controls	6-113

REAR HITCH

Electronic Draft Control (EDC)	6-115
Settings and adjustments	6-119
Electronic Draft Control (EDC) operation	6-121
External hitch controls	6-126

FRONT HITCH

Settings and adjustments	6-128
Front hitch operation	6-131
External hitch controls	6-134
Front hitch management	6-135
Auxiliary front couplers (where fitted)	6-140
External controls for front couplers	6-142

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

Remote control valves	6-143
Settings and adjustments	6-151
Valve priority	6-158
Programming tractor functions	6-159
Connecting remote cylinders	6-166
Operating with remote valves	6-169
Mid mount remote valves	6-171
External EHR controls	6-172
EHR implement control setting	6-173
Transmission rear axle and hydraulic system oil level	6-177

HYDRAULIC POWER BEYOND PORT

Power beyond circuit	6-179
ISO Power beyond couplings	6-181

THREE POINT HITCH

Attaching three-point hitch equipment	6-182
---	-------

Lift rod adjustment.....	6-184
Top link adjustment.....	6-187
Quick hitch.....	6-189
Automatic stabilizers (where fitted).....	6-191
Hydraulic stabilizers (where fitted).....	6-193

DRAWBARS AND TOWING ATTACHMENTS

Drawbars and towing attachments.....	6-195
Swinging drawbar.....	6-198
Automatic pickup hitch.....	6-200
Rear trailer hitches.....	6-205

TRAILER BRAKING SYSTEMS

Trailer brake release switch.....	6-212
Air-operated trailer brakes (Universal type).....	6-213
Air-operated trailer brakes (UK type).....	6-216
Air-operated trailer brakes (Italian type).....	6-217
Auxiliary air supply connector (where fitted).....	6-218
Hydraulic trailer brakes (Universal type - Dual line).....	6-219
Hydraulic trailer brakes (Universal type - Single line).....	6-222
Hydraulic trailer brakes (Italian type).....	6-223

WHEEL TRACK ADJUSTMENT

Tire combinations.....	6-224
Front wheel track adjustment.....	6-225
Front wheel alignment.....	6-228
Steering stops.....	6-229
Front axle oscillation stops.....	6-230
Front wheel fenders.....	6-231
Rear wheel track adjustment.....	6-233
Flange type axle (where fitted).....	6-233
Bar type axle (where fitted).....	6-235
Dual rear wheels (where fitted).....	6-238

BALLASTING AND TIRES

Ballasting and tires.....	6-240
Iron weights (where fitted).....	6-243
Liquid ballast.....	6-246
Tire inflation.....	6-248
Tire pressures and permissible loads.....	6-249

AUXILIARY POWER CONNECTIONS

Diagnostic socket.....	6-251
Trailer electrical socket.....	6-252
Electrical power connectors.....	6-253
Internal power connectors.....	6-253
External power connectors.....	6-255
ISO bus classes.....	6-257

ISO bus functionality	6-259
Reconfigurable inputs for ISO Bus function	6-267

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Fuel requirement - Diesel fuel	7-2
Fuel - Storage, handling and transport	7-2
Biodiesel fuel	7-3
Engine oils	7-5
Protective devices	7-6
Tractor jacking points	7-8
General specifications	7-9
Capacities	7-10
Organic Acid Technology (OAT) coolant	7-11

MAINTENANCE CHART

Maintenance chart	7-12
-------------------------	------

WHEN THE WARNING LAMP LIGHTS

Change the engine air cleaner outer element	7-14
Drain the fuel system water separator	7-15
Check the brake fluid level	7-16

EVERY 10 HOURS OR EACH DAY

Check the engine coolant level	7-17
Check the engine oil level	7-18
Check the remote control valve drain bottles	7-18
Check windscreen washer reservoir	7-19
Drain air reservoir on air operated trailer brake	7-19

FIRST 50 HOURS

Service operations	7-20
--------------------------	------

EVERY 50 HOURS

Clean the cab air filter	7-21
Clean the SCR cover air ducts	7-23
Clean the cooler section	7-24
Grease all fittings	7-25
Check the front and the rear wheel nuts	7-31
Check the tire pressures and the tire condition	7-31

EVERY 150 HOURS

Inspect the compressor drive belt	7-32
---	------

EVERY 375 HOURS

Inspect the poly V-belt	7-33
-------------------------------	------

Check the battery fluid level	7-33
Check the transmission oil level, the rear axle oil level and the hydraulic oil level	7-35
EVERY 750 HOURS	
Change engine oil and filter	7-36
Change the first stage fuel filter and the fuel filter element.....	7-38
Change the hydraulic charge pump oil filter and the van pump oil filter.....	7-40
Check the engine air intake connections	7-41
Check the transmission oil cooler pipe couplings	7-42
Check the 4WD front axle differential oil level and the hubs oil level.....	7-43
EVERY 750 HOURS OR EVERY YEAR	
Change the engine air cleaner outer element	7-44
EVERY 750 HOURS OR EVERY 2 YEARS	
Change the 4WD planetary hub oil	7-44
EVERY YEAR	
Check the accumulators (where fitted)	7-45
EVERY 1500 HOURS OR EVERY YEAR	
Change the cab air filters	7-45
EVERY 1500 HOURS OR EVERY 2 YEARS	
Change the engine air cleaner inner element	7-47
Change the air brake drier reservoir.....	7-48
Change the transmission oil, the rear axle oil and the hydraulic oil	7-49
Clean the lubrication pump filter.....	7-50
Change the engine breather filter	7-51
Change the Diesel Exhaust Fluid (DEF)/AdBlue® suction filter.....	7-52
Change the hydraulic suction pump oil filter.....	7-53
Change the 4WD differential oil	7-54
EVERY 2 YEARS	
Change the air conditioning receiver drier.....	7-55
EVERY 1500 HOURS OR EVERY 4 YEARS	
Change the poly V-belts	7-56
EVERY 2250 HOURS	
Check the engine tappet valve clearance	7-58
EVERY 3750 HOURS OR EVERY 3 YEARS	
Change the DEF/AdBlue® main filter	7-58

EVERY 3750 HOURS OR EVERY 4 YEARS

Change the engine coolant fluid	7-59
---------------------------------------	------

GENERAL MAINTENANCE

Cleaning the tractor	7-62
Check first stage fuel filter and water trap	7-65
Bleeding the fuel system	7-65
Hydraulic system hoses	7-66
Electrical socket maintenance	7-67
Check the brake pedal latching/unlatching	7-68
Adjust the cab suspension (where fitted)	7-69
Adjust the automatic pickup hitch	7-70
Headlight adjustment	7-71
Work light adjustment	7-71
Bulb replacement	7-72
Fuses and relays	7-74
Protecting the electronic and electrical systems during battery charging or welding ..	7-85
Battery removal and installation	7-86

STORAGE

Tractor storage	7-88
Removing the machine from storage	7-88

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Introduction	8-1
--------------------	-----

ALARM(S)

Fault codes and symbols	8-2
-------------------------------	-----

SYMPTOM(S)

Engine	8-4
Transmission	8-5
Hydraulics	8-5
Three-point hitch	8-6
Brakes	8-6
Cab	8-6
Electrical system	8-7

9 SPECIFICATIONS

General dimensions	9-1
Minimum turn radius	9-3
Axle dimension	9-4
Maximum operating angle	9-6
Maximum permissible operating weights	9-7
Tractor weights	9-7

Capacities	9-8
Engine	9-9
Fuel system.....	9-9
Air cleaner system.....	9-10
Cooling system	9-10
Transmission	9-10
Rear Power Take-Off (PTO).....	9-11
Front Power Take-Off (PTO).....	9-11
Hydraulic system	9-12
Rear three-point hitch	9-12
Front three-point hitch	9-13
Remote control valves.....	9-14
Front remote control valve.....	9-14
Brakes	9-15
Steering.....	9-15
Electrical equipment.....	9-16
Minimum hardware tightening torques	9-17

10 ACCESSORIES

Radio (where fitted).....	10-1
External rear view mirrors	10-1
Border marker plates	10-3
Auxiliary head lights and signature lights.....	10-4
Rotating beacon	10-4
Auxiliary pneumatic coupler	10-5

11 FORMS AND DECLARATIONS

Service record 1st 50 hour, Owner copy	11-1
Service record 1st 50 hour, Dealer copy	11-3
Telematics module declaration of conformity.....	11-4

1 - GENERAL INFORMATION

Metric and imperial units abbreviations

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	ha	acre	ac
	square meter	m²	square foot	ft²
			square inch	in²
	square millimeter	mm²	square inch	in²
Electricity				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	µF	microfarad	µF
	ohm	Ω	ohm	Ω
Force				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
Force per length				
	newton per meter	N/m	pound per foot	lb/ft
			pound per inch	lb/in
Frequency				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
Frequency – Rotational				
	revolution per minute	r/min	revolution per minute	r/min ^a
		rpm		rpm
Length				
	kilometer	km	mile	mi
	meter	m	foot	ft
	centimeter	cm	inch	in
	millimeter	mm	inch	in
	micrometer	µm		
Mass				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
Mass per mass				
	milligram per kilogram	mg/ kg	parts per million	ppm
Power				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour	Btu/hr
			Btu per minute	Btu/min
Pressure or stress (Force per area)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH2O
	megapascal	MPa	pound per square inch	psi
	millibar	mbar		
	bar	bar		

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
Torque (includes bending moment, moment of force, and moment of a couple)				
	newton meter	N m	pound foot	lb ft
			pound foot	lb in
Velocity				
	kilometer per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimeter per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
Volume (includes capacity)				
	cubic meter	m ³	cubic yard	yd ³
				cu yd
	liter	l	cubic inch	in ³
	liter	l	US gallon	US gal
			UK gallon	UK gal
			US quart	US qt
			UK quart	UK qt
	milliliter	ml	fluid ounce	fl oz
Volume per time (includes discharge and flow rate)				
	cubic meter per minute	m ³ /min	cubic foot per minute	ft ³ /min
	liter per minute	l/min	US gallon per minute	US gal/min
	milliliter per minute	ml/min	UK gallon per minute	UK gal/min
Sound power level and sound pressure level				
	decibel	dB	decibel	dB
Water hardness				
	German hardness	°dH	English hardness	°e
	French hardness	°fH	parts per million	ppm

Glossary

Acronym	Definition
DEF	Diesel Exhaust Fluid
ISO	International Organization for Standardization
MSDS	Material Safety Data Sheet
NOx	Nitrogen Oxide
PPE	Personal Protective Equipment
SCR	Selective Catalytic Reduction
ULSD	Ultra Low Sulfur Diesel
%	Percent
<	Less than
>	Greater than

To the owner

General information

This manual has been prepared according to ISO 3600:1996 to assist you in the correct procedure for running-in, driving and operating and for the maintenance of your new tractor. Read this manual carefully. Your tractor is intended for use in normal and customary agricultural applications.

If at any time you require advice concerning your tractor, do not hesitate to contact your authorised dealer. He has factory trained personnel, genuine manufacturers' parts and the necessary equipment to carry out all your service requirements.

The specification are provided for your information and guidance. For further information concerning your tractor and equipment, consult your authorised dealer.

All data given in this manual is subject to production variations. Dimensions and weight are approximate only. The illustrations do not necessarily show tractors in standard condition or imply that these features are available in all countries. For exact information about any particular tractor, please consult your authorised dealer.

Your tractor has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Your tractor fulfills all requirements as specified in the Regulation (EU) No 167/2013 of the European Parliament and of the Council. Prior to delivery, the tractor was carefully inspected, both at the factory and by your dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble-free operation, it is important that the routine services, as specified on page 7-12 of this Manual, are carried out at the recommended intervals.

All persons training to operate, or who will operate this tractor should be old enough to possess a valid local vehicle operating permit (or meet other applicable local age requirements). These persons must demonstrate the ability to operate and service the tractor in correct and safe manner.

About this manual

This manual gives information for use of your machine, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance.

Read and understand; keep it in good condition and always safely store it in the provided pocket in the back of your seat for later easy retrieval.

This manual does not contain all the information related to periodical service, converting and repairs to be carried out by professional service personnel.

The Table of Contents page(s) are provided to have an overview of main manual's topics. A detailed alphabetic index is available at the end of this manual for locating specific items.

Normal operation

- Normal operation means the use of the tractor for the purpose intended by the manufacturer by an operator familiar with the tractor and the mounted or towed equipment and complying with the information for operation and safe practices, as specified by the manufacturer in this manual and by the decals on the tractor and the equipment.
- Normal operation includes the preparation and storage of the tractor, swinging components into work position and vice versa, adding or removing ballast and picking up and setting off attachments.
- Normal operation includes the adjustment and setting of the tractor and equipment, for the specific condition of the field and/ or the crop.

Routine service

- Routine service and maintenance means activities that must be done daily by an operator familiar with the tractor characteristics and complying with the information for routine service and safe practices, as specified by the manufacturer in this manual and by decals on the tractor, in order to maintain its proper function. Routine service includes activities such as fueling, cleaning, washing, topping up fluid levels, greasing, replacing of consumable articles such as lamp bulbs.

Converting, periodical service and repair

- Periodical service means activities that must be done at defined intervals by trained personnel familiar with the tractor characteristics and which are complying with the information for periodical service and safe practices, as partly specified by the manufacturer in this manual and in other Company literature, in order to maintain the expected life time of the tractor.
- Converting means activities that must be done by professional service personnel familiar with the tractor characteristics and complying with the information for converting, as partly specified by the manufacturer in this manual, in assembly instructions or in other Company literature, in order to fit the tractor to a specific configuration.
- Repair means activities that must be done by professional service personnel only familiar with the tractor characteristics and complying with the information for repair, as specified by the manufacturer in the dealer's workshop manual, in order to restore the proper function of the tractor after a failure or degradation of performance.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com