

OPERATOR'S MANUAL


T4030F

T4040F

T4050F

T4060F

Tractors



Part number 84518034

2nd edition English

February 2012



Contents

1 GENERAL INFORMATION

Note to the Owner	1-1
Proposition 65	1-2
Electro-magnetic interference (EMC).....	1-3
International symbols	1-4
Introduction	1-6
Tractor intended use.....	1-7
Ecology and the Environment	1-9
Identification plates	1-10
Component Identification	1-12

2 SAFETY INFORMATION

Safety rules and signal word definitions	2-1
Safety information	2-2
Air conditioning safety regulations.....	2-6
Roll over protective structure (ROPS).....	2-7
Machine stability	2-8
Tractor jacking points	2-10
Safety signs	2-11

3 CONTROLS/INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Cab	3-1
Heating system	3-4
Heating, ventilation or air-conditioning control	3-5
Cab air filter.....	3-7

OPERATOR'S SEAT

Operator seat.....	3-9
--------------------	-----

FORWARD CONTROLS

Analogue dashboard	3-11
Digital dashboard	3-16
Front controls	3-22

LEFT-HAND SIDE CONTROLS

Console Left - Control identification	3-26
Parking brake for hydraulic transmissions.....	3-27

RIGHT-HAND SIDE CONTROLS

Console Right - Control identification.....	3-28
---	------

REARWARD CONTROLS

Console - Control identification	3-30
--	------

EXTERIOR CONTROLS

Console - Control identification	3-31
--	------

DISPLAY SETTINGS

Instrument panel - Program	3-32
----------------------------------	------

TRANSMISSION

TRANSMISSION - Operating 4WD models	3-39
Transmission with gear reducer and mechanical reversing mechanism	3-40
Transmission with gear reducer and electrohydraulic reversing mechanism	3-43
Parking brake for hydraulic transmissions.....	3-46
Transmission with gear reducer, electrohydraulic reversing mechanism and HI-LO control	3-47
Transmission with gear reducer, electrohydraulic reversing mechanism, HI-LO control and electrohydraulic clutch.....	3-50

4 OPERATING INSTRUCTIONS

STARTING THE UNIT

STARTING SYSTEM - Safety rules	4-1
STARTING SYSTEM - Care.....	4-2
STARTING SYSTEM - Start.....	4-3

STOPPING THE UNIT

STARTING SYSTEM - Stop	4-5
------------------------------	-----

MOVING THE UNIT

Moving the machine	4-6
--------------------------	-----

5 TRANSPORT OPERATIONS

ROAD TRANSPORT

Transporting the machine	5-1
--------------------------------	-----

PREPARING FOR ROAD TRANSPORT

Wheels and tires.....	5-2
Tyre dimensions	5-6
Wheel tread settings.....	5-8
Tire Combinations and Tread Positions	5-11
Ballast	5-14
Maximum permitted weights.....	5-15

RECOVERY TRANSPORT

Towing the tractor	5-17
--------------------------	------

6 WORKING OPERATIONS

GENERAL INFORMATION

2WD-4WD SYSTEM Hydraulic - Operating	6-1
Differential lock system	6-2
Differential lock command Mechanical - Operating	6-3
Power take off (PTO)	6-4
Hydraulic lift	6-6
Hydraulic lift with electronic control	6-9
Three-point linkage	6-14
Additional equipment attachment points	6-18
Rear remote control valve(s)	6-20
Electrohydraulically controlled side hydraulic valves	6-24
Side hydraulic valves	6-26
Maintenance	6-27

7 MAINTENANCE

GENERAL INFORMATION

Introduction	7-1
Various controls	7-3
Body maintenance	7-4
Break-in period	7-6
Fuel supply	7-7
General specification - Biodiesel Fuels	7-8
Opening the hood	7-9

MAINTENANCE CHART

Maintenance Chart	7-10
-------------------------	------

AS REQUIRED

Radiator expansion tank	7-13
Windscreen washer tank	7-13
Road light - Check	7-13
Clutch pedal adjustment	7-14
PARKING BRAKE - Adjust	7-14
Radiator - Cleaning	7-14
Tire pressure	7-15
Wheel nuts torque	7-15
Brake pedals	7-15

AT WARNING MESSAGE DISPLAY

Engine air filters	7-16
Fuel filter water drain	7-17
Brake fluid level	7-17

EVERY 10 HOURS OR EACH DAY

Engine oil level	7-19
------------------------	------

EVERY 50 HOURS

Rear wheel hub.....	7-20
Lift and linkage	7-20
2WD steering cylinder	7-20
4WD steering cylinders.....	7-21
2WD front axle pivot	7-21
4WD front axle pivot	7-21
4WD transmission shaft	7-22
2WD right and left-hand stub axle	7-22
Front lift arms shaft	7-22
Front PTO coupling.....	7-23

EVERY 100 HOURS

Transmission oil cooler	7-24
Air conditioning condenser	7-24
Intercooler	7-24
Cab air filter.....	7-25
Cab recirculated air filter	7-25

EVERY 300 HOURS

Alternator belt.....	7-26
Battery - Check	7-26
Transmission oil filter	7-26
Oil filter models with power shuttle/dual command.....	7-27
Engine air filters	7-27
Transmission oil level.....	7-27
4WD front axle housing.....	7-28
4WD front axle final drives	7-28
4WD front axles stub	7-28
2WD front wheels.....	7-29

EVERY 500 HOURS

Engine oil and filter	7-30
Fuel filter.....	7-31
Fuel pre-filter	7-32

EVERY 600 HOURS

Engine oil and filter	7-33
Fuel filter.....	7-34
Fuel pre-filter	7-35

EVERY 1200 HOURS OR ANNUALLY

Cab air filters	7-36
Cab recirculated air filter	7-36

Engine air filters	7-36
Fuel tank.....	7-37

EVERY 1200 HOURS OR EVERY 2 YEARS

4WD front axle housing.....	7-38
Engine valves.....	7-38
Change transmission oil.....	7-39
Washing cooling system.....	7-40

EVERY 1800 HOURS

Fuel injector - Check	7-43
-----------------------------	------

ELECTRICAL SYSTEM

Battery	7-44
Fuses and relays	7-46
Fuses and relays location	7-47
Fuses and relays location	7-49
Fuses and relays location Fuses and relays on cab right hand upright	7-51
Power sockets	7-51
Power sockets	7-52
Head light - Adjust	7-53
Head light - Replace.....	7-54
Brake, direction and rear lamp replacing	7-54
Number plate light	7-54
Front sidelight and marker light replacing	7-55
Front and rear work lights	7-55
Work lights for tractors with roll bar.....	7-55
Interior light	7-56

CALIBRATIONS

Dual command calibration.....	7-57
-------------------------------	------

BODYWORK MAINTENANCE

General	7-60
---------------	------

FLUIDS AND LUBRICANTS

LUBRICATION SYSTEM - Change fluid	7-62
---	------

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Display fault codes	8-1
TROUBLESHOOTING ENGINE	8-3
ELECTRICAL POWER SYSTEM - Troubleshooting ELECTRICAL SYSTEM	8-5
PRIMARY HYDRAULIC POWER SYSTEM - Troubleshooting HYDRAULIC SYSTEM	8-6

HITCH - Troubleshooting HYDRAULIC LIFT AND 3-POINT LINKAGE	8-7
SERVICE BRAKE - Troubleshooting	8-8
ENVIRONMENT CONTROL - Troubleshooting	8-9

ALARM(S)

Alarms	8-10
Alarms, cause, solutions	8-12

9 SPECIFICATIONS

Technical data	9-1
----------------------	-----

10 ACCESSORIES

Radio	10-1
Towing equipment	10-6
Quick coupling three point linkage	10-8
FRONT PTO - Operating	10-10
Front hydraulic lift	10-12
Quick coupling three point linkage	10-14

1 - GENERAL INFORMATION

Note to the Owner

This manual contains information concerning the adjustment and maintenance of your new equipment. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this equipment. Please have all operators read this manual carefully and keep it available for ready reference.

Your NEW HOLLAND AGRICULTURE dealer will instruct you in the general operation of your new equipment. Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your machine.

New Holland Top Service is also available. Call 1-866-NEWHLND (1-866-639-4563) or email: na.topservice@cnh.com.

Your NEW HOLLAND AGRICULTURE dealer carries a complete line of genuine NEW HOLLAND AGRICULTURE service parts. These parts are manufactured and carefully inspected to insure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and product identification number of your new equipment when ordering parts. Locate these numbers now and record them below. Refer to the 'General Information' section of this manual for the location of the model and product identification numbers of your machine.

PLEASE RECORD THE FOLLOWING INFORMATION
Model:
Product Identification Number (PIN):



This is the safety alert symbol. It is used with and without signal words to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

⚠ WARNING

**Illustrations in this manual may show protective shielding open or removed to better illustrate a particular feature or adjustment.
Replace all shields before operating the machine.
Failure to comply could result in death or serious injury.**

W0012A

Engine tampering statement:

ATTENTION: *The fuel system and engine on your machine are designed and built to government emissions standards. Tampering by dealers, customers, operators and users is strictly prohibited by law. Failure to comply could result in government fines, rework charges, invalid warranty, legal action and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*

Improvements

CNH America LLC is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

Proposition 65

CALIFORNIA Proposition 65 Warning
Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.

Electro-magnetic interference (EMC)

Interference may arise as a result of add-on equipment which may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the machine.
- The electro-magnetic field generated by the add-on system should not exceed **24 V/m** at any time and at any location in the proximity of electronic components.
- The add-on equipment must not interfere with the functioning of the on board electronics.

Failure to comply with these rules will render the [brand] warranty null and void.

International symbols

TYPICAL APPLICATIONS	RECOMMENDED SI (METRIC) UNITS		IMPERIAL UNIT	
	NAME	SYMBOL	NAME	SYMBOL
AREA				
	hectare	ha	acre	ha
	square meter	m ²	square foot	ft ²
			square inch	in ²
	square millimetre	mm ²	square inch	in ²
ELECTRICITY				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	μF	microfarad	μF
	ohm	Ω	ohm	Ω
FORCE				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
FORCE PER LENGTH				
	Newton metres	N/m	pound per inch	lb/in
FREQUENCY				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
FREQUENCY - ROTATIONAL				
	revolution per minute	r/min	revolution per minute	r/min ^a
		rpm		rpm
LENGTH				
	kilometre	km	mile	mi
	meter	m	foot	ft
	centimetre	cm	inch	in
	millimetre	mm	inch	in
	micrometer	μm		
MASS				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
POWER				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu/hour	Btu/hr
			Btu/minute	Btu/min
PRESSURE or STRESS (FORCE PER AREA)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH ₂ O
	megapascal	MPa	pound per square inch	psi

1 - GENERAL INFORMATION

TYPICAL APPLICATIONS	RECOMMENDED SI (METRIC) UNITS		IMPERIAL UNIT	
	NAME	SYMBOL	NAME	SYMBOL
TEMPERATURE (other than THERMODYNAMIC)				
	degrees Celsius	°C	degrees Fahrenheit	°F
TIME				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
TORQUE (includes BENDING MOMENT, MOMENT OF FORCE, and MOMENT OF A COUPLE)				
	Newton per metre	N m	feet-pounds	lb ft
			inch-pound	lb in
VELOCITY				
	kilometre per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimetre per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
VOLUME (includes CAPACITY)				
	cubic meter	m³	cubic yard	yd³ (cu yd)
	litre	l	cubic inch	in³
	litre	l	US gallon	US gal
			U.K. gallon	UK gal
			US quart	US qt
			U.K. quart	UK qt
	millilitre	ml	fluid ounce	fl oz
VOLUME PER TIME (includes DISCHARGE and FLOW RATE)				
	cubic meter per minute	m³/min	cubic foot per minute	ft³/min
	litre per minute	l/min	US gallon per minute	US gal/min
	millilitre per minute	ml/min	UK gallon per minute	UK gal/min
SOUND POWER LEVEL and SOUND PRESSURE LEVEL				
	decibel	dB	decibel	dB

Introduction

About this manual

⚠ DANGER

Improper operation or service of this machine can result in an accident.

Do not operate this machine or perform any lubrication, maintenance, or repair on it until you have read and understood the operation, lubrication, maintenance, and repair information.

Failure to comply will result in death or serious injury.

D0010A

This manual gives information for use of your machine, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance. Read and understand; keep it in good conditions and always safely store it in the provided pocket in the back of your seat for later easy retrieval. This manual does not contain all the information related to periodical service, converting and repairs to be carried out by professional service personnel. The Table of Contents page(s) are provided to have an overview of main manual's topics. A detailed alphabetic index is available at the end of this manual for locating specific items.

Normal operation

- Normal operation means the use of the tractor for the purpose intended by the manufacturer by an operator familiar with the tractor and the mounted or towed equipment and complying with the information for operation and safe practices, as specified by the manufacturer in this manual and by the decals on the tractor and the equipment.
- Normal operation includes the preparation and storage of the tractor, swinging components into work position and vice versa, adding or removing ballast and picking up and setting off attachments.
- Normal operation includes the adjustment and setting of the tractor and equipment, for the specific condition of the field and/or the crop.

Routine service

Routine service and maintenance means activities that must be done daily by an operator familiar with the tractor characteristics and complying with the information for routine service and safe practices, as specified by the manufacturer in this manual and by decals on the tractor, in order to maintain its proper function. Routine service includes activities such as fueling, cleaning, washing, topping up fluid levels, greasing, replacing of consumable articles such as lamp bulbs.

Converting, periodical service and repair

- Periodical service means activities that must be done at defined intervals by trained personnel familiar with the tractor characteristics and which are complying with the information for periodical service and safe practices, as partly specified by the

manufacturer in this manual and in other Company literature, in order to maintain the expected life time of the tractor.

- Converting means activities that must be done by professional service personnel familiar with the tractor characteristics and complying with the information for converting, as partly specified by the manufacturer in this manual, in assembly instructions or in other Company literature, in order to fit the tractor to a specific configuration.
- Repair means activities that must be done by professional service personnel only familiar with the tractor characteristics and complying with the information for repair, as specified by the manufacturer in the dealer's workshop manual, in order to restore the proper function of the tractor after a failure or degradation of performance.

Spare Parts

"Non-original" spare parts have not been tested or authorised by the Manufacturer. Installment and/or use of such products may adversely affect the tractor's design specifications, thereby compromising operational safety. The manufacturer cannot be held responsible for any damage resulting from the use of "non-original" spare parts. No modifications may be made to the tractor without written authorisation from the Manufacturer.

Warranty

The tractor is guaranteed in accordance with current legislation in your country and in line with contractual agreements reached with the dealer at the time of sale. However, the warranty is no longer valid if the rules and instructions for the use and maintenance of the tractor, described in this Manual, are not observed.

Cleaning the tractor

Your tractor is an advanced machine, fitted with an electrohydraulic control system. Care must be taken when cleaning the tractor, especially if a pressurized water cleaner is used.

Never stand too close to the tractor or direct the water jet on electrical components, seals or intake openings, etc. Never direct jets of cold water at the hot engine or exhaust.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com