BS163H 63" Two Stage Snowblower 717151066

For Farmall 31, Farmall 35, Farmall 40, Farmall 45, Farmall 50 Tractors

Operator's Manual

84518857 07/11 (OM 0405SB63-A)



TABLE OF CONTENT

INTRODUCTI	ION -TO THE PURCHASER	3
SAFETY PRE	ECAUTIONS	4
Before C	Operation	4
Notice		5
The Sno	owblower	5
	Before Operation	5
	Snowblower Operation	6
The Tra	ctor	7
	General Information	7
	Operating the Tractor	7
	During Operation	8
	Roll-Over Protective Structure (ROPS)	8
Mainten	ance	9
Transpo	orting	10
Storage		10
DECALS		11
ASSEMBLY		12
Snowblower Assembly		12
	Snowblower Assembly	12
	Installation of the Chute	12
	Snowblower Installation	13
Detachir	ng Snowblower from Male Quick Hitch	14

TABLE OF CONTENT

OPERATION	15	
General Preparation		
Engine Speed	15	
Increasing Traction and Stability	15	
Engaging the Drive Mechanism	15	
Deflector Adjustment	16	
Auger Drive Chain Adjustment	16	
Skid Shoe Adjustment	16	
Snow Removal Methods	17	
MAINTENANCE	18	
Shear Bolts	18	
Gearbox and Reduction Box	19	
Oil Level – Oil Filling	19	
Oil Change	19	
LUBRICATION	20	
PART	21	
Introduction	21	
Chute with Hydraulic Rotation	22	
Snowblower Assembly - Front	24	
Snowblower Assembly - Back		
Driveline Female Half		
Reduction Box Assembly	29	
Gearbox Assembly	30	
AVAILABLE OPTIONS	31	
AVAILABLE EQUIPMENT		
TORQUE SPECIFICATION TABLE	33	

INTRODUCTION

TO THE PURCHASER

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. Read and understand this manual before operation.

This manual has been prepared to assist the owner and operators in the safe operation and suitable maintenance of the equipment. The information was applicable to products at the time of manufacture and does not include modifications made afterwards.

Read and understand this operator's manual before attempting to put equipment into service. Familiarize yourself with the operating instructions and all the safety recommendations contained in this manual and those labeled on the equipment and on the tractor. Follow the safety recommendations and make sure that those with whom you work follow them.


Illustrations

The illustrations may not necessarily reproduce the full detail and the exact shape of the parts or depict the actual models, but are intended for reference only.

Direction Reference

All references to right and left, forward or rearward, are from the operator's seat, facing the steering wheel.

Serial Plate



To assist your dealer in handling your needs, please record hereafter the model number and serial number of your equipment and tractor. It is also advisable to supply them to your insurance company. It will be helpful in the event that an equipment or tractor is lost or stolen.

	TRACTOR	<u>IMPLEMENT</u>
MODEL:		
WODEL.		
SERIAL NUMBER:		
DATE OF PURCHASE:		
DEALER NAME:		

SAFETY PRECAUTIONS



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.

A DANGER: Indicates an immediate hazardous situation which, if not avoided, will

result in death or serious injury.

WARNING: Indicates a potentially hazardous situation which, if not avoided, could

result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation which, if not avoided, may

result in minor or moderate injury.

IMPORTANT: Indicates that equipment or property damage could result if instructions

are not followed.

NOTE: Gives helpful information.

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. Read and understand this manual before operation. It is the owner's responsibility to be certain anyone operating this product reads this manual, and all other applicable manuals, to become familiar with this equipment and all safety precautions. Failure to do so could result in serious personal injury or equipment damage. If you have any questions, consult your dealer.

BEFORE OPERATION

<u>Children</u>

- Tragic accidents can occur if the operator is not alert to the presence of children. Children are generally attracted to machines and the work being done. Never assume children will remain where you last saw them.
- Keep children out of the operating area and under the watchful eye of another responsible adult.
- **3.** Be alert and turn machine off if children enter the work area.
- **4.** Before and when backing, look behind for small children.

- 5. Never carry children while operating the machine. They may fall off and be seriously injured or interfere with the safe operation of the machine.
- **6.** Never allow children to play on the machine or attachment even when they are turned off.
- **7.** Never allow children to operate the machine even under adult supervision.
- **8.** Use extra care when approaching blind corners, shrubs, trees, or other obstructions that might hide children from sight.

SAFETY PRECAUTIONS - continued

NOTICE

A safe operator is the best assurance against accidents. All operators, no matter how experienced they may be, should read this operator's manual and all other related manuals before attempting to operate the equipment. Please read the following section and pay particular attention to all safety recommendations contained in this manual and those labeled on the equipment and on the tractor.

THE SNOWBLOWER

Before Operation

- Read and understand this operator's manual and tractor operator's manual. Know how to operate all controls and how to stop the unit and disengage the controls quickly.
- 2. Never wear loose, torn, or bulky clothing around the tractor and the snowblower. It may catch on moving parts or controls, causing injury.
- 3. Before and during the snow season, thoroughly inspect the area where the equipment is to be used and remove all objects that may be thrown or cause damage to the equipment.
- **4.** Set transmission to neutral and disengage clutch, if equipped, before starting the engine.
- **5.** Do not operate equipment in wintertime without wearing adequate winter garments and protective clothing.

- 6. Never attempt to make any adjustments while engine is running. Read this manual carefully to acquaint yourself with the equipment as well as the tractor operator's manual. Working with unfamiliar equipment can lead to accidents. Be thoroughly familiar with the controls and proper use of the equipment.
- **7.** Keep all safety guards in place and verify hardware for proper tightening.
- **8.** Check for moving parts excessive wear regularly. Replace worn parts with genuine parts.
- Replace all missing, illegible, or damaged safety and warning decals. See list of decals in operator's manual.
- **10.** Keep safety decals clean of dirt and grime.
- 11. Do not modify or alter this equipment or any of its components, or any equipment function without first consulting your dealer.
- **12.** Use of rear counterweights is recommended. Weights provide the necessary balance to improve stability, traction and steering. Use only those recommended by your dealer.

SAFETY PRECAUTIONS - continued

SNOWBLOWER OPERATION

- Before leaving the tractor unattended, take all possible precautions. Park the tractor/snowblower on level ground, place the transmission in neutral, set the parking brake, disengage the PTO, lower the equipment to the ground, place all levers including auxiliary control levers in neutral, shut off the engine and remove the ignition key.
- 2. Before starting the tractor/ snowblower, remove any ice that has accumulated in the auger/fan.
- Prior to operation, clear work area of all objects that can be picked up and thrown.
 Mark all curbs, pipes, etc. that cannot be moved.
- 4. Be sure the PTO switch/lever is in OFF position before starting engine.
- Exercise extreme caution when operating on or crossing a gravel drive, walks, or roads. Stay alert for hidden hazards or traffic.
- 6. Do not carry passengers.
- 7. Adjust collector-housing height to clear gravel or crushed rock surface.
- 8. Keep clear of rotating parts. Do not put hands or feet under, or into snowblower with engine running.
- 9. Park the tractor/snowblower on level ground, place the transmission in neutral, set the parking brake, disengage the PTO, lower the equipment to the ground, place all control levers in neutral, shut off the engine, remove the ignition key and allow the rotating parts to stop BEFORE unclogging the collector/fan housing or chute, and making any repairs, adjustments or inspections. Use only a 36" long piece of wood to unclog blower.

- If the snowblower starts to vibrate abnormally, disengage the PTO, stop the engine immediately and check for cause. Excessive vibration is generally a sign of trouble.
- 11. Do not run the engine indoors except when starting engine and transporting attachment in or out of building. Carbon monoxide gas is colorless, odorless and deadly.
- 12. Do not attempt to operate on steep slopes. If operating on slopes is necessary, exercise extreme caution when changing direction.
- 13. Never operate snowblower without guards, and other safety protective devices in place.
- Keep clear of chute discharge. This chute has the capability of throwing objects at far distances.
- Never operate snowblower near glass enclosures, automobiles, window wells, embankments, etc., without proper adjustment of snow discharge angle.
- 16. Never operate machine at high transport speeds on a slippery surface.
- 17. Use extra caution when backing up.
- 18. Do not direct discharge at bystanders or animals. Ejected objects may cause injury.
- 19. Disengage power to auger/fan when transporting or when not in use.
- 20. Never operate the snowblower without good visibility and lighting.
- 21. Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable noises.
- 22. Never allow anyone near the work area.



Our support email: ebooklibonline@outlook.com