

# OPERATOR'S MANUAL

---


**T7.220**

**T7.235**

**T7.250**

**T7.260**

Power Command Tractors



**Part number 84571681**

3rd edition English

January 2012





## OPERATOR'S MANUAL



**T7.220 Power Command**  
**T7.235 Power Command**  
**T7.250 Power Command**  
**T7.260 Power Command**

# Contents

---

## 1 GENERAL INFORMATION

METRIC AND IMPERIAL UNITS ABBREVIATIONS .....	1-1
TO THE OWNER .....	1-3
PRODUCT IDENTIFICATION .....	1-5
ENGINE IDENTIFICATION .....	1-6
DRIVELINE IDENTIFICATION .....	1-7
CAB IDENTIFICATION .....	1-8
ECOLOGY AND THE ENVIRONMENT .....	1-9
NOISE LEVEL .....	1-10
PROGRAMMING TRACTOR FUNCTIONS .....	1-11
BEFORE OPERATING THE TRACTOR .....	1-12
INTERNATIONAL SYMBOLS .....	1-13
VIBRATION LEVEL INFORMATION SHEET .....	1-14
MACHINE STABILITY .....	1-15
INSTRUCTOR'S SEAT .....	1-19
SELECTIVE CATALYTIC REDUCTION (SCR) SYSTEM .....	1-20

## 2 SAFETY INFORMATION

SAFETY DECALS .....	2-1
SAFETY PRECAUTIONS .....	2-8
BEFORE DRIVING THE TRACTOR .....	2-9
DRIVING THE TRACTOR .....	2-10
OPERATING THE TRACTOR .....	2-11
OPERATING THE P.T.O. ....	2-13
OPERATING THE EXTERNAL CONTROLS .....	2-13
SERVICING THE TRACTOR .....	2-14
DIESEL FUEL .....	2-16
PREVENTION OF FIRE OR EXPLOSION .....	2-17
FIRE EXTINGUISHER .....	2-18
PROTECTION OFFERED BY THE TRACTOR .....	2-19
INTENDED USE STATEMENT .....	2-22
SAFETY ASPECTS .....	2-24

## 3 CONTROLS/INSTRUMENTS

### ACCESS TO OPERATOR'S PLATFORM

INTRODUCTION .....	3-1
CAB AIR FILTERS .....	3-5
IN CAB STORAGE (where fitted) .....	3-6
CABLE AND WIRING ROUTING .....	3-7
MOBILE TELEPHONE USAGE .....	3-7
IMPLEMENT MONITOR INSTALLATION .....	3-8
CAB AIR PRESSURISATION MONITOR (where fitted) .....	3-8

### OPERATOR'S SEAT

AIR SUSPENSION SEAT .....	3-10
AIR SUSPENSION SEAT DELUXE .....	3-12
SEAT BELT .....	3-17

### INSTRUCTOR'S SEAT

---

INSTRUCTIONAL SEAT (where fitted).....	3-18
<b>FORWARD CONTROLS</b>	
KEY- START SWITCH .....	3-19
HAZARD WARNING LIGHT SWITCH.....	3-19
LIGHT-/ TURN LEVER .....	3-20
FOLLOW ME HOME LIGHTS.....	3-20
WINDSHIELD WIPER AND WASHER CONTROLS .....	3-21
SHUTTLE LEVER .....	3-22
ELECTRONIC PARK BRAKE .....	3-25
CLUTCH/ INCHING PEDAL.....	3-29
FOOT THROTTLE PEDAL .....	3-30
FOOT BRAKES .....	3-31
STEERING COLUMN .....	3-32
ADJUSTABLE AIR VENTS .....	3-33
<b>LEFT-HAND SIDE CONTROLS</b>	
HANDBRAKE.....	3-34
<b>RIGHT-HAND SIDE CONTROLS</b>	
SWITCH PANEL.....	3-35
<b>REARWARD CONTROLS</b>	
SWITCH PANEL C- PILLAR.....	3-36
BATTERY ISOLATOR SWITCH .....	3-37
CLIMATE CONTROLS .....	3-38
MANUAL TEMPERATURE CONTROL .....	3-39
AUTOMATIC TEMPERATURE CONTROL (ATC).....	3-40
<b>OVERHEAD CONTROLS</b>	
SWITCH PANEL WORKLIGHTS .....	3-41
RADIO/CASSETTE/CD PLAYER (where fitted).....	3-42
INTERIOR LIGHT .....	3-42
<b>INSTRUMENT CLUSTER</b>	
ANALOGUE/ DIGITAL INSTRUMENT CLUSTER .....	3-44
GAUGES .....	3-44
INDICATOR AND WARNING LIGHTS .....	3-45
DISPLAYS.....	3-47
KEYPAD ENHANCED.....	3-50
SELECTING OR CHANGING THE DISPLAY SETTINGS .....	3-52
GROUND SPEED CALIBRATION.....	3-53
TRANSMISSION Powershift - Operating Ground speeds .....	3-58
PERFORMANCE MONITOR.....	3-63
ALARM FUNCTIONS .....	3-71
ACCESSING STORED ERROR CODES .....	3-73
WARNING AND ADVISORY SYMBOLS .....	3-74
COLOUR MONITOR (Where fitted) .....	3-84
POP- UP SCREENS .....	3-86
PERFORMANCE MONITOR ON COLOUR DISPLAY .....	3-92
SETTING THE IMPLEMENT WIDTH .....	3-95

---

## 4 OPERATING INSTRUCTIONS

### COMMISSIONING THE UNIT

TRACTOR REFUELLING .....	4-1
--------------------------	-----

### STARTING THE UNIT

STARTING THE ENGINE .....	4-3
GRID HEATER COLD START AID (where fitted) .....	4-4
FUEL HEATER (where fitted) .....	4-5
COOLANT IMMERSION HEATER (where fitted) .....	4-5
TRANSMISSION OIL HEATER (where fitted) .....	4-6
BOOSTING THE BATTERY .....	4-7

### STOPPING THE UNIT

STOPPING THE ENGINE .....	4-8
AUTOMATIC ENGINE SHUTDOWN .....	4-8
AUTOMATIC ENGINE SHUTDOWN WITH ENHANCED KEYPAD (where fitted) .....	4-9

### MOVING THE UNIT

OPERATING IN COLD TEMPERATURES .....	4-10
FULL POWERSHIFT TRANSMISSION .....	4-11
TRANSMISSION OPERATION .....	4-11
Electronic control - Control .....	4-12
DRIVING THE TRACTOR .....	4-13
TRANSMISSION Powershift - Operating .....	4-15
SPEED MATCHING .....	4-19
PROGRAMMING REVERSE GEAR RATIOS .....	4-20
CREEPER GEARS (where fitted) .....	4-22

## 5 TRANSPORT OPERATIONS

### PREPARING FOR ROAD TRANSPORT

CARRYING THE TRACTOR ON A TRANSPORTER .....	5-1
SECURE THE HIGH VISIBILITY ROOF PANEL .....	5-1

### RECOVERY TRANSPORT

TOWING THE TRACTOR .....	5-2
--------------------------	-----

## 6 WORKING OPERATIONS

### GENERAL INFORMATION

VARIABLE ENGINE POWER MANAGEMENT .....	6-1
CONSTANT ENGINE SPEED .....	6-3
DIFFERENTIAL LOCK .....	6-5
FOUR WHEEL DRIVE .....	6-7
FRONT AXLE SUSPENSION (where fitted) .....	6-9
AUTOMATED HEADLAND FUNCTIONS .....	6-10
QUICK GUIDE .....	6-10

---

RECORDING AND RE-PLAYING .....	6-12
EXPLANATION OF SYMBOLS.....	6-14
RECORDING A SEQUENCE .....	6-15
RE-PLAYING A SEQUENCE.....	6-17
FAST STEERING SYSTEM (where fitted) .....	6-19

## TRANSMISSION

FOOT THROTTLE PEDAL .....	6-21
HAND THROTTLE .....	6-21
SHUTTLE LEVER .....	6-22
ERROR CODES.....	6-23

## REAR POWER TAKE-OFF

P.T.O. OPERATING PRECAUTIONS.....	6-24
CHANGING THE P.T.O. OUTPUT SHAFT .....	6-24
ATTACHING P.T.O. DRIVEN EQUIPMENT .....	6-25
P.T.O. OPERATION.....	6-26
TWO-SPEED P.T.O. SYSTEM .....	6-32
THREE-SPEED P.T.O. SYSTEM.....	6-33
EXTERNAL P.T.O. CONTROLS.....	6-34
AUTO P.T.O. OPERATION .....	6-36

## FRONT POWER TAKE OFF

P.T.O. OPERATION.....	6-39
-----------------------	------

## REAR HITCH

ELECTRONIC DRAFT CONTROL .....	6-41
HITCH Rear hitch - Control.....	6-45
ELECTRONIC DRAFT CONTROL OPERATION .....	6-47
HITCH Electronic draft control - Operating .....	6-52
EXTERNAL HITCH CONTROLS.....	6-53

## FRONT HITCH

SETTINGS AND ADJUSTMENTS .....	6-55
HITCH OPERATION.....	6-58
HITCH Front hitch - Operating .....	6-63
AUXILIARY FRONT COUPLERS (where fitted).....	6-64
EXTERNAL HITCH CONTROLS.....	6-66

## HYDRAULIC REMOTE CONTROL VALVES

REMOTE CONTROL VALVES .....	6-67
OPERATING WITH REMOTE VALVES .....	6-70
CONNECTING REMOTE CYLINDERS .....	6-73
HYDRAULIC OIL LEVEL WHEN USING REMOTE HYDRAULIC EQUIPMENT .....	6-75

## ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

MID MOUNT REMOTE VALVES .....	6-77
Mid-mount remote control valve - Adjust .....	6-78
Mid-mount remote control valve - Adjust .....	6-79
JOYSTICK OPERATION WITH A FRONT LOADER.....	6-83

---

## HYDRAULIC POWER BEYOND PORT

HYDRAULIC POWER BEYOND FOR EXTERNAL SERVICES .....	6-85
Power beyond - Static description .....	6-87

## THREE POINT HITCH

ATTACHING THREE-POINT HITCH EQUIPMENT .....	6-88
LIFT ROD ADJUSTMENT .....	6-90
TOP LINK ADJUSTMENT .....	6-92
FLEXIBLE LINK END ADJUSTMENT .....	6-93
QUICK HITCH .....	6-94
LINKAGE STABILISER ADJUSTMENT .....	6-96

## DRAWBARS AND TOWING ATTACHMENTS

DRAWBARS AND TOWING ATTACHMENTS .....	6-100
SWINGING DRAWBARS .....	6-102

## TRAILER BRAKING SYSTEMS

AIR-OPERATED TRAILER BRAKES .....	6-105
TRAILER BRAKE BIAS CONTROL .....	6-108
AUXILIARY AIR SUPPLY CONNECTOR (where fitted) .....	6-108
HYDRAULIC TRAILER BRAKES .....	6-109

## WHEEL TRACK ADJUSTMENT

FRONT WHEEL TRACK ADJUSTMENT .....	6-110
FRONT WHEEL ALIGNMENT .....	6-113
STEERING STOPS .....	6-114
FRONT AXLE OSCILLATION STOPS .....	6-114
FRONT FENDER .....	6-115
REAR WHEEL TRACK ADJUSTMENT .....	6-117
FLANGE TYPE AXLE (where fitted) .....	6-117
BAR TYPE AXLE (where fitted) .....	6-121
DUAL REAR WHEELS (where fitted) .....	6-127

## BALLASTING AND TYRES

BALLASTING AND TYRES .....	6-130
IRON WEIGHTS (where fitted) .....	6-133
LIQUID BALLAST .....	6-136
TYRE INFLATION .....	6-138
TYRE PRESSURES AND PERMISSIBLE LOADS .....	6-139

## AUXILIARY POWER CONNECTIONS

DIAGNOSTIC SOCKET .....	6-141
TRAILER SOCKET ELECTRICAL .....	6-141
ELECTRICAL POWER CONNECTORS .....	6-142
INTERNAL POWER CONNECTORS .....	6-142
EXTERNAL POWER CONNECTORS .....	6-144

---

## 7 MAINTENANCE

### GENERAL INFORMATION

INTRODUCTION .....	7-1
FUEL REQUIREMENT .....	7-2
BODIESEL FUEL - Biodiesel fuels .....	7-4
ENGINE OIL CHANGE .....	7-6
PROTECTIVE DEVICES .....	7-7
LUBRICANTS AND COOLANTS .....	7-9
TRACTOR JACKING POINTS .....	7-11
GENERAL SPECIFICATIONS .....	7-12
CAPACITIES .....	7-13

### MAINTENANCE CHART

Maintenance Chart .....	7-14
-------------------------	------

### WHEN THE WARNING LAMP LIGHTS

CHANGE THE ENGINE AIR CLEANER OUTER ELEMENT .....	7-16
DRAIN FUEL SYSTEM WATER SEPARATOR .....	7-17

### EVERY 10 HOURS OR EACH DAY

CHECK ENGINE COOLANT LEVEL .....	7-18
CHECK ENGINE OIL LEVEL .....	7-19
CHECK REMOTE CONTROL VALVE DRAIN BOTTLES .....	7-19
CHECK WINDSCREEN WASHER RESERVOIR .....	7-20
DRAIN AIR RESERVOIR ON AIR OPERATED TRAILER BRAKE .....	7-20

### FIRST 50 HOURS

SERVICE OPERATIONS .....	7-21
--------------------------	------

### EVERY 50 HOURS

CLEAN THE CAB AIR FILTER .....	7-23
CLEAN THE SCR COVER AIR DUCTS .....	7-25
CLEAN THE COOLER SECTION .....	7-26
ALL GREASE FITTINGS .....	7-27
CHECK FRONT AND REAR WHEEL NUTS .....	7-34
CHECK TYRE PRESSURES AND TYRE CONDITION .....	7-34

### EVERY 100 HOURS

INSPECT POLY V-BELT .....	7-35
INSPECT COMPRESSOR DRIVE BELT .....	7-35

### EVERY 300 HOURS

CHECK BATTERY FLUID LEVEL .....	7-36
ADJUST HANDBRAKE .....	7-37
CHECK TRANSMISSION/REAR AXLE AND HYDRAULIC OIL LEVEL .....	7-38
CHECK 4WD FRONT AXLE DIFFERENTIAL AND HUBS OIL LEVEL .....	7-39
CHECK FRONT P.T.O. GEARBOX OIL LEVEL .....	7-39

### EVERY 600 HOURS

---



CHANGE ENGINE OIL AND FILTER .....	7-40
CHANGE FUEL PRE-FILTER AND FUEL FILTER ELEMENT.....	7-42
CHANGE THE ENGINE AIR CLEANER OUTER ELEMENT .....	7-43
CHANGE CHARGE PUMP OIL FILTER .....	7-44
CHECK ENGINE AIR INTAKE CONNECTIONS .....	7-45
CHECK TRANSMISSION OIL COOLER PIPE COUPLINGS .....	7-46
CLEAN DEF/ AdBlue INLINE FILTER.....	7-47

## EVERY 1200 HOURS OR ANNUALLY

CHANGE CAB AIR FILTERS.....	7-48
CHANGE MAIN OIL FILTER CARTRIDGE.....	7-49
CHANGE TRANSMISSION/ REAR AXLE AND HYDRAULIC OIL.....	7-50
CHANGE 4WD DIFFERENTIAL OIL .....	7-51
CHANGE 4WD PLANETARY HUB OIL .....	7-52
CHANGE FRONT P.T.O. GEARBOX OIL .....	7-52
GREASE REAR AXLE SHAFT BEARING .....	7-53

## EVERY 1200 HOURS OR EVERY 2 YEARS

CHECK BATTERY FLUID LEVEL.....	7-54
CHANGE DEF/ AdBlue INLINE FILTER.....	7-55
CHANGE ENGINE AIR CLEANER INNER ELEMENT.....	7-56
CHANGE ENGINE BREATHER FILTER .....	7-57
CHECK VALVE TAPPET CLEARANCE.....	7-57
CHANGE ENGINE COOLANT FLUID .....	7-58
CHANGE AIR BRAKE DRIER RESERVOIR.....	7-62
CHANGE POLY V-BELTS.....	7-63

## EVERY 3600 HOURS OR EVERY 2 YEARS

CHANGE DEF/ AdBlue MAIN FILTER .....	7-64
--------------------------------------	------

## EVERY 36 MONTHS

SERVICE THE AIR CONDITIONER SYSTEM.....	7-65
CHECK BATTERY FLUID LEVEL.....	7-66

## GENERAL MAINTENANCE

CLEANING THE TRACTOR.....	7-68
FUEL SYSTEM PRE- FILTER AND WATER TRAP.....	7-70
BLEEDING THE FUEL INJECTION SYSTEM .....	7-70
CHECK BRAKE PEDAL LATCHING/UNLATCHING .....	7-71
ADJUST CAB SUSPENSION (where fitted) .....	7-72
TRANSMISSION CLUTCH CALIBRATION .....	7-73
HEADLIGHT AND WORKLAMP ADJUSTMENT.....	7-75
BULB REPLACEMENT.....	7-76
FUSES AND RELAYS.....	7-80
PROTECTING THE ELECTRONIC AND ELECTRICAL SYSTEMS DURING BATTERY CHARGING OR WELDING .....	7-85
BATTERY REMOVAL AND INSTALLATION .....	7-86

## STORAGE

TRACTOR STORAGE.....	7-87
PREPARATION FOR USE AFTER STORAGE .....	7-87

---

## 8 TROUBLESHOOTING

### FAULT CODE RESOLUTION

INTRODUCTION .....	8-1
--------------------	-----

### ALARM(S)

FAULT CODES AND SYMBOLS .....	8-2
-------------------------------	-----

### SYMPTOM(S)

ENGINE .....	8-4
TRANSMISSION .....	8-5
HYDRAULICS .....	8-5
THREE POINT HITCH .....	8-6
BRAKES .....	8-6
CAB .....	8-7
ELECTRICAL SYSTEM .....	8-7

## 9 SPECIFICATIONS

GENERAL DIMENSIONS .....	9-1
FRAME AND CAB - General specification .....	9-1
CAPACITIES .....	9-4
TRANSMISSION - Capacity .....	9-5
FRONT AXLE - Capacity .....	9-5
ENGINE .....	9-6
TRANSMISSION .....	9-7
REAR POWER TAKE-OFF .....	9-8
FRONT POWER TAKE OFF .....	9-8
HYDRAULIC SYSTEM .....	9-9
THREE POINT HITCH .....	9-10
REMOTE CONTROL VALVES .....	9-11
THREE POINT HITCH FRONT .....	9-11
BRAKES .....	9-12
STEERING .....	9-12
ELECTRICAL EQUIPMENT .....	9-13
MINIMUM HARDWARE TIGHTENING TORQUES .....	9-14

## 10 ACCESSORIES

EXTERNAL REAR VIEW MIRRORS .....	10-1
AUXILIARY HEADLIGHTS .....	10-2
ROTATING BEACON .....	10-2

## 11 FORMS AND DECLARATIONS

Service record 1st 50 hour, Owner copy .....	11-1
Service record 1st 50 hour, Dealer copy .....	11-3

---

# 1 - GENERAL INFORMATION

## METRIC AND IMPERIAL UNITS ABBREVIATIONS

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	<b>ha</b>	acre	<b>ac</b>
	square meter	<b>m<sup>2</sup></b>	square foot	<b>ft<sup>2</sup></b>
	square millimeter	<b>mm<sup>2</sup></b>	square inch	<b>in<sup>2</sup></b>
Electricity				
	ampere	<b>A</b>	ampere	<b>A</b>
	volt	<b>V</b>	volt	<b>V</b>
	microfarad	<b>μF</b>	microfarad	<b>μF</b>
	ohm	<b>Ω</b>	ohm	<b>Ω</b>
Force				
	kilonewton	<b>kN</b>	pound	<b>lb</b>
	newton	<b>N</b>	pound	<b>lb</b>
Force per length				
	newton per meter	<b>N/m</b>	pound per foot	<b>lb/ft</b>
			pound per inch	<b>lb/in</b>
Frequency				
	megahertz	<b>MHz</b>	megahertz	<b>MHz</b>
	kilohertz	<b>kHz</b>	kilohertz	<b>kHz</b>
	hertz	<b>Hz</b>	hertz	<b>Hz</b>
Frequency - Rotational				
	revolution per minute	<b>r/min</b>	revolution per minute	<b>r/min<sup>a</sup></b>
		<b>rpm</b>		<b>rpm</b>
Length				
	kilometer	<b>km</b>	mile	<b>mi</b>
	meter	<b>m</b>	foot	<b>ft</b>
	centimeter	<b>cm</b>	inch	<b>in</b>
	millimeter	<b>mm</b>	inch	<b>in</b>
	micrometer	<b>μm</b>		
Mass				
	kilogram	<b>kg</b>	pound	<b>lb</b>
	gram	<b>g</b>	ounce	<b>oz</b>
	milligram	<b>mg</b>		
Mass per Mass				
	milligram per kilogram	<b>mg/ kg</b>		
Power				
	kilowatt	<b>kW</b>	horsepower	<b>Hp</b>
	watt	<b>W</b>	Btu per hour	<b>Btu/hr</b>
			Btu per minute	<b>Btu/min</b>
Pressure or stress (Force per area)				
	kilopascal	<b>kPa</b>	pound per square inch	<b>psi</b>
			inch of mercury	<b>inHg</b>
	pascal	<b>Pa</b>	inch of water	<b>inH<sub>2</sub>O</b>
	megapascal	<b>MPa</b>	pound per square inch	<b>psi</b>

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than Thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	<b>h</b>	hour	<b>h</b>
	minute	<b>min</b>	minute	<b>min</b>
	second	<b>s</b>	second	<b>s</b>
Torque (includes Bending moment, Moment of force, and Moment of a couple)				
	newton meter	<b>N m</b>	pound foot	<b>lb ft</b>
			pound foot	<b>lb in</b>
Velocity				
	kilometer per hour	<b>km/h</b>	mile per hour	<b>mph</b>
	meter per second	<b>m/s</b>	foot per second	<b>ft/s</b>
	millimeter per second	<b>mm/s</b>	inch per second	<b>in/s</b>
	meter per minute	<b>m/min</b>	foot per minute	<b>ft/min</b>
Volume (includes Capacity)				
	cubic meter	<b>m<sup>3</sup></b>	cubic yard	<b>yd<sup>3</sup></b>
				<b>cu yd</b>
	liter	<b>l</b>	cubic inch	<b>in<sup>3</sup></b>
	liter	<b>l</b>	US gallon	<b>US gal</b>
			UK gallon	<b>UK gal</b>
			US quart	<b>US qt</b>
			UK quart	<b>UK qt</b>
	milliliter	<b>ml</b>	fluid ounce	<b>fl oz</b>
Volume per time (includes Discharge and Flow rate)				
	cubic meter per minute	<b>m<sup>3</sup>/min</b>	cubic foot per minute	<b>ft<sup>3</sup>/min</b>
	liter per minute	<b>l/min</b>	US gallon per minute	<b>US gal/min</b>
	milliliter per minute	<b>ml/min</b>	UK gallon per minute	<b>UK gal/min</b>
Sound power level and Sound pressure level				
	decibel	<b>dB</b>	decibel	<b>dB</b>

**Glossary**

Acronym	Definition
DEF	Diesel Exhaust Fluid
ISO	International Organization for Standardization
MSDS	Material Safety Data Sheet
NOx	Nitrogen Oxide
PPE	Personal Protective Equipment
SCR	Selective Catalytic Reduction
ULSD	Ultra Low Sulfur Diesel
%	Percent
<	Less than
>	Greater than

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)