

Magnum 180, 190, 210 Tractors


Operator's Manual

87750194
Issued March 2009
1st Printing

CASE IH
AGRICULTURE



OPERATOR'S MANUAL



Magnum 180
Magnum 190
Magnum 210

Contents

1 GENERAL INFORMATION

Personal safety	1-1
Proposition 65	1-2
Product identification	1-3
Note to the Owner	1-4
Tractor intended use	1-4
Manual storage	1-5
Product identification	1-6
Component location	1-8

2 SAFETY INFORMATION

Safety rules	2-1
ROPS and CSF	2-6
Safety decals	2-7

3 CONTROLS/INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Tractor access	3-1
----------------------	-----

OPERATOR'S SEAT

Overview	3-2
Control identification	3-3

INSTRUCTOR'S SEAT

Overview	3-6
----------------	-----

FORWARD CONTROLS

Steering column	3-7
Front console	3-10
Pedal controls	3-12

LH SIDE CONTROLS

Hand brake	3-13
------------------	------

RH SIDE CONTROLS

Armrest console	3-14
Multi-function handle	3-15
Control panel	3-18
Remote valve controls	3-26
Joystick	3-27
Armrest compartment	3-29
Adjusting the armrest console	3-30

REARWARD CONTROLS

Fender console	3-31
Automatic temperature controls	3-34
Automatic temperature control system	3-37
Ventilation	3-38

OVERHEAD CONTROLS

Interior lamps	3-40
----------------------	------

EXTERIOR CONTROLS

Rear fender	3-41
-------------------	------

INSTRUMENT CLUSTER

Overview	3-42
Gauges	3-42
Status and warning icons	3-43
Dedicated display	3-46
Programmable display	3-47
Keypad	3-48
Standard instrumentation	3-50
Performance instrumentation	3-55

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Before starting the engine	4-1
----------------------------------	-----

STARTING THE UNIT

Normal engine starting	4-4
Cold starting aids	4-6
Cold temperature operation	4-7

STOPPING THE UNIT

Stopping the engine	4-9
---------------------------	-----

MOVING THE UNIT

Powershift transmission	4-10
Inching pedal and throttle	4-11
Transmission controls	4-12
Dedicated display	4-14
Driving the vehicle	4-15
Autoshift road and field	4-17
Go To feature	4-23
Speed matching	4-23
Setting reverse gear ratios	4-25
Transmission errors and calibration	4-26
Creeper gears	4-27
Mechanical front drive (MFD)	4-28
Differential lock system	4-30
Suspended axle	4-32
Engine power management	4-33
Ride control	4-35
Constant engine speed	4-36
Electronic end of row system	4-39

PARKING THE UNIT

Park brake and electronic park lock (EPL)	4-50
---	------

5 TRANSPORT OPERATIONS

ROAD TRANSPORT

Tractor warning lamps and SMV symbol	5-1
Wide transport marker light	5-2
Tractor warning lamps	5-4
Safe transport speed	5-5

Implement warning lamps and SMV symbol	5-6
Safety chain	5-7
SHIPPING TRANSPORT	
Securing the tractor for shipping	5-8
RECOVERY TRANSPORT	
Safety rules	5-9
6 WORKING OPERATIONS	
GENERAL INFORMATION	
Before operating the vehicle.....	6-1
Guidelines	6-2
REAR PTO	
Safety rules.....	6-3
Connecting the PTO	6-6
PTO operation	6-8
Two speed PTO systems.....	6-10
Auto PTO operation	6-11
PTO fender switch operation	6-13
THREE POINT HITCH	
Connecting three-point hitch implements.....	6-14
Three-point hitch adjustments.....	6-15
Hitch controls and settings	6-22
Draft control	6-27
Position and ride control.....	6-30
DRAWBARS AND TOWING ATTACHMENTS	
Safety rules.....	6-32
Adjusting the drawbar	6-33
HYDRAULIC TRAILER BRAKES	
Trailer brake connections.....	6-35
AUXILIARY POWER CONNECTIONS	
Auxiliary power and lighting	6-36
Cab power connections	6-38
HYDRAULIC REMOTE CONTROL VALVES	
Valve couplers and connections	6-40
Transport lock	6-45
Operating the controls	6-46
Remote valve display screens.....	6-50
Rear fender controls	6-53
Joystick operation	6-54
BALLASTING THE TRACTOR	
Guidelines	6-56
Tire load and inflation charts	6-60
Weights, cast metal and liquid.....	6-66
Wheel slip and power hop performance	6-74
MECHANICAL FRONT DRIVE (MFD) AXLES	

Tire combinations and tread positions.....	6-76
Steering and oscillation stops	6-81

REAR AXLE

Rear wheel installation	6-86
Rear wheel tread settings	6-88

7 MAINTENANCE

GENERAL INFORMATION

Safety rules.....	7-1
Opening the hood	7-2
Closing the hood	7-3
Battery access and service.....	7-4
Tire and rim service.....	7-6
Tractor jacking points.....	7-8
Capacities	7-10
Consumables.....	7-12
Electrical component location	7-16

MAINTENANCE CHART

Maintenance Chart	7-20
-------------------------	------

At warning message display

Air filter service icon/message.....	7-21
Fuel filter water separator	7-24

Every 10 hours or daily

Engine coolant level	7-25
Engine oil level	7-26
Windshield washer fluid level.....	7-27

First 50 hours

Dealer performed service.....	7-28
-------------------------------	------

Every 50 hours

Coolers and condenser.....	7-29
Cab air filter.....	7-31
Grease fittings	7-34
Wheel bolt torque.....	7-40
Tire pressure	7-41

Every 300 hours

Battery water level.....	7-42
Fan belt	7-44
Transmission oil level.....	7-45
Mechanical front drive (MFD) gearbox	7-46
Park brake	7-47

Every 600 hours

Engine oil and filter	7-48
Hydraulic filter(s)	7-50
Engine primary air filter.....	7-51
Engine air intake hoses.....	7-54
Fuel filters	7-56

Differential and planetary oil.....	7-58
-------------------------------------	------

Every 1200 hours or annually

Cab air filter.....	7-59
Hydraulic filter(s)	7-61
Transmission oil	7-66
Differential and planetary oil.....	7-69
Mechanical front drive (MFD) gearbox	7-72
Battery water level.....	7-73

Every 1200 hours or two years

Engine coolant.....	7-75
Engine secondary air filter.....	7-78
Engine valve adjustment	7-81
Blowby filter.....	7-82

Every 36 months

Air conditioning system.....	7-82
------------------------------	------

As required

Pre-filter and water trap	7-83
Fuel tank vent filter	7-85
Fan belt.....	7-86
Spark arresting muffler	7-90
Remote valve collection bottle.....	7-92
Cab fabric and carpet.....	7-92
Tractor exterior	7-93
Seat belt	7-94

STORAGE

Preparing for storage	7-95
Removing from storage.....	7-95

ELECTRICAL SYSTEM

Radio or audio system.....	7-97
Battery removal and installation	7-98
Battery - Charging	7-100
Head light - Replace.....	7-101
Front work light - Replace	7-107
Fender tail light and warning light	7-109
Roof front warning and work light	7-111
Roof rear warning light	7-114
High intensity work light	7-116
Wide transport marker light.....	7-118
Rotating beacon light.....	7-119
Interior light - Replace	7-120

8 TROUBLESHOOTING

ALARM(S)

Display warnings	8-1
Automatic engine shut down	8-8
Fault reporting	8-9

SYMPTOM(S)

- Engine symptoms 8-11
- Transmission symptoms..... 8-13
- Hydraulic symptoms 8-14
- Hitch symptoms 8-15
- Brake symptoms..... 8-16
- Cab environment symptoms..... 8-16
- Electrical power system symptoms..... 8-17

9 SPECIFICATIONS

- Engine specifications 9-1
- Power train specifications 9-2
- Operating speeds..... 9-4
- Vehicle dimensions and shipping weight 9-7
- Maximum operating weight..... 9-8

10 ACCESSORIES

- Front wheel fenders 10-1
- Farming system displays 10-5
- Chemical tank mounting 10-6
- Loader connection and operation 10-8
- General accessories..... 10-9

11 FORMS AND DECLARATIONS

- First service dealer copy 11-1
- First service customer copy 11-3

1 - GENERAL INFORMATION

Personal safety



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF DEATH OR SERIOUS INJURY.




Throughout this manual and on the machine's safety decals, you will find precautionary statements: DANGER< WARNING or CAUTION followed by special instructions or ISO two panel safety pictorial symbols. These precautions are intended for your personal safety.

Failure to follow the DANGER, WARNING or CAUTION instructions may result in death or serious bodily injury.

DANGER, WARNING or CAUTION are defined as follows:

- DANGER: Indicates an immediate hazardous situation that, if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. The color associated with Warning is ORANGE.
- CAUTION: Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

ISO two panel pictorial symbol decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard
- Background color is YELLOW.
- Prohibition symbols such as   and  if used are RED.



IMPROPER OPERATION OF THIS MACHINE CAN CAUSE DEATH OR SERIOUS INJURY. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow CNH America LLC instructions on machine operation and maintenance.

CNH America LLC technical manuals

Manuals are available from your Dealer for the operation, service and repair of your machine. For prompt convenient service, contact your Dealer for assistance in obtaining the manuals for your machine.

Your Dealer can expedite your order for Operators Manuals, Parts Catalogs, Repair Manuals and maintenance records.

Always give the Machine Name, Model and P.I.N. (product identification number) of your machine so your Dealer can provide the correct manuals for your machine.

The company is continually striving to improve its products and therefore reserves the right to make improvements and changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

All data given in this manual is subject to production variations. **IMPORTANT: OPERATING AND SERVICE MESSAGES DISPLAYED ON THE ELECTRONIC OPERATING PANEL MAY VARY FROM WHAT IS SHOWN IN THE OPERATOR'S MANUAL. SHOULD THIS OCCUR ADHERE TO THE LATEST INSTRUCTION ON THE ELECTRONIC OPERATING PANEL.**

Dimensions and weights are approximate only and the illustrations do not necessarily show the machine in standard condition. For exact information about any particular machine, please consult your dealer.

Proposition 65

CALIFORNIA


Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.

RCIL08CCH001EAA 1

Product identification



RCPH09CCH012BAB 1

The right hand and left hand side of the tractor used in this manual are the same as your right hand and left hand when sitting in the tractor seat looking forward.

Note to the Owner

This manual contains important information about the safe operation, adjustment and routine maintenance of your Magnum series tractor. The manual is divided into eleven chapters as outlined in the table of contents. Refer to the index at the end of this manual for locating specific items about your tractor.

Do NOT operate or permit anyone to operate or service this machine until you or the other persons have read this manual. Use only trained operators who have demonstrated the ability to operate and service this machine correctly and safely.


This Operator's Manual is to be stored in the manual compartment behind the operator's seat in the vehicle. Make sure this manual is in good condition. Contact your dealer to obtain additional manuals. Contact your dealer for any further information or assistance about your machine. Your dealer has approved service parts. Your dealer has technicians with special training that know the best methods of repair and maintenance for your tractor.

Tractor intended use

Magnum series tractors with standard equipment and authorized attachments, are intended to be used for customary farming and related agriculture operations. Farming implements and attachments for loading and moving materials can be used on the tractor where recommended and approved by CASEIH. Installation of utility (dozer) blades, tile plows, or push bars on the tractor is not recommended. Any tractor damage resulting from the installation and/or use of such equipment is not covered by the tractor warranty.

Consult an authorized dealer or CNH America LLC on changes, additions or modifications that can be required for this machine to comply with various regulations and safety requirements. Unauthorized modifications will cause serious injury or death. Anyone making such unauthorized modifications is responsible for the consequences.

Manual storage



RCPH08CCH002FAB 1

Keep the Operator's Manual in the storage compartment provided on your tractor. The Operator's Manual must be available for use by all operators.

Buy Now



Our support email:

ebooklibonline@outlook.com