# **CATERPILLAR®**

# Service Repair Manual

## **Models**

385B and 385B L Excavator

Model: 385B EXCAVATOR RCD

Configuration: 385B L Excavator RCD00001-UP (MACHINE) POWERED BY 3456 Engine

#### **Disassembly and Assembly** 385B and 5090B Excavators Excavator Systems

Media Number -RENR5407-06

Publication Date -01/02/2016

Date Updated -12/02/2016

i01674415

### Control Valve - Disassemble - Proportional Valve

**SMCS -** 5051-015

### **Disassembly Procedure**




Illustration 1 g00864935

1. Remove bolts (1) and valve group (2).




Illustration 2 g00864942

2. Remove nut (3) and solenoid (4).




Illustration 3 g00864965

3. Remove bolt (5) and bracket assembly (6). Remove cartridge (7).




Illustration 4 g00864984

4. Remove O-ring seals (8) from cartridge (6).

Copyright 1993 - 2020 Caterpillar Inc.
All Rights Reserved.
Private Network For SIS Licensees.

<u>1993 - 2020 Caterpillar Inc.</u> Fri Oct 16 15:36:33 UTC+0800 2020

Model: 385B EXCAVATOR RCD

Configuration: 385B L Excavator RCD00001-UP (MACHINE) POWERED BY 3456 Engine

#### **Disassembly and Assembly** 385B and 5090B Excavators Excavator Systems

Media Number -RENR5407-06

Publication Date -01/02/2016

Date Updated -12/02/2016

i01659183

#### Control Valve - Assemble - Attachment, Bucket, and Boom

**SMCS -** 5051-012

#### **Assembly Procedure**

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1P-1862	Pliers	1

**Note:** Check the O-ring seals, the gaskets, and the seals for wear or for damage. Replace the components, if necessary.




Illustration 1 g00854185

1. Install plugs and O-ring seals (80).




Illustration 2 g00854173

2. Assemble resolver (71). Install ball (73) in valve (74). Install seat (72). Install backup rings (76) and (79). Install O-ring seals (75), (77), and (78).

**Note:** Reduce the temperature of seat (72) before inserting the seat into the bore of valve (74).




Illustration 3 g00854162

3. Install resolver (71). Tighten the resolver to a torque of  $50 \pm 10 \text{ N} \cdot \text{m}$  (37 ± 7 lb ft). Install stems (68), (69), and (70). Install plugs and O-ring seals (67).

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com