



Service Repair Manual

Models

924K Wheel Loader

Product: WHEEL LOADER

Model: 924K WHEEL LOADER SNZ

Configuration: 924K Small Wheel Loader SNZ00001-UP (MACHINE) POWERED BY C7.1 Engine

Disassembly and Assembly 924K, 930K and 938K Wheel Loaders Power Train

Media Number -UENR0281-03

Publication Date -01/04/2017

Date Updated -24/04/2017

i05142776

Transmission

SMCS - 3030


Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1U-7505	Hydraulic Jack	1
B	138-7575	Link Bracket	3
	1U-9200	Lever Puller Hoist Gp	1

Start By:

- A. Remove the front hydrostatic piston motor and the rear hydrostatic piston motor.



1. Remove bolts (1) and the caps in order to disconnect drive shaft (2) from the yoke. Discard bolts (1) .




Illustration 2

2. Remove cover (3) .



Illustration 3

3. Disconnect harness assemblies (4) and (5) . Reposition harness assemblies (4) and (5) out of the way.
-



Illustration 4

g02802564

4. Disconnect harness assembly (6) and reposition harness assembly (6) out of the way.




Illustration 5

g02802576

5. Remove bracket (7) .




Illustration 6

g02802636

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com