



Service Repair Manual

Models

988K Wheel Loader

Product: WHEEL LOADER

Model: 988K WHEEL LOADER TWX

Configuration: 988K Wheel Loader TWX00001-UP (MACHINE) POWERED BY C18 Engine

Disassembly and Assembly

836K Landfill Compactor, 834K Wheel Dozer and 988K Wheel Loader Power Train

Media Number -KENR6490-06

Publication Date -01/09/2015

Date Updated -05/12/2017

i02071477

Torque Converter (Lockup) - Disassemble

SMCS - 3101-015-L7

Disassembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	138-7573	Link Bracket	1
	138-7575	Link Bracket	2
B	5F-7366	Screw	1
	3H-0465	Plate	2
	1P-5546	Crossblock	1
	5H-7369	Puller Leg	2
	6B-6682	3/4" - 16 NF Nut	2
	1P-0520	Driver Gp	1
	4C-5653	Threaded Adapter	2
C	188-1456	Metric Eyebolt	1
D	138-7575	Link Bracket	2
E	138-7575	Link Bracket	3
F	5F-7366	Screw	1
	3H-0465	Plate	2
	1P-5546	Crossblock	1

G	5H-7369	Puller Leg	2
	8B-7551	Bearing Puller	1
	6B-6682	3/4" - 16 NF Nut	2
	1P-0520	Driver Gp	1
	5F-7366	Screw	1
	3H-0465	Plate	2
	1P-5546	Crossblock	1
	8B-7549	Puller Leg	2
	5F-7343	Bearing Puller	1
	6B-6682	3/4" - 16 NF Nut	2
	1P-0520	Driver Gp	1
	5F-7342	Adapter	2
H	1P-0520	Driver Gp	1
J	138-7574	Link Bracket	2

Start By:

- Remove the torque converter. Refer to Disassembly and Assembly, "Torque Converter - Remove" for the machine that is being serviced.
 - Remove the transmission oil pump. Refer to Disassembly and Assembly, "Transmission Oil Pump - Remove" for the machine that is being serviced.
 - Remove the torque converter outlet relief valve. Refer to Disassembly and Assembly, "Relief Valve (Torque Converter Outlet) - Remove" for the machine that is being serviced.
 - Remove the modulating valve for the torque converter impeller clutch. Refer to Disassembly and Assembly, "Modulating Valve (Torque Converter Impeller Clutch) - Remove" for the machine that is being serviced.
 - Remove the modulating valve for the torque converter lockup clutch. Refer to Disassembly and Assembly, "Modulating Valve (Torque Converter Lockup Clutch) - Remove" for the machine that is being serviced.
-



Illustration 1

g00673844

1. Place the torque converter assembly on cribbing. The weight of the torque converter assembly is 545 kg (1200 lb).




Illustration 2

g00660841

2. Remove speed sensor (1).




Illustration 3

g00665406

3. Remove bolt (2) and retainer (3).
-




Illustration 4

g00665411

4. Remove O-ring seal (4) and yoke (5).



Illustration 5

g00665412

5. Remove eleven bolts (6) and the washers.



Illustration 6

g00665414

6. Install Tooling (A) to housing assembly.
7. Attach a suitable lifting device and lifting chains to Tooling (A).

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com