

Product: TRACK-TYPE TRACTOR

Model: D6H TRACK-TYPE TRACTOR 4GG

Configuration: D6H TRACK-TYPE TRACTOR / POWERSHIFT / 4GG04000-UP (MACHINE) POWERED BY 3306 ENGINE

Disassembly and Assembly

D6H TRACTOR POWER TRAIN

Media Number -SEN3242-03

Publication Date -01/11/2004

Date Updated -10/01/2017

SEN32420013

Final Drives

SMCS - 4050-011; 4050-012; 4050-015; 4050-016


Remove Final Drives

Tools Needed		A	B
FT1952	Axle Removal Tool	1	
8T3207	Lifting Bracket		1
5P8622	Shackle		1
1D4615	Bolt		2
1B4331	Nut		2
5P8248	Washer		4

Start By:


a. separate track

NOTE: The final drive planetary carriers can be removed in chassis. See topic, Remove Final Drive Planetary Carriers (In Chassis).





1. Turn the final drive until drain plug (1) is on the bottom as shown. Remove drain plug (1) and drain approximately **13.2 liters (3.4 U.S. gal.)** of oil from the final drive.

2. Remove the cover from the final drive and remove the O-ring seal from the cover.
3. Install tooling (A) and remove the outer axle.



4. Adjust the top bracket on tooling (B) so that dimension (X) is **213 mm (8.4 in)**. The lower mounting bracket must be installed with the spacers outward as shown.



5. Remove two of the bolts from the sprocket segments. Fasten a hoist and install tooling (B) onto the final drive.

NOTICE


**Bolts (4) hold the steering clutch and brake to the main case and frame.
Do not remove bolts (4).**


6. Remove bolts (2) that hold the final drive to the main case and frame.
7. The weight of the final drive is **490 kg (1075 lb)**. Remove four bolts (3) that hold the final drive and steering clutch and brake together.
8. Use tooling (B) and remove the final drive from the machine.
9. Remove the O-ring seal from either the face of the steering clutch or the final drive hub.

Install Final Drives


Tools Needed		A	B
FT1952	Axle Removal Tool	1	
8T3207	Lifting Bracket		1
5P8622	Shackle		1
1D4615	Bolt		2
1B4331	Nut		2
5P8248	Washer		4

1. Inspect the condition of O-ring seals and replace if necessary.
2. Put the O-ring seal in position on the face of the steering clutch.





3. Fasten a hoist and install tooling (B) onto the final drive. Adjust tooling (B) if necessary to put the final drive in a level position.
4. Put the final drive in position onto the frame and install four bolts (3) that hold the final drive to the steering clutch and brake.
5. Install bolts (2) that hold the final drive and steering clutch and brake to the main case and frame. Remove tooling (B).
6. Put **SAE 30 oil** on the threads of the segment bolts. Install the bolts and nuts with the nuts and washers against the final drive. Tighten the nuts to a torque of **$175 \pm 40 \text{ N}\cdot\text{m}$ ($130 \pm 30 \text{ lb ft}$)**. Tighten the nuts **1/3 of a turn more**.



7. Install tool (A) onto the outer axle and install the axle into the final drive.
8. Install the O-ring seal onto the cover and install the cover onto the final drive.
9. Rotate the final drive so drain plug (1) is toward the bottom. Fill the final drive with oil to the bottom of the fill plug hole. See the Operation And Maintenance Guide for the type of oil and capacity.

End By:


a. connect track

Disassemble Final Drives


Tools Needed		A	B	C	D
6V2156	Link Bracket	3			
1A2029	Bolt	3			
1P510	Driver Group		1		
FT1934	Beam			1	
6V3160	Cylinder			1	
6V9061	Pump Group			1	
1D4621	Bolt			4	
6V2157	Link Bracket				2
2A1538	Bolt				2

Start By:

a. remove final drives



1. Install tooling (A) onto the planetary carrier and attach a hoist.
2. The weight of the planetary carrier is **137 kg (301 lb)**. Remove bolts (1) that hold the planetary carrier to the hub. Remove planetary carrier (3) and the two O-ring seals from the hub.
3. Remove three retainers (2).





4. Support planetary carrier (3), from underneath, to prevent damage. Use tooling (B) and a press and remove the three planetary gear shafts.

5. Remove three planetary gears (4) from carrier (3).



6. Remove bearing cones (5) from each of the gears (4).

7. Remove the bearing cups from each side of the gears.



8. Remove ten bolts (6) and retainer (7).

9. The weight of the hub and ring gear (8) is **68 kg (150 lb)**. Use nylon straps and a hoist and remove the hub and ring gear (8).

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com