



Service Repair Manual

Models

D6R II TRACK-TYPE TRACTOR

Product: TRACK-TYPE TRACTOR

Model: D6R II TRACK-TYPE TRACTOR AGM

Configuration: D6R Series II TRACK-TYPE TRACTOR FTC AGM00001-UP (MACHINE) POWERED BY C-9 Engine

Disassembly and Assembly

D6R Series II Track-Type Tractor Power Train

Media Number -REN4257-03

Publication Date -01/08/2009

Date Updated -01/09/2009

i01618664

Final Drive - Disassemble

SMCS - 4050-015

Disassembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	138-7573	Link Bracket	3
A	1A-2029	Bolt	3
B	1P-510	Driver Group	1
C	FT-1934	Beam	1
C	6V-3160	Cylinder	1
C	6V-9061	Pump Group	1
C	1D-4621	Bolt	4
D	138-7574	Link Bracket	2
D	2A-1538	Bolt	2

Start By:

- Remove the final drives. Refer to Disassembly and Assembly, "Final Drive - Remove" for the correct procedure.

Note: Cleanliness is an important factor. Before the disassembly procedure, the exterior of the component should be thoroughly cleaned. This will help to prevent dirt from entering the internal mechanism.




Illustration 1

g00841087

1. Install Tooling (A) on the planetary carrier. Attach a hoist.
2. Remove bolts (1) that hold the planetary carrier to the hub. Remove planetary carrier (3) and the two O-ring seals from the hub. The weight of the planetary carrier is approximately 137 kg (302 lb).
3. Remove three retainers (2) .




Illustration 2

g00841089

4. Place support under planetary carrier (3) in order to prevent damage. Use Tooling (B) and a press to remove the three planetary gear shafts.
5. Remove three planetary gears (4) from carrier (3) .




Illustration 3

g00841091

6. Remove bearing cones (5) from each gear (4) .
7. Remove the bearing cups from each side of the gears.




Illustration 4

g00841092



Illustration 5

g00841093

8. Remove bolts (6) and retainer (7) .

9. Use nylon straps and a hoist to remove the hub and ring gear (8). The weight of the hub and ring gear (8) is approximately 68 kg (150 lb).



Illustration 6

g00841094

10. Turn over hub (9) and ring gear (8). Remove retaining ring (10). The weight of hub (9) is approximately 37 kg (82 lb). The weight of ring gear (8) is approximately 32 kg (71 lb). Use nylon straps and a hoist to remove hub (9) .




Illustration 7

g00841095

11. Install Tooling (C) on hub (12).

Note: Do not lift hub (12) too high. Do not allow hub (12) to contact the fitting on the hydraulic cylinder.

12. Use Tooling (C) to loosen hub (12) from spindle (13). Remove Tooling (C) .

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com