



Service Repair Manual

Models

D6T TRACK-TYPE TRACTOR

Product: TRACK-TYPE TRACTOR

Model: D6T TRACK-TYPE TRACTOR MB5

Configuration: D6T XL, XW, LGP Track-Type Tractor MB500001-UP (MACHINE) POWERED BY C9.3 Engine

Disassembly and Assembly D6T Track Type Tractor Power Train

Media Number -M0073303-04

Publication Date -01/09/2018

Date Updated -06/09/2018

i06788640

Final Drive - Disassemble

SMCS - 4050-015

Disassembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	439-3938	Link Bracket	3
	1A-2029	Bolt	1
B	1P-0510	Driver Group	1
C	FT-1934	Beam	1
	6V-3160	Double Acting Cylinder	1
	4C-4865	Pump Group	1
	1D-4621	Bolt	4
D	439-3939	Link Bracket	2
	2A-1538	Bolt	2

Start By:

- a. Remove the final drive.
-




Illustration 1

g01195912

1. Install Tooling (A) and a suitable lifting device to planetary carrier (3).
2. Remove bolts (1). Remove planetary carrier (3) and the two O-ring seals from the hub. The weight of planetary carrier (3) is approximately 137 kg (302 lb).
3. Remove retainers (2).




Illustration 2

g00841089

4. Place support under planetary carrier (3) to prevent damage. Use Tooling (B) and a suitable press to remove the planetary gear shafts.
 5. Remove planetary gears (4) from planetary carrier (3).
-



Illustration 3

g00841091

6. Remove bearing cones (5) from gears (4).
7. Remove the bearing cups from each side of the gears.




Illustration 4

g00841092



Illustration 5

g01195913

8. Remove bolts (6) and retainer (7).
 9. Attach a suitable lifting device to hub (12) and ring gear (8). The weight of hub (12) and ring gear (8) is approximately 68 kg (150 lb). Remove hub (12) and ring gear (8).
-



Illustration 6

g01195915

10. Turn over hub (9) and ring gear (8). Remove retaining ring (10). Attach a suitable lifting device to hub (9). The weight of hub (9) is approximately 37 kg (82 lb). The weight of ring gear (8) is approximately 32 kg (71 lb). Remove hub (9).




Illustration 7

g00841095

11. Install Tooling (C) on hub (12).

Note: Do not lift hub (12) too high. Do not allow hub (12) to contact the fitting on the hydraulic cylinder.

12. Use Tooling (C) to loosen hub (12) from spindle (13). Remove Tooling (C).
 13. Remove bearing cone (11).
-

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com