CATERPILLAR®

Service Repair Manual

Models

D9R TRACK-TYPE TRACTOR

Product: TRACK-TYPE TRACTOR
Model: D9R TRACK-TYPE TRACTOR ACL
Configuration: D9R Track-Type Tractor Power Shift ACL00001-UP (MACHINE) POWERED BY 3408 Engine

Disassembly and Assembly

D9R Track-Type Tractor Power Train

Media Number -SENR5387-14

Publication Date -01/08/2018

Date Updated -30/08/2018

i05768467

Final Drive Planetary Carrier (In Chassis) - Install

SMCS - 4092-012

Installation Procedure

Required Tools			
Tool	Part Number	Part Description	Qty
A	5P-8622	Shackle	1
	151-2816	Plate	1
	142-6893	Adjustable Hook Gp	1
	5P-8732	Adapter	1
	1D-4609	Bolt	3
	2J-3505	Full Nut	3
	5H-1504	Hard Washer	6
В	6V-3170	Double Acting Cylinder	1
	6V-3009	Crossbar	1
	9U-6600	Hand Hydraulic Pump	1
C	1P-1837	Bearing Puller Adapter	2
D	1P-0520	Driver Group	1

_ . . .

1. Make sure that all of the parts are clean. Inspect all of the parts. Make replacements, if necessary.




Illustration 1

g00627127




Illustration 2



- 2. Lower the temperature of the sleeve bearing if sleeve bearing (19) has been removed. Install the sleeve bearing with Tooling (D) .
- 3. Use Tooling (D) to install the lip seal in the hub. If Tooling (D) is not available, retainer (15) may be installed. Ring (6) and a soft hammer may be used to install lip seal (18).
- 4. Put clean oil on the lip of the seal.




Illustration 3

g01092639

5. Use Tooling (D) and a suitable press in order to install ring (16) in retainer (15).





Illustration 4

g00627125

6. Install pins (17) in the holes that are in the hub.



7. Put retainer (15) in position on the hub. Install bolts (14) that hold the retainer in place. Tighten the bolts to a torque of 135 ± 15 N·m (100 ± 11 lb ft).




Illustration 6

g00627129

8. Remove Tooling (B) and Tooling (C) from the final drive.

Note: For assembly of the planetary carriers, see Disassembly and Assembly, "Final Drive - Assemble".




Illustration 7

g00627120

9. Put sun gear (13) in position in the planetary carrier.

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com