



Operation and Maintenance Manual

TH560B Telehandler

S/N TBP00100 & After

Keep this manual with machine at all times.

Important Safety Information

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "DANGER", "WARNING" or "CAUTION". The Safety Alert "WARNING" label is shown below.



The meaning of this safety alert symbol is as follows:

Attention! Become Alert! Your Safety is Involved.

The message that appears under the warning explains the hazard and can be either written or pictorially presented.

Operations that may cause product damage are identified by "NOTICE" labels on the product and in this publication.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. If a tool, procedure, work method or operating technique that is not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the product will not be damaged or be made unsafe by the operation, lubrication, maintenance or repair procedures that you choose.

The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job. Caterpillar® dealers have the most current information available.



When replacement parts are required for this product Caterpillar recommends using Caterpillar replacement parts or parts with equivalent specifications including, but not limited to, physical dimensions, type, strength and material.

Failure to heed this warning can lead to premature failures, product damage, personal injury or death.

Table of Contents

Foreword

Literature Information	5
Safety	5
Operation	5
Maintenance	5
Maintenance Intervals	5
Certified Engine Maintenance	5
Machine Capacity	5
Contact Information	6

Safety Section

Safety Messages	7
Do Not Operate (1)	10
Do Not Stand Under the Load (2)	10
No Hands (3)	11
Do Not Operate (4)	11
Forks (5)	12
Do Not Weld On The ROPS/FOPS Structure (6)	12
Crushing Hazard (7)	13
No Hands (8)	13
Seat Belt (9)	14
Crushing Hazard (10)	14
Crushing Hazard (11)	15
Engine Coolant (12)	15
Avoid Power Lines (13)	16
Low Bridge (14)	16
Jump Start Cables (15)	17
Ether (16)	17
Crushing Hazard (17)	17
Crushing Hazard (18)	17
Operation (19)	18
Impaling Hazard (20)	18
Crushing Hazard (21)	18
Entanglement and Flying Objects (22)	18
Trap Point (23)	19
Crushing Hazard (24)	19
Ether (25)	19
Hand (High Pressure) (26)	20
Universal Warning (27)	20
Additional Messages	20
General Hazard Information	24
Pressurized Air and Water	24
Trapped Pressure	24
Fluid Penetration	25
Containing Fluid Spillage	25
Dispose of Waste Properly	25
Crushing Prevention and Cutting Prevention	25
Burn Prevention	26
Coolant	26
Oils	26
Batteries	26
Fire Prevention and Explosion Prevention	26
Fire Extinguisher	27
Lines, Tubes and Hoses	27
Fire Extinguisher Location	27
Tire Information	28
Electrical Storm Injury Prevention	28

Before Starting Engine	28
Engine Starting	29
Before Operation	29
Operation	29
Machine Operating Temperature Range	29
Machine Operation	29
Travel	30
Lifting Capacities	30
Work Tools	30
Engine Stopping	30
Work Tools	31
Parking	31
Equipment Lowering with Loss of Hydraulic Power	31
Sound Information and Vibration Information	31
Sound Level	31
Vibration Level	31
Operator Station	32
Guards (Operator Protection)	32
Rollover Protective Structure (ROPS), Falling Object Protective Structure (FOPS)	32
Other Guards (If Equipped)	32

Product Information Section

General Information	33
Lifting Capacities	33
Examples of Estimating the Lift Operation from the Load Chart	34
Specifications	35
Intended Use	35
Application/Configuration Restrictions	35
Identification Information	36
Plate Locations and Film Locations	36
Serial Number	36
Certification	37
Sound	37
ROPS/FOPS Film	37
Machine Security System	37
Italian Roading Homologation	38
Emissions Certification Film	39

Operation Section

Before Operation	41
Mounting and Dismounting	41
Alternate Exit	41
Daily Inspection	41
Machine Operation	43
Alternate Exit	43
Seat	43
Air Suspension (If Equipped)	43
Seat Belt	44
Operator Controls (Side Console)	46
Operator Controls	48
Battery Disconnect Switch (If Equipped)	61
Boom Cylinder Lock (If Equipped)	61
Operation Information	64
Work Tools	71
Monitoring System	78
Backup Alarm	81

Cab Door.....	81	Braking System - Test.....	109
Engine Starting.....	82	Service Brake	109
Engine Starting	82	Parking Brake	109
Starting Below 0 °C (32°F)	82	Cab Air Filter - Clean/Replace	110
Engine and Machine Warm-Up	83	Primary Cab Air Filter	110
Parking	83	Secondary Cab Air Filter.....	111
Stopping the Machine	83	Circuit Breakers - Test	111
Stopping the Engine.....	83	Compensating Cylinder Bearing - Lubricate	111
Stopping the Engine if an Electrical Malfunction		Cooling System Coolant - Change.....	112
Occurs.....	84	Cooling System Coolant Level - Check	113
Leaving the Machine	84	Cooling System Coolant Sample (Level 1) -	
Transportation Information	84	Obtain	113
Shipping the Machine.....	84	Cooling System Coolant Sample (Level 2) -	
Rooding the Machine	84	Obtain	114
Lifting and Tying Down the Machine	85	Cooling System Pressure Cap - Clean/Replace	115
Towing Information.....	86	Cooling System Water Temperature Regulator	
Towing the Machine	86	Replace	115
Engine Starting (Alternate Methods)	88	Differential Oil - Change.....	116
Engine Starting with Jump Start Cables.....	88	Rear Axle Differential.....	116
Equipment Lowering with Loss of Hydraulic		Front Axle Differential	116
Power	89	Differential Oil Level - Check	117
Maintenance Section		Rear Axle Differential.....	117
Maintenance Access	93	Front Axle Differential	117
Access Doors and Covers.....	93	Differential Oil Sample - Obtain	118
Tire Inflation Information	93	Drive Shaft Spline - Lubricate	118
Tire Inflation with Air.....	93	Drive Shaft Universal Joint Bolts - Check	119
Tire Pressure.....	94	Engine Air Filter Primary Element -	
Tire Inflation Pressure Adjustment.....	94	Clean/Replace	119
Tire Damage	95	Cleaning Primary Air Filter Elements.....	120
Tire Replacement.....	95	Inspecting the Primary Air Filter Elements.....	120
Wheel and Tire Installation.....	95	Engine Air Filter Primary Element - Replace	121
Lubricant Viscosities and Refill Capacities.....	96	Engine Air Filter Secondary Element - Replace.....	121
Lubricant Viscosities	96	Engine Mounts - Inspect	121
Capacities (Refill)	98	Engine Oil Level - Check	122
SOS Information.....	98	Engine Oil Sample - Obtain	122
Maintenance Support	99	Engine Oil and Filter - Change.....	122
Welding on Machines and Engines with		Engine Valve Lash - Check.....	124
Electronic Controls	99	Final Drive Oil - Change.....	124
Maintenance Interval Schedule	99	Final Drive Oil Level - Check	125
Axle Breathers - Clean/Replace.....	101	Final Drive Oil Sample - Obtain	125
Backup Alarm - Test.....	101	Fork Leveling Cylinder Pin -Lubricate	126
Battery - Recycle.....	101	Frame Leveling Cylinder Pin -Lubricate.....	126
Battery or Battery Cable -Inspect/Replace.....	101	Fuel System - Prime	126
Belt - Inspect/Replace	101	Fuel System Water Separator - Drain	127
Inspect	101	Fuel System Water Separator Element - Replace	
Replace	102	(Tier II)	127
Boom Chain - Inspect/ Lubricate	103	Fuel System Water Separator Element - Replace	
Boom Chain Tension -Check/Adjust	103	(Tier III)	128
Check Condition.....	103	Fuel Tank Cap - Clean.....	129
Check and Adjust the Chain Tension.....	103	Fuel Tank Water and Sediment - Drain	129
Measure the Chain for Wear.....	104	Fuses and Relays - Replace	130
Boom Cylinder Pin - Lubricate	105	Fuses	130
Boom Head Section - Lubricate	105	Relays.....	132
Boom Pivot Shaft - Lubricate	105	Indicators and Gauges - Test.....	133
Boom Telescoping Cylinder Air- Purge	105	Longitudinal Stability Indicator - Calibrate.....	133
Boom Wear Pad Clearance -Inspect/Adjust.....	106	Longitudinal Stability Indicator -Test	133
Adjustment	107	Initial Test	133
Boom and Frame - Inspect.....	108	Second Test.....	133
		Oil Filter - Inspect.....	134

Table of Contents

Inspect a Used Filter for Debris.....	134
Parking Brake - Adjust.....	134
Pulley for Boom Extension Chain - Lubricate	135
Pulley for Boom Retraction Chain - Lubricate ...	135
Radiator Core - Clean	135
Refrigerant Dryer - Replace	136
Rollover Protective Structure (ROPS) and Falling Object Protective Structure (FOPS) -Inspect	136
Seat Belt - Inspect.....	137
Seat Belt - Replace	137
Stabilizer and Cylinder Bearings - Lubricate	137
Tire Inflation - Check	138
Transmission and Hydraulic System Oil - Change.....	138
Transmission and Hydraulic System Oil Filter - Replace	139
Transmission and Hydraulic System Oil Level - Check	141
Transmission and Hydraulic System Oil Sample - Obtain.....	141
Transmission and Hydraulic System Tank Breather - Clean	142
Turbocharger - Inspect.....	142
Wheel Nut Torque - Check.....	142
Window Washer Reservoir -Fill.....	142
Window Wiper -Inspect/Replace	143
Windows - Clean	143
Work Tool - Inspect/Replace	143
Forks	143
Buckets	145
Reference Information Section	
Approved Work Tools.....	147

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com