



# Bobcat®

EN


---

## Service Manual

# S100 Skid-Steer Loader

---

**S/N A2G811001 & Above**  
**S/N A8ET11001 - A8ET19999**



**EQUIPPED WITH  
BOBCAT INTERLOCK  
CONTROL SYSTEM (BICS)**



# MAINTENANCE SAFETY




## WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903




**Safety Alert Symbol:** This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




B-10731a

⚠ Never service the Bobcat Skid-Steer Loader without instructions.




B-15590

⚠ Use the correct procedure to lift or lower operator cab.




B-15591

⚠ Cleaning and maintenance are required daily.




B-15592

- ⚠ Have good ventilation when welding or grinding painted parts.
- ⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- ⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.




B-15593

⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.




B-15599

- ⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- ⚠ Never modify equipment or add attachments not approved by Bobcat Company.




B-15600

- ⚠ Stop, cool and clean engine of flammable materials before checking fluids.
- ⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.
- ⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- ⚠ Never fill fuel tank with engine running, while smoking or when near open flame.



B-15601

- ⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- ⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- ⚠ Keep rear door closed except for service. Close and latch door before operating the loader.



B-6589

- ⚠ Lead-acid batteries produce flammable and explosive gases.
- ⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
- ⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner / operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW08-0805

## ALPHABETICAL INDEX

AIR CLEANER .....	70-01	HYDRAULIC / HYDROSTATIC SYSTEM .....	10-01
AIR CLEANER SERVICE .....	10-01	HYDRAULIC PUMP .....	20-01
ALTERNATOR .....	60-01	HYDRAULIC SYSTEM INFORMATION .....	20-01
BACK-UP ALARM SYSTEM .....	10-01, 60-01	HYDROSTATIC MOTOR .....	30-01
BATTERY .....	60-01	HYDROSTATIC PUMP .....	30-01
BLOWER FAN .....	20-01	HYDROSTATIC SYSTEM INFORMATION .....	30-01
BOBCAT CONTROLLER (MAIN) .....	60-01	INSTRUMENT PANELS .....	60-01
BOBCAT INTERLOCK CONTROL SYSTEM (BICS) .....	60-01	LIFT ARM BYPASS CONTROL VALVE .....	20-01
BOB-TACH (HAND LEVER) .....	10-01, 50-01	LIFT ARMS .....	50-01
BOB-TACH (POWER) BLOCK .....	20-01	LIFT ARM SUPPORT DEVICE .....	10-01
BOB-TACH (POWER-OPTION) .....	10-01, 50-01	LIFTING AND BLOCKING THE LOADER .....	10-01
BRAKE .....	40-01	LIGHTS .....	60-01
BUCKET POSITION VALVE .....	20-01	LOADER SPECIFICATIONS .....	SPEC-01
CAB DOOR .....	50-01	LOADER STORAGE AND RETURN TO SERVICE .....	10-01
CAMSHAFT AND TIMING GEARS .....	70-01	LUBRICATING THE LOADER .....	10-01
CASE DRAIN FILTER .....	30-01	LUBRICATION SYSTEM .....	70-01
CHAINCASE .....	40-01	MAINTENANCE CLOCK .....	60-01
CHARGE PRESSURE .....	30-01	MAIN RELIEF VALVE .....	20-01
CONTROL HANDLE / LEVER .....	50-01	MUFFLER .....	70-01
CONTROL PANEL .....	50-01	OIL COOLER .....	20-01
CONTROL PANEL SETUP .....	60-01	OPERATOR CAB .....	10-01, 50-01
CONTROL PEDALS AND LINKAGE .....	50-01	OPERATOR SEAT .....	50-01
CONVERSIONS .....	SPEC-01	OPERATOR SEAT (SUSPENSION) .....	50-01
CRANKSHAFT AND PISTONS .....	70-01	PASSWORD SETUP .....	60-01
CYLINDER (BOB-TACH) .....	20-01	PIVOT PINS .....	10-01
CYLINDER HEAD .....	70-01	REAR DOOR .....	50-01
CYLINDER (LIFT) .....	20-01	REAR GRILL .....	50-01
CYLINDER (TILT) .....	20-01	REGULAR MAINTENANCE .....	80-01
DIAGNOSTICS SERVICE CODES .....	60-01	REMOTE START TOOL .....	10-01
DRIVE BELT .....	30-01	SEAT BAR .....	50-01
DRIVE COMPONENTS .....	40-01	SEAT BAR SENSOR .....	60-01
ELECTRICAL SYSTEM INFORMATION .....	60-01	SERVICE PC (LAPTOP COMPUTER) .....	60-01
ENGINE COOLING SYSTEM .....	10-01, 70-01	SERVICE SCHEDULE .....	10-01
ENGINE INFORMATION .....	70-01	SPARK ARRESTOR MUFFLER .....	10-01
ENGINE LUBRICATION SYSTEM .....	10-01	STARTER .....	60-01
ENGINE SPEED CONTROL .....	70-01	STOPPING THE ENGINE AND LEAVING THE LOADER .....	10-01
FINAL DRIVE TRANSMISSION (CHAINCASE) .....	10-01	TIRE MAINTENANCE .....	10-01
FLYWHEEL AND HOUSING .....	70-01	TORQUE SPECIFICATIONS FOR BOLTS .....	SPEC-01
FLYWHEEL RPM SENSOR .....	60-01	TOWING THE LOADER .....	10-01
FRONT AUXILIARY HYDRAULIC COUPLER BLOCK .....	20-01	TRACTION LOCK .....	60-01
FUEL SYSTEM .....	10-01, 70-01	TRANSPORTING THE BOBCAT LOADER .....	10-01
FUEL TANK .....	50-01	TROUBLESHOOTING .....	80-01
HEATER COIL .....	80-01	WINDOW (FRONT DOOR) .....	50-01
HEATER FAN .....	80-01	WINDOW (REAR) .....	50-01
HEATER SYSTEM .....	80-01	WINDOW (SIDE) .....	50-01
HEATER UNIT .....	80-01	WINDOW (TOP) .....	50-01
HEATER VALVE .....	80-01		
HYDRAULIC CONNECTION SPECS .....	SPEC-01		
HYDRAULIC CONTROL VALVE .....	20-01		
HYDRAULIC FLUID RESERVOIR .....	20-01		
HYDRAULIC / HYDROSTATIC FILTERS .....	20-01		
HYDRAULIC / HYDROSTATIC FLUID SPECIFICATIONS .....	SPEC-01		

# CONTENTS

FOREWORD .....	II
SAFETY INSTRUCTIONS .....	V
FIRE PREVENTION .....	VII
SERIAL NUMBER LOCATIONS .....	IX
DELIVERY REPORT .....	X
LOADER IDENTIFICATION .....	XI
SAFETY AND MAINTENANCE .....	10-01
HYDRAULIC SYSTEM .....	20-01
HYDROSTATIC SYSTEM .....	30-01
DRIVE SYSTEM .....	40-01
MAIN FRAME .....	50-01
ELECTRICAL SYSTEM & ANALYSIS .....	60-01
ENGINE SERVICE .....	70-01
HEATER .....	80-01
SPECIFICATIONS .....	SPEC-01

**SAFETY &  
MAINTENANCE**

**HYDRAULIC  
SYSTEM**

**HYDROSTATIC  
SYSTEM**

**DRIVE  
SYSTEM**

**MAIN FRAME**

**ELECTRICAL  
SYSTEM &  
ANALYSIS**

**ENGINE  
SERVICE**

**HEATER**


**SPECIFICATIONS**

# FOREWORD


This manual is for the Bobcat loader mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, starting procedure, daily checks, etc.

A general inspection of the following items must be made after the loader has had service or repair:


1. Check that the ROPS/FOPS (Including side screens) is in good condition and is not modified.




2. Check that ROPS mounting hardware is tightened and is Bobcat approved.



3. The seat belt must be correctly installed, functional and in good condition.



4. The seat bar must be correctly adjusted, clean and lubricated.




5. Check lift arm support device, replace if damaged.



6. Machine signs (decals) must be legible and in the correct location.




7. Steering levers, hand controls and foot pedals must return to neutral (as applicable).




8. Check for correct function of the work lights.




9. The parking brake must function correctly.




10. Enclosure door latches must open and close freely.




11. Bob-Tach wedges and linkages must function correctly and be in good condition.




12. Safety treads must be in good condition.




13. Check for correct function of indicator lamps.




14. Check hydraulic fluid level, engine oil level and fuel supply.



15. Inspect for fuel, oil or hydraulic fluid leaks.




16. Lubricate the loader.




FW SSL-0308 SM

Dealer Copy -- Not for Resale


17. Check the condition of the battery and cables.



18. Inspect the air cleaner for damage or leaks. Check the condition of the element.




19. Check the electrical charging system.



20. Check tires for wear and pressure. Check tracks for wear and tension. Use only approved tires or tracks.




21. Inspect for loose or broken parts or connections.




22. Check for any field modification not completed.



23. Operate the machine and check all functions.




24. Check for correct function of the Bobcat Interlock Control System (BICS™) before the machine is returned to the customer.



25. Check function or condition of all equipped options and accessories (examples: back-up alarm, fire extinguisher, rotating beacon, lift kits, etc.).



26. Recommend to the owner that all necessary corrections be made before the machine is returned to service.



Dealer Copy -- Not for Resale

## SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

SI SSL-0308 SM

## FIRE PREVENTION



### Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

### Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

### Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

## Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

### Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

### Starting

Do not use ether or starting fluids on any engine that has glow plugs. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

### Spark Arrestor Exhaust System

The spark arrestor exhaust system is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrestor exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

SI SSL-0308 SM



## FIRE PREVENTION (CONT'D)


### Welding And Grinding

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

### Fire Extinguishers




Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

SI SSL-0308 SM

## SERIAL NUMBER LOCATIONS

Always use the serial number of the loader when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.


**Figure 1**



### Loader Serial Number

The loader serial number plate (Item 1) [Figure 1] is located inside the cab on the right-hand side.

Explanation of loader Serial Number:




1. The four digit Model / Engine Combination Module number identifies the model number and engine combination.

2. The five digit Production Sequence Number identifies the order which the loader is produced.

### Engine Serial Number

**Figure 2**



The engine serial number is located on top of the engine (Item 1) [Figure 2].


## DELIVERY REPORT

Figure 3

The diagram shows a form layout for a 'DELIVERY REPORT'. It features a header section at the top right, a 'WARNING' section on the left, and a main body of text on the right. A small box at the bottom right contains the code 'B-16315'.

The delivery report must be filled out by the dealer and signed by the owner or operator when the Bobcat Loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely **[Figure 3]**.

**LOADER IDENTIFICATION**



- \* TIRES - Tires shown may not be standard. The machine is factory equipped with standard tires. Other tires are available.
- ROPS, FOPS - Roll Over Protective Structure, per ISO 3471, and Falling Object Protective Structure per ISO 3449, Level I. Level II is available.
- † Bucket - Several different Buckets and other Attachments are available.

Dealer Copy -- Not for Resale

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)