




Bobcat®

Service Manual Stump Grinder

(SG30) S/N 005600101 & Above
(SG60) S/N 233000101 & Above
(SGX60) S/N A00700101 & Above



Dealer Copy -- Not for Resale



MAINTENANCE SAFETY




WARNING









Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0807



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.



-  Never service attachments / implements without instructions. See Operation & Maintenance Manual and Attachment / Implement Service Manual.
-  Cleaning and maintenance are required daily.
-  Never service or adjust attachment / implement with the engine running unless instructed to do so in manual.
-  Always lower the attachment / implement to the ground before lubricating or servicing.
-  Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
-  Stop, cool and clean engine of flammable materials before checking fluids.
-  Keep body, loose objects and clothing away from moving parts, electrical contacts, hot parts and exhaust.
-  Safety glasses are needed for eye protection from electrical arcs, battery acid, compressed springs, fluids under pressure and flying debris or when tools are used. Use eye protection approved for type of welding.

CONTENTS

SAFETY AND MAINTENANCE	10-01
HYDRAULIC SYSTEM	20-01
MAINFRAME	30-01
SPECIFICATIONS	SPEC-01
ALPHABETICAL INDEX	INDEX-01

Dealer Copy -- Not for Resale

FOREWORD

SERIAL NUMBER LOCATION	1-7
Attachment Serial Number	1-7
DELIVERY REPORT	1-7
ATTACHMENT IDENTIFICATION (SG60 AND SGX60)	1-8
ATTACHMENT IDENTIFICATION (SG30)	1-9

SERIAL NUMBER LOCATION

Attachment Serial Number

Always use the serial number of the stump grinder when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

Figure 1






Figure 2



DELIVERY REPORT


Figure 3



The delivery report [Figure 3] must be completed by the dealer and signed by the owner or operator when the Bobcat chipper is delivered. An explanation of the form must be given to the owner.

Dealer Copy -- Not for Resale

ATTACHMENT IDENTIFICATION (SG60 AND SGX60)




WARNING

FLYING OBJECTS AND ROTATING GRINDING WHEEL CAN CAUSE SERIOUS INJURY OR DEATH

- Stay at least 4 m (12 ft) away from operating equipment.
- Do not operate with damaged or missing screens, shields or rubber deflectors.
- Stop engine before cleaning or servicing.

6808208

Quick Couplers And Wire Harness



WARNING

FLYING OBJECTS AND ROTATING GRINDING WHEEL CAN CAUSE SERIOUS INJURY OR DEATH

- Stay at least 4 m (12 ft) away from operating equipment.
- Do not operate with damaged or missing screens, shields or rubber deflectors.
- Stop engine before cleaning or servicing.

6808208



OPERATION INSTRUCTIONS

- Wear eye protection when using grinder attachment.
- Keep frame firmly on ground when grinding.
- See Operation & Maintenance Manual for more instructions.

6808209

P-15984
P-15981

Dealer Copy -- Not for Resale



Dealer Copy -- Not for Resale

P-47912
P-47913


SAFETY AND MAINTENANCE

TROUBLESHOOTING	10-10-1
Chart	10-10-1
DAILY INSPECTION	10-20-1
Attachment Mounting Frame	10-20-1
Bob-Tach	10-20-2
Rubber Debris Shield Inspection	10-20-4
Screen Inspection	10-20-5
Screen Replacement	10-20-6
LUBRICATING THE ATTACHMENT (SG60 AND SGX60)	10-30-1
Lubrication Locations	10-30-1
LUBRICATING THE ATTACHMENT (SG30)	10-31-1
Lubrication Locations	10-31-1
CUTTING TEETH (SG60 AND SGX60)	10-40-1
Removal And Installation	10-40-1
Cutting Teeth Pattern	10-40-3
CUTTING TEETH (SG30)	10-41-1
Removal And Installation	10-41-1
Cutting Teeth Pattern	10-41-2

Dealer Copy -- Not for Resale

TROUBLESHOOTING

Chart

 WARNING	<p>Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.</p>
	W-2003-0903

If the stump grinder is not working correctly, check the hydraulic system of the machine thoroughly before making any repairs on the stump grinder. Stump grinder problems can be affected by a hydraulic system that is not operating to specifications. Connect a flow meter to the machine to check the hydraulic pump output, relief valve setting and tube lines to check flow and pressure. (See the machine's Service Manual for the correct procedure to connect the flow meter.)

Use the following troubleshooting chart to locate and correct problems which most often occur with the stump grinder.

PROBLEM	CAUSE	CORRECTION
Stump grinder cut is inadequate.	Cutting teeth worn or missing.	Replace the cutting teeth.
Noisy motor (with load).	Vibration; loose bolts.	Check torque.
Noisy motor (with no load).	Humming; worn bearings.	Replace bearings.
External oil leaks.	Motor case pressure too high.	Check the quick couplers.
	Damaged O-rings.	Replace O-rings as needed.
Loaded motor does not turn at normal speed.	Not enough hydraulic flow.	Check pump flow and rotation speed.
	Internal leaks.	Check cylinders and valve block assembly. Check motor.
Cutter motor does not rotate.	Front auxiliary hydraulics not engaged.	Engage the loader front auxiliary.
	Couplers are reversed.	Switch couplers.
	Excessive hydraulic leakage.	Check hoses and valve block.
	Hydraulic leaks.	Check cylinders and valve block assembly. Check pump drive and pump inlet.
	No hydraulic flow.	Check valves for damage or corrosion.
Cutter wheel hops.	Cutting teeth worn or missing.	Replace the cutting teeth.
	Cutting teeth setting wrong.	Reset cutting teeth.
Cutter wheel stalls.	Relief valve for boom swing cylinder set too high.	Replace relief valve.
	Cutting depth too deep.	Raise boom.
	Plug orifice blocked.	Check hydraulic lines and valve.
Swing cylinder stalls.	Relief pressure set too low.	Replace relief valve.
Relief valve chatters.	Relief pressure set too low.	Replace relief valve.


Dealer Copy -- Not for Resale

DAILY INSPECTION

Attachment Mounting Frame

SG60 And SGX60

Figure 10-20-1




Inspect the Bob-Tach wedge mounts (Item 1), mounting flange (Item 2) [Figure 10-20-1] and all welds on the stump grinder for wear and damage each time the stump grinder is removed from the loader.

Frequently inspect the stump grinder to ensure that all components are secure and that all bolts and nuts are thoroughly tightened.

SG30

Figure 10-20-2



Inspect the Bob-Tach wedge mounts (Item 1), mounting flange (Item 2) [Figure 10-20-2] and all welds on the stump grinder for wear and damage each time the stump grinder is removed from the loader.

Frequently inspect the stump grinder to ensure that all components are secure and that all bolts and nuts are thoroughly tightened.

Dealer Copy -- Not for Resale

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com