CATERPILLAR®

Service Repair Manual

Model

232D Skid Steer Loader

Model: 232D SKID STEER LOADER KXC

Configuration: 232D Skid Steer Loader KXC00001-UP (MACHINE) POWERED BY C2.2 Engine

Disassembly and Assembly

C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR6948-06

Publication Date -01/06/2015

Date Updated -02/08/2018

i06720081

Flywheel - Remove

SMCS - 1156-011

Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	138-7573	Link Bracket	1
В	-	Guide Stud (M10 x 1.25 mm by 80mm)	2

Start By:

a. Remove the electric starting motor. Refer to Disassembly and Assembly, "Electric Starting Motor - Remove and Install".

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

Note: The three cylinder and the four cylinder engines have different flywheels. The removal

Note: The three cylinder and the four cylinder engines have different flywheels. The removal procedure is similar for all models.




Illustration 1 g01305297

Typical example

- 1. Install Tooling (A) and a suitable lifting device to flywheel (2). The weight of the flywheel is approximately 42 kg (93 lb).
- 2. Remove two bolts (1) from positions (X) on the flywheel.
- 3. Install Tooling (B) in positions (X) on the flywheel.
- 4. Remove the remaining bolts (1) and remove flywheel (2).

Note: On some three cylinder engines, a roll pin is located between the crankshaft and the flywheel.

5. Inspect ring gear (3) and flywheel (2) for wear or damage. If the ring gear or the flywheel is worn or damaged, use new parts for replacement.




Illustration 2 g00825639 Typical example

6. To remove ring gear (3) from flywheel (2), place the flywheel on a suitable support. Use a hammer (not shown) and a punch (4) to remove the ring gear from the flywheel.

Copyright 1993 - 2019 Caterpillar Inc.

All Rights Reserved.

Private Network For SIS Licensees.

Thu Oct 3 21:43:14 UTC+0800 2019



Service Information System

Shutdown SIS

Previous Screen

Model: 232D SKID STEER LOADER KXC

Configuration: 232D Skid Steer Loader KXC00001-UP (MACHINE) POWERED BY C2.2 Engine

Disassembly and Assembly

C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR6948-06

Publication Date -01/06/2015

Date Updated -02/08/2018

i06720105

Flywheel - Install

SMCS - 1156-012

Installation Procedure

Table 1

Required Tools				
Tool	Part Number	Part Description	Qty	
A	138-7573	Link Bracket	1	
В	-	Guide Stud (M10 x 1.25 mm by 80mm)	2	

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.



Always wear protective gloves when handling parts that have been heated.

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com