



# Service Repair Manual

## **Model**

**235B EXCAVATOR**

---

[Previous Screen](#)

Product: EXCAVATOR

Model: 235B EXCAVATOR 9PC

Configuration: 235B EXCAVATOR 9PC00001-UP (MACHINE) POWERED BY 3306 ENGINE

## Disassembly and Assembly 3304B and 3306B Engines for Caterpillar Built Machines

Media Number -SEN5598-09

Publication Date -01/01/2013

Date Updated -25/01/2013

i00984196

# Fuel Priming Pump - Remove and Install

SMCS - 1258-010

## Removal Procedure

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

### NOTICE

**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the machine. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Caterpillar Tools and Shop Products Guide", for tools and supplies suitable to collect and contain fluids in Caterpillar machines.**

**Dispose of all fluids according to local regulations and mandates.**

---

---




Illustration 1

g00500957

1. Turn the fuel supply line valve to the OFF position.
2. Remove the bolts and the washers that secure fuel priming pump (1) to base (5). Remove gasket (4) .
3. Disconnect tube assembly (3) .
4. Remove two bolts (2), the washers and base (5) from the cylinder block.

## Installation Procedure

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---




Illustration 2

g00500957

1. Install base (5), the washers and two bolts (2) .

2. Connect tube assembly (3) to base (5) .

**Note:** Check the condition of the gaskets. If the gaskets are worn or damaged, use new parts for replacement.

3. Install gasket (4). Install fuel priming pump (1) and the bolts that secure the fuel priming pump to base (5) .

4. Turn the fuel supply line valve to the ON position.

[Previous Screen](#)

Product: EXCAVATOR

Model: 235B EXCAVATOR 9PC

Configuration: 235B EXCAVATOR 9PC00001-UP (MACHINE) POWERED BY 3306 ENGINE

## Disassembly and Assembly 3304B and 3306B Engines for Caterpillar Built Machines

Media Number -SEN5598-09

Publication Date -01/01/2013

Date Updated -25/01/2013

i00917143

# Fuel Filter Base - Remove and Install

SMCS - 1262-010

## Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	2P-8250	Strap Wrench Assembly	1

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

### NOTICE

**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the machine. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Caterpillar Tools and Shop Products Guide", for tools and supplies suitable to collect and contain fluids in Caterpillar machines.**

**Dispose of all fluids according to local regulations and mandates.**

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)