



Service Repair Manual

Models

Caterpillar Cat 236 SKID
STEER LOADER

Product: SKID STEER LOADER

Model: 236 SKID STEER LOADER 4YZ

Configuration: 236, 246, 248 Skid Steer Loader 4YZ00001-03999 (MACHINE) POWERED BY 3034 Engine

Disassembly and Assembly 3034 Engine for Caterpillar Built Machines

Media Number -SEN5013-08

Publication Date -01/11/2008

Date Updated -14/11/2008

i01368091

Idler Gear - Remove and Install

SMCS - 1206

Removal Procedure

Start By:

- A. Remove the fan. Refer to Disassembly and Assembly, "Fan - Remove and Install".
- B. Remove the front cover. Refer to Disassembly and Assembly, "Housing (Front) - Remove".

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Tools and Shop Products Guide" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.




Illustration 1

g00721939

Note: Rotate the crankshaft until the timing marks on the following gears are aligned: crankshaft gear, camshaft gear, fuel injection pump gear and idler gear (1) .

1. Remove outer washer (3) from the idler gear shaft.
2. Use a suitable puller to remove idler gear (2) .

Note: Do not rotate the crankshaft once the idler gear has been removed. If the crankshaft is rotated, the number 1 piston must be set to the top center position. Refer to Testing and Adjusting, "Finding Top Center Position for No. 1 Piston".

3. Remove the inner washer from the idler gear shaft (not shown). The inner washer is located behind the idler gear.

Remove the Idler Gear Shaft

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1P-0074	Slide Hammer Puller Gp	1
B	4C-5651	Threaded Adapter	1




Illustration 2

g00721895

- (4) Idler gear shaft
- (5) Oil hole
- (6) O-ring seal




Illustration 3

g00721904

1. Remove O-ring seal (6) .
2. Thread tool (B) onto tool (A) .
3. Use tool (A) to remove idler gear shaft (4) .

Install the Idler Gear Shaft

Table 2

Required Tools			
Tool	Part Number	Part Description	Qty
C		Installation Tool	1




Illustration 4

g00721922

1. Ensure that oil hole (5) is in the up position.
2. Use a soft hammer (8) to start the idler gear shaft into the cylinder block.



Illustration 5

g00721925

3. Use tool (C) and tool (D) to install the idler gear shaft.
4. Drive the idler gear shaft with the installation tool until the installation tool makes contact with the machined surface of the cylinder block.

Installation Procedure

1. Install O-ring seal (6) .
2. Install the inner washer onto the idler gear shaft.
3. Install idler gear (2) .

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com