



Service Repair Manual

Models

308E2SR Mini
Hydraulic Excavator

Product: MINI HYD EXCAVATOR

Model: 308E2 SR MINI HYD EXCAVATOR TM2

Configuration: 308E 2SR Mini Hydraulic Excavator TM200001-UP (MACHINE) POWERED BY C3.3B Engine

Disassembly and Assembly

C3.3B Tier 4 Final and EU Stage 3B Engines for Caterpillar Built Machines

Media Number -UENR3278-07

Publication Date -01/09/2014

Date Updated -11/07/2016

i05224034

Inlet and Exhaust Valve Springs - Remove and Install

SMCS - 1108-010

Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	7F-4292	Valve Spring Compressor	1
	9U-6144	Adapter	1

Start By:

- a. Remove the rocker shaft and push rod.

Note: Refer to Specification UENR3421 "Engine Design" for non-specified engine Torque Values.

Note: The following procedure should be adopted in order to remove the valve springs when the cylinder head is installed to the engine. Refer to Disassembly and Assembly, "Inlet and Exhaust Valves - Remove and Install" for the procedure to remove the valve springs from a cylinder head that has been removed from the engine.

Note: Ensure that the appropriate piston is at top dead center before the valve spring is removed. Failure to ensure that the piston is at top dead center may allow the valve to drop into the cylinder bore.




Illustration 1

g02799356




Illustration 2

g02725099

WARNING

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

NOTICE

Ensure that the valve spring is compressed squarely or damage to the valve stem may occur.

1. Follow Step 1.a through Step 1.d in order to position the appropriate piston at top dead center.

a. Install Tooling (A) in position on the cylinder head in order to compress a valve spring (4) for the appropriate piston.

b. Use Tooling (A) in order to compress valve spring (4) and open the valve slightly.

Note: Do not compress the spring so that valve spring retainer (3) touches the valve stem seal.

c. Rotate the crankshaft carefully, until the piston touches the valve.

Note: Do not use excessive force to turn the crankshaft. The use of force can result in bent valve stems.

d. Continue to rotate the crankshaft and gradually release the pressure on Tooling (A) until the piston is at the top dead center position. The valve is now held in a position that allows the valve spring to be safely removed.

Note: If all valve springs require replacement, the procedure can be carried out on two cylinders at the same time. The procedure can be carried out on the following pairs of cylinders. 1 with 4 and 2 with 3. Ensure that all of the valve springs are installed before changing from one pair of cylinders to another pair of cylinders.

NOTICE

Do not turn the crankshaft while the valve springs are removed.

2. Remove valve cap (1). Apply sufficient pressure to Tooling (A) in order to allow removal of valve keepers (2).

Note: Do not compress the spring so that valve spring retainer (3) touches the valve stem seal.

3. Slowly release pressure on Tooling (A).

4. Remove valve spring retainer (3) and remove valve spring (4).



5. Remove Tooling (A).
6. Remove valve stem seals (5).
7. Repeat Step 2 through Step 5 in order to remove the remaining valve springs from the appropriate cylinder.

Installation Procedure

1. Install the inlet and exhaust valve springs in the reverse order of removal.




Illustration 4

g02862476

- a. Install valve springs with the smaller pitch end (6) downward on cylinder head side.
- b. Inspect valve springs (4) for damage and for the correct length. Refer to Specifications, "Cylinder Head Valves " for further information.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com