CATERPILLAR®

Service Repair Manual

Models

320D2 and 320D2 L Excavator

Model: 320D2 EXCAVATOR ZBD

Configuration: 320D2 & 320D2 L Excavators ZBD00001-UP (MACHINE) POWERED BY C7.1 Engine

Disassembly and Assembly

C7.1 (Mech) Engines for Caterpillar Built Machines

Media Number -UENR0674-08

Publication Date -01/06/2015

Date Updated -23/01/2017

i04780405

Crankshaft Rear Seal - Remove

SMCS - 1161-011

Removal Procedure

Table 1

Required Tools				
Tool	Part Number	Part Description	Qty	
A	227-4389	E10 Torx Socket	1	

Start By:

a. Remove the flywheel. Refer to Disassembly and Assembly, "Flywheel - Remove".

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids. **Note:** The crankshaft rear seal and the housing are manufactured as a one-piece assembly. The assembly is not serviceable. If the crankshaft rear seal is removed, the assembly must be replaced.




Illustration 1 g02711971

- 1. Use Tooling (A) in order to remove torx screws (1) from crankshaft rear seal (2).
- 2. Remove crankshaft rear seal (2) from the cylinder block. Discard the crankshaft rear seal.

<u>Copyright 1993 - 2020 Caterpillar Inc.</u> All Rights Reserved.

Private Network For SIS Licensees.

Sun Jan 19 00:03:08 UTC+0800 2020

Model: 320D2 EXCAVATOR ZBD

Configuration: 320D2 & 320D2 L Excavators ZBD00001-UP (MACHINE) POWERED BY C7.1 Engine

Disassembly and Assembly

C7.1 (Mech) Engines for Caterpillar Built Machines

Media Number -UENR0674-08

Publication Date -01/06/2015

Date Updated -23/01/2017

i04780403

Crankshaft Rear Seal - Install

SMCS - 1161-012

Installation Procedure

Table 1

Required Tools				
Tool	Part Number	Part Description	Qty	
A	227-4389	E10 Torx Socket	1	
В	FT-2806	Alignment Tool	1	

Note: The crankshaft rear seal and the housing are manufactured as a one-piece assembly.

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.




Illustration 1 g02717043

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com