



# Service Repair Manual

## **Model**

322C and 322C L 322CL Excavator

---

Product: EXCAVATOR

Model: 322C EXCAVATOR DAA

**Configuration:** 322C & 322C L Excavators DAA00001-UP (MACHINE) POWERED BY 3126 Engine

## Disassembly and Assembly

### 322C Excavator Machine Systems

**Media Number -REN3843-07**

**Publication Date -01/02/2017**

**Date Updated -20/02/2017**

i02566235

## Pilot Valve (Joystick) - Disassemble


**SMCS - 5059-015**

## Disassembly Procedure

## Start By:

- a. Remove the pilot valve. Refer to Disassembly and Assembly, "Pilot Valve (Joystick) - Remove".

**Note:** Cleanliness is an important factor. Before the disassembly procedure, the exterior of the component should be thoroughly cleaned. This will prevent dirt from entering the internal mechanism.




Spool assembly (17) is installed in port (1) and port (3) in the pilot valve.


Spool assembly (18) is installed in port (2) and port (4) in the pilot valve.

Spring seat (7) is installed in port (1) and port (3) in the pilot valve.

Spring seat (10) is installed in port (2) and port (4) in the pilot valve.



1. Remove rubber boot (4) from the pilot valve.



---

Illustration 3

g01021450

## **WARNING**

**Personal injury can result from being struck by parts propelled by a released spring force.**

**Make sure to wear all necessary protective equipment.**

**Follow the recommended procedure and use all recommended tooling to release the spring force.**

---

2. Measure Distance (A) from the top of plate (12) to the top of plate (20). Record Dimension (a) for assembly purposes.
  3. Tighten nut (8) against plate (12). Remove plate (12), nut (8), and U-joint (14).  
**Note:** If U-joint (14) or plate (12) is not being replaced, do not remove plate (12) from U-joint (14).
  4. Remove nut (8) from U-joint (14).
  5. Remove plate (12) from U-joint (14).
  6. Remove plate (20) from the pilot valve.
-




Illustration 4

g00914179

**Note:** The spring seat and the spring may fall out of the rod while you remove the plug.

**Note:** Mark the seat and the spring for assembly purposes. Spring seat (7) is installed in port (1) and port (3) in the pilot valve. Spring seat (10) is installed in port (2) and port (4) in the pilot valve.

7. Remove plug (2) from the pilot valve.
8. Remove spring seat (7) or (10) and spring (6) from rod (5).
9. Remove rod (5) from plug (2).
10. Remove O-ring seal (3) from plug (2).
11. Remove seal (1) from plug (2).

**Note:** Spool assembly (17) is installed in Port (1) and Port (3) in the pilot valve. Spool assembly (18) is installed in Port (2) and Port (4) in the pilot valve.

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)