



Service Repair Manual

Models

430D Backhoe Loader

Product: BACKHOE LOADER

Model: 430D BACKHOE LOADER BNK

Configuration: 430D Backhoe Loader BNK02502-05899 (MACHINE) POWERED BY 3054 Engine

Disassembly and Assembly 416D, 420D, 424D, 428D, 430D, 432D, 438D and 442D Backhoe Loaders Power Train

Media Number -REN3578-12

Publication Date -01/04/2010

Date Updated -13/04/2010

i02557470

Transmission (Power Shift) - Disassemble

SMCS - 3030-015-PM; 3066-015

Disassembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1U-7502	Repair Stand	1
B	152-7085 ⁽¹⁾	Transmission Shaft Handler	1
	189-0409	Shackle As	1
C	1P-0074	Slide Hammer	1
D	8H-0063	Bearing Puller Assembly	1
	6V-3010	Puller Group	1
	126-7177	Leg	2
E	1U-6405	Puller	1
F	152-7055	Spring Compressor	1
G	1U-6400	Puller	1
H	128-5041	Bearing Puller	1
	6V-3010	Puller Group	1
	126-7177	Leg	2
I	6V-2157	Link Bracket	1

(1) CE Compliant

Start By:

- A. Remove the transmission. Refer to Disassembly and Assembly, "Transmission (Powershift) - Remove".

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Note: Cleanliness is an important factor. Before the disassembly procedure, the exterior of the component should be thoroughly cleaned. This will help to prevent dirt from entering the internal mechanism.

Note: The transmission will be disassembled in major components. The major components will then be disassembled.




Illustration 1

g00730318

1. Use a suitable lifting device in order to install transmission (1) on tooling (A) . The weight of transmission (1) is 172 kg (379 lb).
-




Illustration 2

g00730319

2. Remove two valve groups (2) .




Illustration 3

g00730320

3. Remove nut (3) , washer (4) , and coil assembly (5) . Remove seal kit (6) from cartridge (7) .



Illustration 4

g00730321

4. Remove magnetic sensor (8) .



Illustration 5

g00730322




Illustration 6

g00730323

5. Remove tube assembly (9) .



Illustration 7

g00730324

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com