



# Service Repair Manual

## **Models**

# 962G Wheel Loader

---

Product: WHEEL LOADER

Model: 962G WHEEL LOADER 5AS

Configuration: 962G Wheel Loader 5AS00001-UP (MACHINE) POWERED BY 3126 Engine

## Disassembly and Assembly

### 950G and 962G Wheel Loaders and IT62G Integrated Toolcarrier Power Train

Media Number -SEN1381-10

Publication Date -01/10/2007

Date Updated -25/10/2007

i05754103

## Torque Converter - Disassemble

SMCS - 3101-015


### Disassembly Procedure

Table 1


Required Tools			
Tool	Part Number	Part Description	Qty
A	439-3940	Link Bracket	3
B	1P-7405	Eyebolt	2
C	2P-8312	Retaining Ring Pliers	1

#### Start By:

- A. Separate the torque converter from the transmission and from the output gears. Refer to Disassembly and Assembly, "Torque Converter from Transmission, Output Gears - Separate".




1. Use Tooling (A) and a suitable lifting device to place torque converter housing (1) onto suitable cribbing, as shown.



---

Illustration 2

2. Remove transmission oil pump (2) . Refer to Disassembly and Assembly, "Transmission Oil Pump - Remove".
3. Remove bolt (3) and washer (4) .



---

Illustration 3

4. Remove torque converter speed sensor (5) .
-



Illustration 4

g00319448

5. Remove bolts (6) that hold the torque converter to the torque converter housing.




Illustration 5

g00319449

6. Remove bolts (7) and pump drive flange (8) .




Illustration 6

g00319450

7. Remove bolt (9) that holds shaft (10) to the torque converter housing.




Illustration 7

g00319451

8. Install Tooling (B) in pump drive gear (11) .
9. Lift pump drive gear (11) and drive gear shaft (10) . Lift drive gear shaft (10) out of the torque converter housing bore.
10. Place the assembly to one side of the torque converter housing bore. Make sure that drive gear shaft (10) is not in the torque converter housing bore.




Illustration 8

g00319453

11. Remove Tooling (B) from pump drive gear (11) .
  12. Remove drive gear shaft (10) from pump drive gear (11) .
  13. Remove bearing (12) from pump drive gear (11) .
-

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)