

# 2800 SEMI-INTEGRAL MOLDBOARD PLOW



## OPERATORS MANUAL 2800 SEMI-INTEGRAL MOLDBOARD PLOW

OMA50281 C5 English

JOHN DEERE HARVESTER WORKS  
OMA50281 C5

LITHO IN THE U.S.A. (REVISED)  
ENGLISH




## INTRODUCTION



**This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.**

"Right-hand" and "left-hand" sides are determined by facing in the direction the plow will travel when in use.



This plow is of metric design.

For your convenience, most specifications are given in metric measurement with the customary U.S. measurement following.

Some specifications cannot be converted. These appear in metric only.

Most hardware is metric. Specified metric hardware must be used for replacement.



**CAUTION: Use only metric tools. Other tools may not fit properly. They may slip and cause injury.**

Record the identification number(s) in the space provided following Specifications. Accurately record all of the characters because (should the product be stolen) tracing is sometimes through a computer match of letters and numbers. Also, your dealer needs this information when ordering parts. If you carry your operator's manual on the machine for reference, be sure to also record the identification number(s) on a separate sheet of paper and file it in a secure place not on the machine so you will still have a record in case the machine is stolen.

The warranty on this plow appears on your copy of the purchase order which you should have received from your dealer when you purchased the plow.



# Contents

---

**Page****2-3 Safety****4 Identification Views****5-8 Preparing the Tractor****9-19 Preparing the Plow****20-26 Attaching and Detaching****27-31 Transporting****32-57 Operating the Plow****58-59 Attachments****60-64 Lubrication****65-66 Trouble Shooting****67-71 Service****72 Storage****73-74 Specifications****75 Index**




# Safety

2-3

## Transport Safely

While transporting the plow on a public road, install transport safety locks and follow safety instructions outlined under "Transporting."

Use care when transporting across rough ground.



## Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result.

X3811

## Operate the Plow Safely

Never ride or permit others to ride on the plow.

Allow the tailwheel to clear the furrow before making sharp turns at end of field.

Stay clear of standards while plowing.

Stay clear of the reset path if the standards hang in a partially-tripped position from an obstruction or during maintenance.

Always lower the plow to the ground when not in use.

Always use the support stand to support the plow before unhitching from the tractor.

Lower plow to within 50 mm (2 in.) of ground before releasing quick-coupler latch handles.

## Do Not Modify the Plow

Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.


### Service Tires Safely

Failure to follow proper procedures when mounting a tire on a wheel or rim can produce an explosion which may result in serious injury or death. Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job. Have it done by your John Deere dealer or a qualified tire repair service.

When sealing tire beads on rims never exceed 241 kPa (2.4 bar) (35 psi) or maximum inflation pressures specified by tire manufacturers for mounting tires. Inflation beyond this maximum pressure may break the bead, or even the rim, with dangerous explosive force. If both beads are not seated when the maximum recommended pressure is reached deflate, reposition tire, relubricate bead and reinflate.

Detailed agricultural tire mounting instructions, including necessary safety precautions, are contained in John Deere Fundamentals of Service (FOS) Manual 55, Tires and Tracks, available through your John Deere dealer. Such information is also available from the Rubber Manufacturers Association and from tire manufacturers.

- A—Use a safety cage if available.
- B—Do not stand over tire. Use a clip-on chuck and extension hose.



2-3


TS-0123

### Protect Against Noise

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Hearing protective devices such as earmuffs (A) or earplugs (B) can effectively protect against loud noises.

Wear a suitable hearing protective device when you are exposed to noise which is objectionable or uncomfortable.



X7662

X7662

### Lubricate the Plow Safely

Do not grease, oil or adjust the plow while it is in motion.


### Dispose of Spray Cans Safely

If spray can paint is used for protecting plow bottoms to be put in storage, be careful when discarding empty can. Do not incinerate or puncture can.




# Identification Views

4



A—Spring-Reset Standard    B—Mechanical Turnbuckle    C—Shear-Bolt Coulters    D—Stand    E—Steering Control Cylinder

*John Deere 2800 In-Furrow 6 Bottom Semi-Integral Moldboard Plow with Spring-Reset Standards*



A—Spring-Reset Standard    B—Shear-Bolt Coulters    C—Front Furrow Wheel    D—Stand    E—Steering Control Cylinder

*John Deere 2800 On-Land 7 Bottom Semi-Integral Moldboard Plow with Spring-Reset Standards*



# Preparing The Tractor

---

## TIRE INFLATION

Inflate tractor tires as recommended in the tractor operator's manual.

## TRACTOR DRAWBAR

Set tractor drawbar in the short, high position.

5-8

## TRACTOR WHEEL SETTING

### Tractor Wheel in Furrow (In-Furrow Plows)

Set the rear wheels at 760 mm (30 in.) from the center line of the tractor to the inside of the tire.

Other tractor wheel settings can be used but the hitch crossbar must be adjusted accordingly. Moving the hitch crossbar one setting equals 75 mm (3 in.) difference in wheel tread.

If, for example, the tractor wheel setting is approximately 840 mm (33 in.), move the hitch crossbar one setting to the left. If the tractor wheel setting is approximately 685 mm (27 in.), move the hitch crossbar one setting to the right. For any wheel settings in between, move the hitch crossbar one setting as desired.

On wide-front-end tractors, to get proper field maneuverability when plowing with tractor wheel in furrow, set the front wheels to conform to the rear-wheel setting.

When contour plowing in the furrow, set the front wheels at least 50 mm (2 in.) wider than rear wheels. Measure dimension from center of tractor to inside edge of tire.

### Tractor Wheels on the Land (On-Land Plows)

Set wheels from the center line of the tractor.

When operating the tractor with all wheels on the land, set the wheels (depending on size of plow) to leave at least 100 mm (4 in.) between the furrow wall and the outside edge of the right tractor tire.

*NOTE: If tractor is equipped with dual rear wheels, set wheels in narrowest available setting. See tractor operator's manual.*

## BALLAST

### Front End Weighting (2 Wheel Drive Tractors)

The amount of front weight required is determined by field operating conditions and the gear in which the tractor is operated.


**⚠ CAUTION:** When the tractor is operated in lower gears, under 6.5 km/h (4 mph), maximum permissible front-end weighting is necessary to avoid front-end tip-up.

### Drive Wheel Weighting

Use wheel weights to eliminate excessive wheel slippage and for stability in rough or hillside fields. However, weights should not be added to the point where all slippage is eliminated. To do so hinders maximum performance of the tractor. See tractor operator's manual.

5-8

## SWAY BLOCKS



4850 Tractor Illustrated

RW7165

### 2 Wheel Drive Tractors

Install sway blocks (A) in the lower position to eliminate side sway while in the working position.


See your tractor operator's manual for instructions on positioning sway blocks.



### 4 Wheel Drive Tractors

The sway blocks (A) should be positioned for limited sway to prevent plow damage while in the working position.

See your tractor operator's manual for instructions on positioning sway blocks.



8650 Tractor Illustrated


A25963

## DRAFT LINK BUMPERS

### (4650, 4850, 8450, 8650 and 8850 Tractors)

Install draft link bumpers (A) with thick ends forward for Category 3 or 4; thin ends forward for Category 3N or 4N.

See your tractor operator's manual for instructions on positioning sway blocks.



RW4872


## LIFT LINKS

### In-Furrow

Left Lift Link (A) - Set approximately in the middle.

Right Lift Link (B) - Set 25 mm (1 in.) shorter than left lift link.


Center Link (C) - Adjust center link so plow mast is vertical to slightly rearward in plowing position.



A25567

A25567

## 8 Preparing the Tractor




5-8

### On-land

Left and Right Lift Links (A) — Set equal length.

Center Link (B) — Set at minimum length.

## FLOAT PINS



Set the float pins (A) in the no-float position.

A25965



# Preparing the Plow

---

## LUBRICATION

Lubricate the plow. See pages 60-64.


## TIRE INFLATION

Make certain all plow tires are inflated to 250 kPa (2.5 bar) (36 psi) of air pressure.

9-19

## PLOW BOTTOMS

The surfaces of the plow bottoms have been painted with protective black paint. In soils where the black paint will not wear off, remove with diesel fuel.




A17628Y-2

A17628Y-2

## BOLTS AND SET SCREWS

Before using a new plow or one which has been stored, be sure all bolts and set screws are tight and all cotter pins spread. Check for loose bolts, screws, and parts when lubricating the plow. Be sure the bolts that hold the plow bottoms to the standards are tightened to the proper torque. See bolt torque chart, page 68.


## IN-FURROW PLOWS




### Hitch Side Plates

Be certain the hitch side plates are attached as shown for 4, 5 and 6 bottom plows.

9-19



Be certain the hitch side plates are attached as shown for 7 bottom plows.



### Hitch Crossbar

To set the hitch crossbar, check the chart on page 11 to find the recommended crossbar position for your size plow and width of cut desired. Also refer to the illustration on page 11 for locating the first hitch mounting bolt (Position A).

Attach crossbar (B) to mounting bracket (C) with remaining three M 20 x 170 cap screws, lock washers, and nuts.

Torque cap screws to 340 N-m (250 lb-ft).

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)