

John Deere

**1458**

Forwarder

OMF062128

**Operator's and  
Maintenance Manual**

Serial Number WJ1458X002001-

ENG

# OPERATOR'S AND MAINTENANCE MANUAL

## *John Deere 1458 Forwarder*

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2001  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved.

**Table to enter serial No. and dealer**

Machine serial No.
Dealer

The information contained in this manual is comprised of instructions which will assist the operator to operate the machine in a safe and efficient manner. Make sure this manual is always close at hand and available to all who work on the machine. Should this manual be lost or should it deteriorate to an unintelligible state, contact John Deere or your nearest John Deere dealer for a replacement manual.

If you sell the machine, be sure to give this manual to the new owners.

Continuing product improvement made by John Deere may result in changes to the machine which are not covered in this manual. Should you need up-to-date information about your machine or should you have questions in regards to this manual, please contact John Deere or your John Deere dealer.



## **CAUTION**

**Only persons whose training has been approved by John Deere are permitted to operate John Deere machinery.**

**Improper operation and maintenance of this machine can be hazardous and could result in serious injury or death.**

**Therefore, it is of paramount importance that all the instructions given in this manual and during training be followed when the machine is operated or serviced.**

**The safety rules are given in the group 3.**

# OPERATOR AND MAINTENANCE MANUAL

## *John Deere Forwarder* **1458**

INTRODUCTION	<b>1</b>
WARRANTY	<b>2</b>
SAFETY RULES	<b>3</b>
CONTROLS AND SIGNAL LIGHTS	<b>4</b>
OPERATING THE FORWARDER	<b>5</b>
MAINTENANCE	<b>6</b>
HYDRAULIC SYSTEM	<b>7</b>
ELECTRICAL SYSTEM	<b>8</b>
POWER TRANSMISSION	<b>9</b>
BOOM	<b>10</b>
EQUIPMENT	<b>11</b>
TECHNICAL SPECIFICATIONS	<b>12</b>
TROUBLESHOOTING	<b>13</b>

---

<b>1.</b>	<b>Introduction</b>	<b>1-1</b>
1.1	General	1-1
1.2	Where to Find Decals and Serial Number	1-3
<b>2.</b>	<b>Warranty</b>	<b>2-1</b>
2.1	Warranty Information	2-1
<b>3.</b>	<b>Safety Instructions</b>	<b>3-1</b>
3.1	Safety Features	3-1
3.2	General	3-2
3.3	Safety Symbol	3-2
3.3.1	Signal Words	3-2
3.4	General Safety Rules	3-3
3.4.1	Protective Structures	3-5
3.4.2	Boarding the Machine	3-6
3.5	Operating Safety Precautions	3-7
3.5.1	Alarms	3-9
3.5.2	Secondary Exit	3-10
3.5.3	Driving on Frozen Waters	3-11
3.5.4	Power Cables	3-12
3.5.5	Driving on Public Roads and Other Transport Driving	3-13
3.6	Servicing Safety Precautions	3-14
3.7	Fire Prevention	3-18
3.7.1	What to Do if the Machine Catches Fire	3-19
3.8	Safety Signs	3-20
3.8.1	Safety Sign Information	3-20
3.8.2	Positions in the Machine	3-23
3.8.3	Decals	3-24
<b>4.</b>	<b>Controls and Signal Lights</b>	<b>4-1</b>
4.1	General	4-1
4.2	Front Dashboard	4-2
4.3	Start Key Positions	4-4
4.4	Window Washers and Wipers	4-5
4.5	Overhead Panel Switches	4-6
4.6	Warning Lights	4-7
4.6.1	Warning Lamps and Buzzer	4-8

---

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)