

6620, SIDEHILL 6620, 7720, AND 8820 COMBINES



OPERATORS MANUAL 6620, SIDEHILL 6620, 7720, AND 8820 COMBINES

OMH116946 I3 English

JOHN DEERE HARVESTER WORKS
OMH116946 I3

LITHO IN THE U.S.A.
ENGLISH



INTRODUCTION



This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.


Your operator's manual contains SI metric equivalents which follow immediately after the U.S. customary units of measure.

"Right-hand" and "left-hand" sides are determined by facing in the direction the combine will travel when in use.

Record your combine product identification and serial number in the space provided.

The warranty on this combine appears on your copy of the purchase order which you should have received from your dealer when making your purchase. This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provided field improvements, often without charge to the customer, even if the product is out of warranty.

Warranty and field improvements are a part of John Deere's product support program for customers who operate and maintain their equipment as described in this manual. Should the equipment be abused or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.





Contents

	Page
Contents	1
Safety	2
Operator's Station	6
Engine Break-In	19
Prestarting Checks	20
Operating the Engine	22
Driving the Combine	27
Transporting	30
Lighting and Signals	31
Fuels and Lubricants	36
Lubrication and Maintenance	42
Fundamentals of Combine Harvesting	57
Headers	81
Feeder House	85
Separator	142
Grain Tank and Unloading Auger	204
Engine Service	212
Electrical System	228
Monitors	234
Hydraulic System	245
SideHill Leveling System	249
Power Train	256
Air Conditioner and Heater	287
Trouble Shooting	292
Storage	316
Specifications	321
Index	330



Safety

SAFETY DECALS



H28488N




CAUTION, WARNING or DANGER: Decals with these headings and symbol indicate the possibility of personal injury.

IMPORTANT: Decals with this heading indicate the possibility of damage to the machine.

Decals are located in areas where they apply.

AVOID CONTACT WITH MOVING PARTS



H31200

H31200

A—Pinch Points
B—Belt Drive

Keep guards and shields in place at all times while operating the combine. Always disengage separator and shut off engine before removing guards or shields.

Modifications to the machine may impair the function and or safety and affect machine life.


Keep hands, feet, and clothing away from power-driven parts.

Never clean, lubricate, or adjust the combine when it is running unless it is specifically stated to do so.

Everyone must be clear before starting engine or running combine.

Never attempt to clear obstructions off the header or unplug or clean separator unless the separator is disengaged and the engine is shut off.

LEAVING COMBINE UNATTENDED



H37524


Before leaving the combine unattended, turn off engine and remove keys, support the header with either the hydraulic cylinder safety stop, or lower it to the ground. The gearshift lever must be in neutral and the parking brake engaged. Lock cab doors.

SERVICE TIRES SAFELY

Failure to follow proper procedures when mounting a tire on a wheel or rim can produce an explosion which may result in serious injury or death. Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job. Have it done by your John Deere dealer or a qualified tire repair service.

When seating tire beads on rims, never exceed 35 psi (240 kPa) (2.4 bar) or maximum inflation pressures specified by tire manufacturers for mounting tires. Inflation beyond this maximum pressure may break the bead, or even the rim, with dangerous explosive force. If both beads are not seated when the maximum recommended pressure is reached, deflate, reposition tire, re-lubricate bead, and reinflate.

Detailed tire mounting instructions, including necessary safety precautions, are contained in John Deere Fundamentals of Service (FOS) Manual 55, Tires and Tracks, available through your John Deere dealer. Such information is also available from the Rubber Manufacturers Association and from tire manufacturers.




- A—Use a safety cage if available.
B—Do not stand over tire. Use a clip-on chuck and extension hose.

11431.1

WASHING FRONT CAB WINDOW

To wash front window of cab, stand on ground and use a long handled squeegee or mop to reach top of window. Do not stand on feeder house or header top beam, as this could result in a fall.




1135340

SERVICING DRIVES AND DRIVE RELATED AREAS

Shut off engine and remove key before servicing the combine in either a belt driven area or any area receiving power from a belt drive. Some drives, due to their clutching and declutching characteristics, can be engaged when the engine is running by the applying or removing of outside forces.

Replace any shields that were removed.



OPERATE SAFELY



Clothing worn by operator must be fairly tight and belted. Loose jackets, shirts, or sleeves must never be worn.



Disengage separator lever, move shift lever to neutral and sound horn before starting engine.

Be careful when operating on hillsides so the combine will not tip.

Always keep the combine in gear when going down hills.

Use right-hand cab door to get to engine compartment or feeder house areas. Never climb to these areas from the ground.



Do not ride or attempt to climb rear ladder while combine is moving.



When operating combine in extremely muddy conditions, swing ladder up to prevent it from being bent when backing up.

The radio antenna must be bent forward and secured with clip any time the combine may come into contact with a high voltage wire or when combine is transported.

BATTERIES



H36842


Batteries generate explosive gases. Keep sparks, flames, burning cigarettes, or other ignition sources away at all times. Always shield eyes when working near batteries. Always wear safety glasses.

Do not connect or disconnect live circuits.

Turn off charger before attaching or removing a lead from the battery.

Ventilate the area when charging.

NOISE



X7662

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs (A) or earplugs (B) to protect against objectionable or uncomfortable loud noises.


A—Earmuffs
B—Earplugs

AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pin holes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result.

Cracking hydraulic line fittings to lower the feeder house will result in an instantaneous dropping of feeder house or feeder house and header.



X9511


FIRE EXTINGUISHER

Have a multipurpose dry chemical fire extinguisher filled and handy. Know how to use it.

DO NOT refuel with the engine running.

DO NOT smoke or use a lantern when refueling.

The part number of the extinguisher is AT62018. See Operator's Station for installation instructions.



H35337

H35337

TRANSPORT SAFELY

Never ride or allow anyone on the operator's platform.


Be extra careful when transporting the combine in hilly country. Never transport with grain in tank and always lock brake pedals together.

Never transport combine with 1253A Row Crop Head attached faster than 8 mph (12.9 km/h). A model 25 Combine Transport Trailer Frame is available for transporting headers.

When transporting the combine on a road or highway, use accessory lights and devices for adequate warning to the operators of other vehicles. In this regard, check local governmental regulations. Always check width laws.

The radio antenna must be bent forward and secured with clip when transporting combine. This prevents the antenna coming into contact with a high voltage wire.

At certain transport speeds a hopping action occurs with 73 x 44.00-32 high flotation tires. Speeding up or slowing down eliminates the problem.




H35338

H35338



Operator's Station

INSTRUMENTS AND CONTROLS IDENTIFICATION




	Page		Page
A—Reel Lift or Variable Speed Feeder House Control	84,85	I —Throttle	18
B—Turn Signals	29	J —Reel Drive or Belt Pickup Drive Control	84
C—Steering Wheel	—	K —Variable Speed Feeder House Reverser Handle	86
D—Hydrostatic Drive Speed Range Control (Optional) or Selective Ground Speed Control	28	L —Parking Brake	279
E—Header Lift Control Lever	83	M—Concave Opening Control	142
F—Separator Control Lever	142	N—Brake Pedals	28
G—Gearshift	27,28	O—Clutch Pedal (Posi-Torq™)	27,28
H—Cylinder Speed Control	143	P—Steering Column Pedal	18
		Q—Grain Tank Unloading Auger Lever	205
		R—Unloading Auger Hydraulic Swing Control	205


H35341

Instrument Panel Controls and Instruments

	Page
A —Cylinder Speed Tachometer	8
B —Header Electromagnetic Clutch Switch	83
C —Digital Display Speed Monitoring System	8
D —Horn Button	—
E —Ignition Switch	18
F —Fuel Shutoff Knob	22
G —Ashtray	—
H —Light Switch	32
I —Cigarette Lighter	—
J —Ether Aid Button	26
K —Engine Hour Meter	8
L —DIAL-A-MATIC® Header Height Control Switch (Optional)	84
M —4-Wheel Drive Switch (Optional)	266
N —Fuel Gauge	9
O —Voltmeter	9
P —Engine Oil Pressure Gauge	9
Q —Coolant Temperature Gauge	10
R —Air Filter Restriction Indicator Light	10
S —Parking Brake Indicator Light	10
T —Transmission Oil Pressure Indicator Light	11
U —Hydraulic Oil Overheating Indicator Light	11
V —Plugged Straw Walker Indicator Light	10
W —Hydrostatic Oil Overheating Indicator Light	11
X —HARVES TRAK™ Monitor	12




H50083



H50239

SideHill 6620 Only


	Page
A —Manual Leveling Control Switch	251
B —Leveling Control Cut-Out Switch	251



H36843

Operator's Cab Controls

A —High Pressure Switch Light	13,291
B —Air Conditioning Temperature Control Knob	13
C —Heater Control Knob	13
D —Pressurizer Fan Switch	13
E —Windshield Wiper Switch	13
F —Air Flow Directional Louvers	13



H37662

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com