

106 COMBINE



OPERATORS MANUAL 106 COMBINE

OMH65141 K7 English

OMH65141 K7

LITHO IN THE U.S.A. ENGLISH



TO THE PURCHASER

The combine you have purchased has been carefully designed and manufactured to provide years of dependable, economical service.

To further insure trouble-free service, we recommend that you follow closely all instructions concerning operation, lubrication, adjustments and service. Preventive maintenance has proven to be much more economical than corrective maintenance. Should you require information not covered in this manual, consult your John Deere dealer.

KEEP YOUR COMBINE A JOHN DEERE COMBINE

Genuine John Deere Parts fit properly and insure satisfactory service because they are made from the original patterns and from the same material used in new machines. Should your combine require replacement parts, go to your John Deere dealer where you can obtain Genuine John Deere Parts—accept no substitues.

ATTACHMENTS

In addition to the equipment furnished with your combine, attachments are available to help you do a better job in a special crop or condition. These attachments, illustrated and described in the attachment section, are available from your John Deere dealer.

LOCATION REFERENCE

"Right-hand" and "left-hand" sides are determined by facing in the direction the combine will travel when in use.

SERIAL NUMBERS

Your combine and platform have serial numbers.

When ordering parts, always bring with you the model and complete serial numbers given on the serial number plates. By doing so, you will assist your John Deere dealer in giving you prompt, efficient service.

The combine serial number is on a plate located on the grain tank unloading auger drive support bracket on the right-hand side of combine.


The platform serial number is on a plate located on the outside of the right-hand platform end sheet.


Record these Serial Numbers in the space provided below.

Combine Serial No	 	 	
Platform Serial No		 	
Date Purchased	 		

CONTENTS

	Page		Page
Specifications	2	Lubrication and periodic service	. 17
Controls and instruments	5	Adjustments and service	. 26
Tractor hookup	6	Trouble shooting	. 55
Operation	9	Attachments	. 61
Operating speeds and settings	13	Index	. 63
Safety suggestions	16		







SPECIFICATIONS

NOTE: The 106 Combine platform is available as a pickup platform, with additional parts available to convert to a cutting platform when desired.

PLATFORM PLATFORM AUGER CYLINDER CONCAVE **BEATER** (Behind the Cylinder) SEPARATOR Type...... Grain conveyor-straw walker **GRAIN CONVEYOR** CLEANING FAN Type..... Five-bladed undershot

CHAFFER

OTAT EX						
Type. Width. Length with extension. Area.	48 In 60-3/4 In.					
SIEVE						
Type. Width. Length. Area.	48 In. 45 In.					
CHAFFER EXTENSION						
Type	Adjustable					
Width.						
Length						
Area	591 Sq. In.					
:						
TOTAL CLEANING AREA OF						
CHAFFER, SIEVE AND CHAFFER EXTENSION	E 070 Ca. Ta					
EXTENSION.	5,078 Sq. in.					
STRAW WALKERS						
Number						
Width						
Length with pans extended						
Area						
Number of steps						
Bearings Oil :						
Extension pans One or						
GRAIN TANK	7% 					
Capacity	hel (approx.)					
WEIGHTS						
Combine with 14-ft, pickup platform						
(with 132 In. belt pickup)	. 9817 Lbs.					
(without 132 In. belt pickup)	. 9057 Lbs.					
COMBINE DIMENSIONS						
Shipping length	04 E4 10 E					
Shipping width	11 Ft.					
For other dimensions	Page 4					
TIRE						
Size	18.4-26, R3					
Ply	6					
Pressure	16 psi					

(Specifications and design subject to change without notice.)

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com