

DRAPER PLATFORM FOR 7700 COMBINE



JOHN DEERE

OPERATORS MANUAL DRAPER PLATFORM FOR 7700 COMBINE

OMH78032 K9 English

OMH78032 K9


LITHO IN THE U.S.A.
ENGLISH





To the Purchaser


This new draper platform for the 7700 Combine was carefully designed and manufactured to give years of dependable service. To keep it running efficiently, read the instructions in this operator's manual. Each section is clearly identified so you can easily find the information you need—whether it is operation, lubrication, or adjustments and service. Read the Table of Contents to learn where each section is located.

 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

“Right-hand” and “left-hand” sides are determined by facing in the direction the draper platform will travel when in use.

Record Platform Serial Number and the date of purchase in the space provided on page 32. Your dealer needs this information to give you prompt, efficient service when you order parts. If your draper platform requires replacement parts, go to your John Deere dealer where you can obtain Genuine John Deere parts—accept no substitutes.

The warranty on this draper platform appears on your copy of the purchase order which you should have received from your dealer when you purchased the platform.





Contents

	Page		Page
Operation	2	Assembly	11
Platform Height Control	2	Shipping Bundles	11
Hydraulic Lift Reel	2	Installing Cutter Bar	12
Hydrostatic Drive Reel	3	Attaching Knife to Bell Crank	13
Safety Suggestions	3	Installing Left-Hand Divider, Shoe, and Reel Support Arm	14
Lubrication	4	Installing Right-Hand Divider, Shoe, and Reel Support Arm	16
Adjustments and Service	5	Installing Drapers	18
Draper Platform	5	Installing Hydraulic Tubes	19
Adjusting Drapers	5	Installing Hydrostatic Motors and Hoses	21
Adjusting Platform Auger	6	Installing Reel	22
Adjusting Platform Auger Drive	6	Installing Knife, Auger, and Draper Drive Shields	23
Adjusting Draper Drive	6	Installing Hydraulic Lift Reel Control Lever and Valve Adapter	24
Adjusting Knife Register	7	Installing Hydrostatic Drive Reel Pump	26
Adjusting Control Valve	7	Installing Hydrostatic Drive Reel Valve and Hoses	28
Replacing Drapers	8	Attaching Platform and Connecting Hoses	31
Hydraulic Lift Reel	9		
Bleeding the System	9		
Hydrostatic Drive Reel	9		
Forward and Rearward Adjustment	9		
Pitch Adjustment	9		
Tightening Pump Drive Belt	10		
Tightening Reel Drive Chain	10		
Connecting Hoses	10	Specifications	32




Operation

The basic operation of the draper platform is the same as the regular detachable platform and can be found in the operation section of the combine operator's manual.

The draper platform differs from the regular detachable platform in that three drapers are positioned between the extended cutter bar and platform auger. The drapers provide a greater distance between the cutter bar and platform auger.

With the extended cutter bar and positive feeding by the drapers, tall crops or downed and twisted crops are cut and conveyed evenly by the drapers eliminating bunching and uneven feeding of the crop to the platform auger, feeder conveyor, and threshing cylinder.

PLATFORM HEIGHT CONTROL




To lower the platform, move the platform height control lever forward.

To raise the platform, move the lever rearward.


Regulate the speed of platform lowering by turning a cap screw on the control valve (see page 7).

HYDRAULIC LIFT REEL



To raise the reel, move the lever rearward. To lower the reel, move the lever forward. The lever automatically returns to neutral when released.


The control valve, located under the operator's platform, has an adjustment to control speed of reel lowering. Regulate the speed of reel lowering by turning a nut on the control valve (see page 7).



The height range of the reel is determined by the location of the bottom of the hydraulic cylinders in the adjusting brackets. Select the range that is right for the crop being harvested. Be certain that both cylinders are adjusted alike or the reel will not be level with the cutter bar.

IMPORTANT: When the hydraulic cylinders are completely retracted, be certain that the reel tines do not strike the cutter bar.

HYDROSTATIC DRIVE REEL



The reel speed may be changed from 0 rpm to 30 rpm (regular) or 30 rpm to 44 rpm (special) by turning the control knob on the console.

To increase the reel speed, turn the knob toward FAST. To decrease the reel speed, turn the knob toward SLOW.

Use the reference indicator as a guide to return to the reel speed that was previously found best for a particular crop or field condition.

The reel may be adjusted forward or rearward and also for different pitch. See page 9.

SAFETY SUGGESTIONS



Study these suggestions carefully and insist that they be followed by those working with you and for you.

All machinery should be operated only by responsible persons who have been delegated to do so.

Never clean, oil, or adjust the draper platform when it is running.

Clothing worn by operator should be fairly tight and belted. Loose jackets, shirts, or sleeves should never be worn because of the danger of getting into moving parts.

Make certain everyone is clear of the combine before starting the combine engine so no one can be struck by moving parts.

Always disengage drive and shut off the combine engine before working on the draper platform.

Replace badly frayed or worn belts before they break.

Be certain shields and guards are in place and in good condition before starting in the field.

Provide a first-aid kit for use in case of accident, and use proper antiseptics on scratches, cuts, etc., without delay, to prevent the possibility of infection.

Never attempt to clear obstructions off the platform unless the combine is stopped and the combine engine is shut off.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com