

2140 Tractor (From Serial No. 450,000 L)




JOHN DEERE

OPERATORS MANUAL 2140 Tractor (From Serial No. 450,000 L)

OML40936 J5 English

John Deere Werke Mannheim
OML40936 J5

LITHO IN U.S.A.
ENGLISH





INSPECTIONS

We appreciate the confidence you have shown in John Deere and your John Deere dealer for the purchase of this equipment.

We want you to have the best performance from your new machine. To accomplish this, your dealer will perform a Predelivery Inspection and will familiarize you with the proper and safe operation of this machine.

After the machine has operated the first 100 hours, you should contact your dealer and arrange an appropriate date at which the After-Sale Inspection will be performed. It will be performed most effectively in the workshop of your dealer.

Your dealer completed the predelivery inspection according to the check list, while at the end of this manual you will find the After-Sale Inspection check list.

These check lists will be completed by your dealer while the inspections are being performed. He will then forward the original and one copy of each inspection list to the John Deere Sales Branch Service Department, retaining the second copy for his files. The dealer will confirm completion of these inspections on that portion of the check list which remains in this manual.

The After-Sale Inspection is an important prerequisite to assure best performance of your new machine. For this reason you should not miss THE OPPORTUNITY to make proper arrangements with your dealer to get this service done at the proper time.

SAFETY



CAUTION: This safety alert symbol indicates important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

IMPORTANT: This machine is designed and manufactured according to JOHN DEERE specifications. To avoid accidents and to assure optimum performance the machine must not be modified or altered in ways not approved by JOHN DEERE, nor must it be used in conditions or for purposes it is not designed for.

To assure safe operation of this machine, read and observe the Safety Rules on the first pages of this manual.

MEASUREMENTS

Your operator's manual contains the international standardized SI metric measurement system.

DIRECTION

Right-hand and left-hand sides of this machine are determined by facing in the direction of forward travel.

SERIAL NUMBERS

Record the serial numbers of your machine in the spaces provided at the end of this manual and provide this information to your dealer when ordering spare parts.

© Deere & Co., European Office,
D-6800 Mannheim

All information, illustrations and specifications contained in this operators manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Identification Views



L16916 A

L16916A-2140ALE-250583



L 32348

L32348-2140ALE-250583

Contents

Safety	05-	Operators Platform and SG2 Cab	30-
– General	05-1	– “Bilux” lighting	30-1
– Operation	05-4	– “Sealed-Beam” lighting	30-4
– Service	05-6	– Operator’s seat	30-5
 		– Roll guard	30-6
Controls and Instruments	10-	– Seat belt	30-6
– Controls	10-1	– Opening windows	30-6
– Control lights	10-2	– Torques for hardware	30-7
– Instruments	10-3	– Windshield wipers	30-7
 		– Windshield washers	30-8
Break-In Period	15-	– Cab air filters	30-8
– After first 4 and 8 hours	15-1	– Fan, air louvers, heater	30-9
– After first 50 hours	15-1	– Air conditioning system	30-9
– Within first 100 hours	15-2	– Cab interior lights	30-10
– After first 100 hours	15-2	– Adjusting steering wheel	30-10
 		– Cab hatch	30-10
Operating the Engine	20-	 	
– Prestarting check	20-1	Wheel Treads, Tires and Ballast	35-
– Starting the engine	20-2	Wheel treads	35-1
– Cold weather starting aids	20-2	– Adjusting front wheel tread	35-1
– Thermostart aid	20-3	– Limiting front wheel steering angle	35-4
– Ether starting aid	20-3	– Checking front wheel toe-in	35-4
– Starting with a booster battery	20-5	– Adjusting front wheel toe-in	35-4
– Starting with a slave battery	20-1	– Rear wheel tread adjustment	35-6
– Towing the tractor to start	20-6	Tires	35-10
– Towing the tractor	20-6	– Tire pressures	35-10
– Parking the tractor	20-7	– Service tires safely	35-10
– Stopping the engine	20-7	– Tire combinations	35-11
 		Ballast	35-12
Operating the Tractor	25-	– Selecting ballast	35-12
– Reduce fuel consumption	25-1	– Measuring rear wheel slip	35-13
– Ground travel speeds	25-3	– Installing rear wheel weights	35-13
– At desired engine speed	25-3	– Filling tires with liquid ballast	35-15
– At rated engine speed	25-4	– Installing front weights	35-16
– Shifting transmission gears	25-6	 	
– Hi-Lo shift unit	25-7	Rockshaft and Three-Point Hitch	40-
– Creeper transmission	25-7	Rockshaft	40-1
– Front wheel drive	25-8	– Control lever	40-1
– Differential lock	25-8	– Selector lever	40-3
– Foot brakes	25-9	– Adjusting rate-of-implement drop	40-5
– Trailer brakes	25-9	Three-point hitch	40-5
		– Center link	40-8
		– Draft links	40-6
		– Lift links	40-9
		– Attaching implements	40-11
		– Positioning sway blocks	40-12

Contents

Additional Equipment	45-	Service-Engine	75-
Front hitch	45-1,100-4	– Engine oil	75-1
Selective control valves	45-1	– Engine crankcase filter element	75-2
– Hydraulic hose couplers	45-3	– Alternator V-belt tension	75-2
– Maximum permissible oil withdrawal	45-6	– Checking engine speeds	75-3
– Remote hydraulic cylinder	45-7		
Drawbar	45-8	Service-Cooling System	80-
Front trailer hitch	45-9	– Checking coolant level	80-1
Swinging drawbar	45-8	– Replacing coolant	80-2
Swinging trailer hitch	45-10		
Hydraulic trailer hitch	45-11	Service-Axles and Wheels	85-
		– Lubricating front axle and front wheels	85-1
Power Take-Off	50-	– Checking front axle oil levels	85-2
– PTO guard	50-1	– Lubricating rear axle bearings	85-2
– PTO options	50-1	– Changing front axle oil	85-3
– Operating rear PTO	50-2		
– Changing PTO shaft	50-2	Service-Fuel System	90-
– Hand shift PTO	50-3	– Checking fuel filter element	90-1
– Operating front PTO	50-3	– Replacing fuel filter	90-1
– Attaching PTO driven equipment	50-4	– Bleeding the fuel system	90-2
		– Draining water trap	90-2
Fuel, Lubricants, Hydraulic			
Oil and Coolant	55-	Service-Transmission/Hydraulic System	95-
Fuel	55-1	– Checking oil level	95-1
– Fuel storage	55-1	– Replacing filter element	95-1
Fluid for hydraulically operated clutch	55-1	– Changing transmission/hydraulic oil	95-2
Lubricants	55-2		
– Engine oil	55-2	Service-Miscellaneous	100-
– Transmission/hydraulic oil	55-2	– Checking clutch pedal adjustment	
– Front axle oil	55-3	(mechanically operated clutch)	100-1
– EP multipurpose grease	55-3	– Checking clutch reservoir fluid level	100-1
– Engine coolant	55-4	– Operator’s seat	100-1
		– Cab air filters	100-2
Lubrication and Periodic Service	60-	– Clutch throw-out bearing	100-3
– Service intervals	60-1	– Hydraulic trailer hitch	100-3
– Removing radiator grille screens	60-1	– Compressor V-belt	100-3
– Removing hood	60-1	– 3-point hitch	100-4
– Service time-table	60-2	– Front hitch	100-4
		– Front PTO	100-5
Service-Air Intake System	65-	– Replacing hydrostatic steering filter	100-5
– Air cleaner	65-1		
– Cleaning primary air filter element	65-1		
– Secondary (safety) air filter element	65-2		
– Air pre-cleaner	65-3		
– Dust unloading valve	65-3		
– Air intake hoses	65-3		
Service-Brakes	70-		
– Bleeding brakes	70-1		
– Adjusting handbrake	70-2		

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com