

John DeereOperator's Manual5020 TractorOM-R48276(Serial No. 30,001-up)Issue H0





TO THE PURCHASER

Your versatile new John Deere Tractor meets the exacting requirements of modern farming.

Operating ease and comfort, hydraulic power when and where you need it, the ability to match engine power and transmission speed to any job, outstanding economy and dependability, modern styling, and simplicity of lubrication and service are all special features of this great tractor.

We are confident this modern tractor, combined with equally advanced John Deere tools and implements, will help you to farm better, easier, and more profitably.


This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

At the time the tractor was delivered, the John Deere dealer discussed with you its safe operation and proper care. However, before putting the tractor to work, read this manual. It contains complete instructions for operating the tractor, caring for it, and taking full advantage of its many time- and labor-saving features. After reading the manual, keep it in a convenient place for quick and easy reference if questions arise concerning operation, lubrication, or service.

The warranty on this tractor appears on your copy of the purchase order which you should have received from your dealer when you purchased the tractor.

Your John Deere dealer wants to help you get the most value from your tractor. His skilled servicemen can handle every job efficiently. These men are trained in modern service methods; they have all necessary tools and equipment. If new parts are needed, only genuine John Deere parts will be installed. These parts are exact duplicates of the originals, made from the same patterns and of the same high-quality materials.

When in need of new parts, be prepared to furnish your dealer with the tractor type, complete tractor chassis serial number, engine type, and complete engine serial number. For ready reference, locate and record the above information in the spaces provided in the illustrations below.




Engine Serial Number



CONTENTS

	Page
SPECIFICATIONS	. 2
CONTROLS AND INSTRUMENTS	. 4
OPERATION	. 6
SAFETY RULES	. 32
FUELS AND LUBRICANTS	. 34
LUBRICATION AND PERIODIC SERVICE	. 36
SERVICE	. 44
TRACTOR CAB	. 55
TRACTOR STORAGE	. 58
TROUBLE SHOOTING	. 59
INDEX	. 66



John Deere 5020 Row-Crop Diesel Tractor with Roll-Gard, Canopy, and Double Rear Wheels



SPECIFICATIONS

GROUND SPEEDS: **

*HORSEPOWER:

Measured at the PTO 141.34

ENGINE:

Type . . . 6-cylinder, in-line, valve-in-head Engine Speeds:

Slow idle 800 rpm
Working range 1500 to 2200 rpm
Maximum transport speed 2500 rpm
Bore and stroke $\dots \dots 4-3/4$ in. x 5 in.
Displacement
Compression ratio 16.5 to 1
Firing order 1-5-3-6-2-4
Valve clearance intake 0.018 in.
exhaust 0.028 in.
Injection pump timing TDC


CAPACITIES:

2 U.S. qts. for cab heater)... 33 U.S. qts.

*Above horsepower figure is official at 2200 engine rpm.

1.7 mph 2.6 mph 3.5 mph 4.5 mph 5.6 mph 7.3 mph9.4 mph 8th 15.4 mph 3.4 mph 5.4 mph CLUTCH: Heavy-duty, two 12-in. plates, foot operated LUBRICATION SYSTEM: ... Force-feedpressurized with full-flow oil filter FUEL SYSTEM: Type Direct injection Injection pump type Inlet metering, distributing type Air cleaner Dry type COOLING SYSTEM: Type ... Pressurized with centrifugal pump Engine temperature control . . . Two heavyduty thermostats

**Calculated at 1900 rpm engine speed with 24.5-32 tires.



John Deere 5020 Row-Crop Diesel Tractor

ELECTRICAL SYSTEM: Type 12-volt, negative grounded
Batteries Two 6-volt, 87-plate, 204 ampere-hour, group 6T3A, tractor-type, connected in series
tractor-type, connected in series
TRANSMISSION: Type Syncro-Range, constant-mesh Gear selections 8 forward and 2 reverse Shifting 4 stations, synchronized shifting within stations
POWER TAKE-OFF:
Type.IndependentSpeed (1900 engine rpm).1010 rpmPTO ahead of drawbar hitch point.16 in.PTO shaft above ground.25-1/2 in.
PTO CLUTCH Hydraulically power ac- tuated, hand-operated
HYDRAULIC SYSTEM:
Type Closed center, constant pressure. Includes power steering, power brakes, and implement control.
Maximum pressure 2250 psi BRAKES Hydraulically power actuated, disk-type operating in oil
FRONT TIRES: *** Standard 11.00-16, 8-ply
Row-Crop
Standard
FRONT WHEEL TREAD See page 12 REAR WHEEL TREAD See page 14

•

DIMENSIONS:		
Standard (Fixed tread	front axle):	
Wheel base		. 104 in.
Over-all length		172.3 in.
Over-all height		9 8.3 in.
Height to steering w	heel	82.4 in.
Width		
Drawbar clearance.		. 16 in.
Turning radius		
Row-Crop (81.5-inch t		
Wheel base	102	2 to 106 in.
Over-all length		172.3 in.
Over-all height		
Height to steering w	heel	82.4 in.
Over-all width		108.4 in.
Turning radius		13 ft.
TRACTOR CAB:	NI	
	Not Air Conditioned	Air Conditioned
Blower capacity	290 cfm	560 cfm
Heater capacity	20,000	22,000
 .	btu/hr.	btu/hr.
Exterior cab height		
(tires at loaded radius)) 10 7.3 in.	115.0 in.
SHIPPING WEIGHT (With		for
average field service)		
Standard		15,600 lbs.
Row-Crop	•••••	14,480 lbs.
	•	

***Additional tire sizes available.

(Specifications and design subject to change without notice.)

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com