

**John Deere  
690D Excavator  
693D Feller-Buncher/  
Delimber  
Repair**



**TECHNICAL  
MANUAL**

**John Deere Davenport Works  
TM-1388 (Oct-87)**

Litho in U.S.A.

**690D EXCAVATOR  
693D FELLER-BUNCHER/DELIMBER  
TECHNICAL MANUAL  
TM-1388 (SEP-87)**

**SECTION AND GROUP CONTENTS**

*NOTE: This manual covers machine Repair (gray tabs).*

**SECTION I—GENERAL INFORMATION**

- Group I—Introduction and Safety Information
- Group II—General Specifications
- Group III—Torque Values
- Group IV—Fuels and Lubricants
- Group V—Inspection Procedure

**SECTION 01—TRACKS**

- Group 0130—Track Systems
  - Track Roller, Track Chain, Sprocket, Front Idler, Recoil Spring, Relief Valve and Adjusting Cylinder

**SECTION 02—AXLES AND SUSPENSION SYSTEMS (PROPEL)**

- Group 0250—Axle Shafts, Bearings and Reduction Gears
  - Tow Excavator and Propel Gearbox
- Group 0260—Hydraulic Systems
  - Propel Motor, Propel Brake, Propel Brake Valve with Counterbalance Valve, Hydraulic Lines, and Rotary Manifold

**SECTION 04—ENGINE**

- 6414 Engine—See CTM-4
- Group 0400—Removal and Installation
  - Engine, Oil Pan, Fuel Injection Pump, Injection Nozzles, Bleed Fuel System, Turbocharger and Water Pump, Oil Cooler, Fuel Transfer Pump, and Thermostat

**SECTION 05—ENGINE AUXILIARY SYSTEMS**

- Group 0505—Cold Weather Starting Aids
  - Fluid Starting Aid Solenoid, Nozzle, Engine Coolant Heater
- Group 0510—Cooling Systems
  - Fan, Shroud and Guards, Fan Belt, Radiator
- Group 0515—Speed Controls
  - Speed Control Assembly (Auto Idle), Linkage
- Group 0520—Intake System
  - Air Cleaner, Air Intake System Leakage Test
- Group 0530—External Exhaust Systems
  - Muffler and Bracket
- Group 0560—External Fuel Supply Systems
  - Fuel Tank

**SECTION 07—DAMPENER DRIVE (FLEX COUPLING)**

- Group 0752—Elements

**SECTION 16—ELECTRICAL SYSTEMS**

- Group 1671—Batteries, Support and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1673—Lighting System
- Group 1674—Wiring Harness and Switches
- Group 1677—Motors and Actuators
  - Starting Motor

**SECTION 17—FRAME, CHASSIS, OR SUPPORTING STRUCTURE**

- Group 1740—Frame Installation
  - Welding Repair
- Group 1749—Chassis Weights

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT® 1987  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A JOHN DEERE ILLUSTRATION

/1388 CC1 040987

## SECTION AND GROUP CONTENTS—Continued

### SECTION 18—OPERATOR'S STATION

- Group 1800—Removal and Installation  
Cab or Canopy
- Group 1810—Operator Enclosure  
Windowpanes, Cab Door and  
Latch, Door Lock, Windshield  
Wiper
- Group 1821—Seat
- Group 1830—Heating and Air Conditioning  
Compressor, High Pressure  
Switch, Condenser, Evaporator,  
Expansion Valve, Receiver-Dryer,  
Low Pressure Switch, Air  
Conditioning Switches, Resistor,  
Blower Motor, Heater, Controls

### SECTION 99—DEALER FABRICATED TOOLS

### SECTION 19—SHEET METAL AND STYLING

- Group 1910—Hood or Engine Enclosure

### SECTION 33—EXCAVATOR

- Group 3302—Buckets  
Bucket, Linkage, Bushings, Tooth  
Tip, Tooth Shank
- Group 3340—Frames  
Arm, Boom, Bushings
- Group 3360—Hydraulic System  
Hydraulic Pump, Pilot System  
Pump, Pilot System Pressure  
Regulating Valve, Hydraulic  
Control Valve, Relief Valve Block,  
Hydraulic Control Valve Return  
Restrictors, Reservoir, Return  
Filter, Reservoir Relief Valve, Oil  
Cooler Bypass Valve, Oil Cooler,  
Cylinders, Propel Function Pilot  
Controller Valve, Propel Pilot  
System Check Valve Block, Dig  
Function Pilot Controller Valve,  
Pilot System Shut-off Valve, Pilot  
System Filter, Flow Control Valve

### SECTION 43—SWING, ROTATION OR PIVOTING SYSTEM

- Group 4311—Brakes (Swing Lock)
- Group 4350—Mechanical Drive Elements  
Swing Gearbox, Swing Bearing,  
Seals
- Group 4360—Hydraulic System  
Swing Motor, Crossover Relief  
Valves, Swing Lock Release Valves

/1388 CC2 040987

## INTRODUCTION

This manual is part of a total service support program.

### **FOS Manuals—reference**


### **Technical Manuals—machine service**

### **Component Manuals—component service**

*Fundamentals of Service (FOS) Manuals* cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

*Technical Manuals* are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

*Component Technical Manuals* are concise service guides for specific components. Component technical manuals are written as stand alone manuals covering multiple machine applications.



AB6;RW5559 053;INTRO2 030785

## FEATURES OF THIS TECHNICAL MANUAL

John Deere ILLUSTRATION format emphasizing illustrations and concise instructions in easy-to-use modules.

Emphasis on diagnosis, analysis, and testing so you can understand the problem and correct it.


Diagnostic information presented with the most logical and easiest to isolate problems first to help you identify the majority of routine failures quickly.

Step-by-step instructions for teardown and assembly.

Summary listing at the beginning of each group of all applicable specifications, wear tolerances, torque values, essential tools, and materials needed to do the job.

An emphasis throughout on safety—so you do the job right without getting hurt.

This technical manual was planned and written for you—an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.




AB6;RW5560 053;INTRO3 071085

## USING TABS

To fully utilize this technical manual, you must understand how it is organized.

Only two tab colors are used—gray and yellow. Each color represents a different type of information.

Spend a minute reading this now and save many minutes of searching later.




018;T5933AB T82;FLPD I 260785

## GRAY TAB SECTIONS

The gray tab sections are repair sections that tell how to repair the components of the various systems.

Repair of a component includes:

- Removal from machine (when necessary)
- Disassembly
- Inspection
- Replacement of parts
- Assembly
- Adjustment
- Installation on machine (when necessary)




The numbers used for the repair (gray tab) sections are part of an overall service publication numbering system. The numbers identify the same sections in the parts catalog, flat rate manual, service information bulletins, and service training courses.

018;T5933AC T82;FLPD J 260785

## YELLOW TAB SECTIONS

Each yellow tab section contains information on:

Groups	
05	Theory of Operation
10	System Operational Checks
15	System Diagnostic Information
20	Adjustments
25	Tests



018;T5933AD T82;FLPD K 260785

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)