

Workshop Handbook

66C, 66D turbo

HYDRAULIC SYSTEM

Workshop Handbook

Hydraulic System 66 C

3072 517 M1

HANOMAG

PREFACE and EXPLANATIONS


This manual should assist the skilled construction machine mechanic when carrying out repairs and adjustments on MF construction machines. The procedures are written in such a style that the dismantling and assembling of the components can be carried out successfully and without difficulty.

To assist in the locating of specific test-repair operations, working description etc. this manual is divided into main and sub-groups. This also applies to all types of service manuals.

At the top right hand corner of every page next to the section heading a series of numbers (orientation number) are to be found. These numbers follow in numerical sequence throughout the book.

The section heading applies either to the construction machine type, assembly or component for which the text and illustrations are valid.

Orientation number:



The main group numbers refer to either main assemblies, groups of main assemblies, sub-assemblies or components.

Example: Group 1700 - Steering (mechanical steering, assisted steering, hydro-steering, steering unit)

The sub-group numbers classify the descriptions and details as follows:

- 0 - General
- 1 - Functional description
- 2 - Fault diagnosis and possible remedies
- 3 - Tests and adjustments
- 4 - Strip and rebuild
- 5 - Technical data

C O N T E N T S**SUB GROUP 1****Page****Working (loader) hydraulics**

Illustrations of the individual components	101
Hydraulic diagram of working hydraulics with servo control and steering circuits	102 - 103
Hydraulic diagram with 3-spool control valve and related electrical system	104 - 105
Functional description	105 - 107

Control spool valve

Description and arrangement of the connections	108 - 109
Cross sectional view	110 - 111
Cross sectional view of the 3-spool control valve	112 - 113
Description of the secondary pressure relief valve (shock valve)	114 - 115

Demand/regulating valve

Description and arrangement of the connections	116 - 117
Functional description	118 - 120

Pressure relief valve (servo control)

Description and arrangement of the connections	122 - 123
--	-----------

Servo control valve

Description and arrangement of the connections	124 - 125
Description and arrangement of the connections (3-spool)	126 - 127
Cross sectional view of the 3-spool servo control valve	128 - 129
Pipe connection block for servo control valve	130
Pipe connection block for servo control valve (3-spool)	131

Directional valve

Description and arrangement of the connections	132 - 133
--	-----------

SUB GROUP 2**Working (loader) hydraulics**

Fault diagnosis and possible remedies	201 - 204
---------------------------------------	-----------

C O N T E N T S**SUB GROUP 3**

	Page
Control spool valve	
Secondary pressure relief valve (shock valve) testing	301 - 303
Test method 1	301 - 302
Test method 2	303
2-stage pressure relief valve, pressure testing and adjusting	304 - 307
Spool valve stroke limiters, adjusting	308 - 309
Pressure valve group in the float valve (emergency lowering), adjusting	310 - 311
 Demand/regulating valve	
Regulating pressure, testing and adjusting	312 - 313
 Pressure relief valve	
Pressure testing and adjusting	314 - 315
 Servo control valve	
Switch for tip-in and dump-out, adjusting	316 - 317
 Lift (loader) and bucket cylinders	
Leakage tests	318 - 322
Test method 1	318 - 319
Test method 2	320 - 321
Test method 3	322
 Flow capacities - measuring	323 - 338

CONTENTS

	Page
<u>SUB GROUP 4</u>	
Oil tank	
Removing and refitting	401 - 404
External fittings, removing and refitting	405 - 409
Hydraulic pump (loader pump)	
Removing and refitting	410 - 411
External fittings, removing and refitting	412
Reconditioning	413 - 416
Hydraulic pump (switch pump)	
Removing and refitting	417 - 420
External fittings, removing and refitting	421
Reconditioning	421 - 424
Control spool valve	
Removing and refitting	425 - 432
External fittings, removing and refitting	433
Secondary pressure relief valve (shock valve) reconditioning	435 - 436
Anti-cavitation valve, reconditioning	437
2-stage pressure relief valve, reconditioning	438 - 439
Spool valve stroke limiters, reconditioning	440 - 441
Spool valves, reconditioning	442 - 443
Float valve, reconditioning	444 - 447
Spool group, reconditioning	444 - 445
Pressure valve group, reconditioning	446 - 447
Return flow manifold	
Removing and refitting	448 - 450
External fittings, removing and refitting	451
Reconditioning	452 - 453
Demand/regulating valve	
Removing and refitting	454 - 457
External fittings, removing and refitting	458
Reconditioning	459 - 471
Regulating valve, complete, removing from the demand valve	460 - 461
Regulating valve, reconditioning	462 - 463
Check valve in regulating valve, reconditioning	464 - 465
Control spool in regulating valve, reconditioning	466 - 467
Demand valve, reconditioning	468 - 471
Hydraulic pump (servo control)	
Removing and refitting	472
External fittings, removing and refitting	473
Reconditioning	474 - 476

CONTENTS**Page****Pressure relief valve (servo control)**

Removing and refitting	477
External fittings, removing and refitting	478
Reconditioning	479 - 483

Servo control valve

Removing and refitting	484 - 486
Reconditioning	487 - 499
Spring in control valve lever, removing and refitting	488 - 489
Control valve lever complete and upper seals, removing and refitting	490 - 491
Switch for "Tip-in" and "Dump-out", removing and refitting	492 - 493
Spool reset group for "Tip-in" and "Dump-out", reconditioning	494 - 495
Spool reset group for "Lift" and "Lower", reconditioning	496 - 499

Directional valve

Removing and refitting	4100
Mounting plate, removing and refitting	4101

Lift (loader) cylinders

Removing and refitting	4102 - 4103
External fittings, removing and refitting	4104 - 4105
Lift (loader) cylinder (version 1), reconditioning	4106 - 4107
Piston rod packing seal, fitting	4110 - 4113
Type 1	4110
Type 2	4111
Type 3	4112 - 4113
Piston seals and guide bands, refitting	4115 - 4116
Wrapped bushes, removing and refitting	4117
Lift (loader) cylinder (version 2), reconditioning	4118 - 4127
Piston seals and guide bands, refitting	4124 - 4125
Wrapped bushes, removing and refitting	4126 - 4127

Bucket cylinders

Removing and refitting	4128 - 4129
External fittings, removing and refitting	4130 - 4131
Version 1, reconditioning	4132 - 4133
Version 2, reconditioning	4134 - 4135

Lift and bucket cylinders

Application of "Loctite" to piston rod threads	4136
--	------

SUB GROUP 5**Technical data**

501 - 503

Torque tightening limits

Lift and bucket cylinders

504

66 C *turbo* 66 D *turbo*

Group 2200

HYDRAULIC SYSTEM

Group 1700

STEERING SYSTEM

INDEX

	<u>Page</u>
Loader and steering hydraulic systems data	95
Arrangement of the hydraulic components	96
Pressure test points	99
Hydr. and elect. circuit diagram – hydraulic components	100
Hydr. and elect. circuit diagram – Electrical components and pressure test points	103
Description of the loader hydraulics	104
Automatic boom kickout and return to dig systems Description and adjustments	107
Demand / regulating valve	108
3–spool control valve	111
Service line relief (shock) valves and anti– Cavitation valves	116
Description of the service line relief valve	119
Float spool and pressure reducing valve	120
Oil cooler by–pass valve	124
Servo control circuit pressure relief valve	127
3–spool servo control valve	128
Hydraulic cylinders	135
Return to dig system -- Adjustments (see also page 107)	136
Steering system components:	
Steering valve block	140
Hydro–steering column assembly	144
Mechanical steering lock stop – Function and adjustments	147

LOADER and STEERING HYDRAULICS

Loader hydraulics

A two-stage system where the outputs of the loader pump and switch pump are controlled dependent on system load.

The system is remote controlled via a servo control system.

Steering hydraulics

Articulated steering system with ZF hydro-steering column assembly and two steering cylinders.

Constant oil supply by the steering and switch pumps over the complete engine speed range. With the engine stopped, oil supply to steering system maintained by the ZF emergency steering pump.

Summary of pump outputs and system pressures (see Fig. M 304)

1 Switch pump : HAMWORTHY

Output 155 ltr/min at 2200 rpm

2 Steering pump : HAMWORTHY

Output 91.5 ltr/min at 2200 rpm

3 Loader pump : HAMWORTHY

Output 290 ltr/min at 2200 rpm

4 Servo pump: HAMWORTHY

Output 53.5 ltr/min at 2200 rpm

5 Emergency steering pump: ZF

Output dependent on travel speed of machine, however, at a speed approaching 20 km/h = 50 ltr constant



6b	Oil filter by-pass valve	1.5 bar
7d	Unloading (regulating) valve	140 bar
8a	Steering pressure relief valve	180 bar
8f	Emergency steering circuit relief valve	100 bar
10a	Oil cooler by-pass valve	3.5 bar
12	Servo control pressure holding valve	26 ^{+0.5} bar (24 bar min. engine idling)
14a	Loader hydraulics pressure relief valve	180 ⁺⁵ bar
14f	Service line relief valves (shock valves) bucket dump, crowd and loader lift circuits	320 bar
14h	Pressure reducing valve for reducing static pressure	15 ⁺¹ bar
14i	Emergency lowering pressure relief valve	35 ⁺² bar




LOADER and STEERING HYDRAULICS

Arrangement of the hydraulic components mounted on the transmission assembly

Fig. M 308	1	Switch pump
	2	Steering pump
	3	Loader pump
	4	Servo pump
	7	Demand / regulating valve
	7d	Unloading (regulating) valve
	8	Steering valve block

Fig. M 309	5	Emergency steering pump
	12	Servo circuit pressure holding valve
	18	Check valve





CONTROL VALVE

Secondary pressure relief valve (shock valve), testing


Fig. F 372

- 1 = Valve for bucket tip-in
- 2 = Valve for bucket dump out
- 3 = Valve for loader arm lift


Test instruction 1:

Fig. G 1

Testing with the simple to operate OTC-hand pump, type Y-21-1 incorporating a pressure relief valve of 700 bar (10 150 psi) and a pressure gauge of 0 - 400 bar (5800 psi). Other available hand pumps, e. g. track pin press, can also be used.



F 372




G 1

Connecting the hand pump:



Fig. E 230


Support the loader arms and dump out the bucket. Depressurize the system.





E 230

Fig. F 248

Remove the cover plate.



F 248



CONTROL VALVE

Fig. F 777

According to which valve is to be tested, connect the pressure gauge together with the hand pump to the test point.

Test points: 1 = bucket tip-in
2 = bucket dump out
3 = loader arm lift

Filling the hand pump:

Before commencing the test process the hand pump is filled as follows:

With the pump connected and in the "RELEASE" position, screw out the closing screw plug (1) at the rear of the pump. With the engine running at idling speed, carefully operate the hydraulic circuit in question until oil flows out of the screw plug bore (1). Select the "PUMP" position on the pump and replace and tighten the plug screw. The pump is now full.

Note: The pump can also be filled by hand with hydraulic oil via the screw plug bore (1).

Testing process:

The hand pump must remain in the "PUMP" position. This is every important, otherwise the pump can be damaged. The hydraulic circuit in question is now operated against the "crowd" stops. Next, shift the control lever into "NEUTRAL" and stop the engine.

By using the hand pump, oil can now be pumped into the system circuit that is to be tested until the shock valve opens. Read off the gauge pressure.

Finally re-support the loader arms and depressurize the system.

Only now should the hand pump be switched to the "RELEASE" position and disconnected.

CONTROL VALVE

Adjusting lifting and lowering pressure

Fig. F 769

Disconnect the pilot control line pipe (20) and block the union (21) using the closing plug (A) (special tool).





Fig. F 773

A = Special tool - closing plug
(Supplied in special tool set, Part. No. 2975 116 - M 91)



F 773

Figs. F 770, F 378 and F 379

Using the special tools (B and C), hold the threaded sleeve (11) tight, unscrew the adaptor nut (1) and loosen the lock nut (3).

Note: When unscrewing the adaptor nut and lock nut, ensure that the threaded sleeve (11) is not screwed out, as this will result in the valve cone (10) being forced



out of its guide by the valve spring (9) and falling into the control valve housing!






Fig. F 774

Special tools (B and C)
Used in conjunction with 2 straight ring spanners.
(Supplied in special tool set, Part No. 2975 116 - M 91).



F 774



CONTROL VALVE

Figs. F 771, F 378 and F 379

Using the special tool (D) screw in as far as possible the adjusting sleeve (6). The stop nut (7) will now abut the housing.




Fig. F 775

Special tool (D) for adjusting sleeve.
(Supplied in special tool set, Part No. 2975 116 M 91).

Start the engine.

With the loader arms against the crowd stop (lower) the pressure should be 180 - 185 bar (2610 - 2682 psi).

Adjusting the pressure:

Figs. F 772, F 378 and F 379

With the screwdriver (E), hold the valve piston (8) tight and loosen the lock nut (5) with the special socket (F).

By screwing in the valve piston (8) the pressure will be increased, by screwing out, the pressure will be reduced.

Note: During this process the adjusting sleeve (6) should not be allowed to turn !

After adjustment tighten the lock nut (5).





Fig. F 776

Special tool: Screwdriver (E) and special socket (F).

(Supplied in special tool set, Part No. 2975 116 M 91).

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com